

Quant

ELEVATING TECHNOLOGY

Command Line Managed Switch Configuration



Command Line Interface

Managed Switch Software

USER GUIDE

Q-M-3800-48P-L3-4S-R	Q-M-4800-24P-L3-4S-V	Q-IE-7300-16P-8S-E	Q-EP-9500-24P-L3-4G-R
Q-EP-9500-48P-L3-4G-R	Q-IE-9600-24P-L3-4G-E-R	Q-IE-9600-48P-L3-4G-E-R	

Rev. 2.0

USING THIS DOCUMENT

This document is intended for the software engineer’s general information on the usage of switch source files for the chip development of the switch team.

Though every effort has been made to ensure that this document is current and accurate, more information may have become available subsequent to the production of this guide.

REVISION HISTORY

Revision	Release Date	Summary
2.0	2022-10	First Release

Table of Contents

Command Line Interface 1

Managed Switch Software 1

1. AAA 11

- aaa authentication 11
- login authentication 12
- ip http login authentication 13
- enable authentication 14
- show aaa authentication 15
- show line lists 16
- tacacs default-config 16
- tacacs host 17
- show tacacs default-config 18
- show tacacs 19
- show default-config 19
- radius host 20
- show radius default-config 21
- show radius 22

2. ACL 22

- mac acl 22
- permit (MAC) 23
- deny (MAC) 24
- ip acl 25
- permit (IP) 26
- deny (IP) 28
- ipv6 acl 31
- permit (IPv6) 31
- deny (IPv6) 33
- bind acl 112
- show acl 112
- show acl utilization 113

3. Administration 113

- configure 113
- clear arp-cache 114
- enable 114
- end 115
- exit 115
- hostname 116
- interface 117
- ip service 117
- ip session-timeout 118
- ip ssh 119
- line 120
- reboot 121
- exec-timeout 121
- password-thresh 122
- ping 123
- traceroute 124
- show arp 124
- show cpu utilization 125
- show history 125
- show info 126
- show ip 127
- show ip http 127
- show line 128
- show memory statistics 128
- show privilege 129
- show username 129
- show users 130
- show version 130
- system name 131

- system contact 132
 - system location 132
 - terminal length 133
 - username 133
4. Authentication Manager 134
- authentication 134
 - authentication (Interface) 135
 - authentication mac radius 136
 - authentication mac local 137
 - authentication guest-vlan 138
 - authentication guest-vlan (Interface) 139
 - authentication host-mode 139
 - authentication max-hosts 140
 - authentication method 141
 - authentication order 141
 - authentication port-control 142
 - authentication radius-attributes vlan 143
 - authentication reauth 143
 - authentication timer inactive 144
 - authentication timer quiet 145
 - authentication timer reauth 146
 - authentication web local 146
 - authentication web max-login-attempts 147
 - clear authentication sessions 148
 - dot1x 149
 - dot1x guest-vlan 149
 - dot1x max-req 150
 - dot1x port-control 151
 - dot1x reauth 152
 - dot1x timeout reauth-period 152
 - dot1x timeout quiet-period 153
 - dot1x timeout server-timeout 154
 - dot1x timeout supp-timeout 155
 - dot1x timeout tx-period 156
 - show authentication 156
 - show authentication sessions 158
5. Diagnostic 159
- show cable-diag 159
 - show fiber-transceiver 159
6. DHCP Snooping 160
- ip dhcp snooping 160
 - ip dhcp snooping vlan 161
 - ip dhcp snooping trust 162
 - ip dhcp snooping verify 163
 - ip dhcp snooping rate-limit 163
 - clear ip dhcp snooping statistics 164
 - show ip dhcp snooping 164
 - show ip dhcp snooping interface 165
 - show ip dhcp snooping binding 165
 - ip dhcp snooping option 166
 - ip dhcp snooping option action 167
 - ip dhcp snooping option circuit-id 167
 - ip dhcp snooping option remote-id 168
 - show ip dhcp snooping option 168
 - ip dhcp snooping database 169
 - ip dhcp snooping database write-delay 170
 - ip dhcp snooping database timeout 171
 - clear ip dhcp snooping database statistics 172
 - renew ip dhcp snooping database 172
 - show ip dhcp snooping database 173
7. DoS 174
- dos 174
 - dos (interface) 176
 - show dos 176
8. Dynamic ARP Inspection 177
- ip arp inspection 177
 - ip arp inspection vlan 178
 - ip arp inspection trust 178

- ip arp inspection validate 179
 - ip arp inspection rate-limit 180
 - clear ip arp inspection statistics 180
 - show ip arp inspection 181
 - show ip arp inspecton interface 181
9. GVRP 182
- gvrp (Global) 182
 - gvrp (Interface) 183
 - gvrp registration-mode 184
 - gvrp vlan-create-forbid 184
 - clear gvrp statistics 185
 - show gvrp statistics 186
 - show gvrp 187
 - show gvrp configuration 187
10. IGMP Snooping 188
- ip igmp snooping 188
 - ip igmp snooping report-suppression 188
 - ip igmp snooping version 189
 - ip igmp snooping unknown-multicast action 189
 - ip igmp snooping querier 190
 - ip igmp snooping vlan 190
 - ip igmp snooping vlan fastleave 191
 - ip igmp snooping vlan last-member-query-count 191
 - ip igmp snooping vlan last-member-query-interval 192
 - ip igmp snooping vlan query-interval 193
 - ip igmp snooping vlan response-time 193
 - ip igmp snooping vlan robustness-variable 194
 - ip igmp snooping vlan router 194
 - ip igmp snooping vlan forbidden-port 195
 - ip igmp snooping vlan static-port 195
 - ip igmp snooping vlan forbidden-router-port 196
 - ip igmp snooping vlan static-router-port 196
 - ip igmp snooping vlan static-group 197
 - ip igmp snooping vlan group 198
 - profile range 198
 - ip igmp profile 199
 - ip igmp filter 199
 - ip igmp max-groups 200
 - ip igmp max-groups action 201
 - clear ip igmp snooping groups 201
 - clear ip igmp snooping statistics 202
 - show ip igmp snooping groups counters 203
 - show ip igmp snooping groups 203
 - show ip igmp snooping router 204
 - show ip igmp snooping querier 205
 - show ip igmp snooping 205
 - show ip igmp snooping vlan 206
 - show ip igmp snooping forward-all 207
 - show ip igmp profile 207
 - show ip igmp filter 208
 - show ip igmp max-group 208
 - show ip igmp max-group action 209
11. IP Source Guard 210
- ip source verify 210
 - ip source binding 211
 - show ip source interface 211
 - show ip source binding 212
12. Link Aggregation 212
- lag 212
 - lag load-balance 213
 - lacp port-priority 214
 - lacp system-priority 214
 - lacp timeout 215
 - show lacp 215
 - show lag 218
13. LLDP 219
- clear lldp statistics 219
 - lldp 219

- lldp rx 220
 - lldp tx-interval 221
 - lldp reinit-delay 222
 - lldp holdtime-multiplier 222
 - lldp lldpdu 223
 - lldp med 224
 - lldp med fast-start-repeat-count 225
 - lldp med location 225
 - lldp med network-policy 226
 - lldp med network-policy (Interface) 227
 - lldp med network-policy voice auto 228
 - lldp med tlv-select 229
 - lldp tlv-select 230
 - lldp tlv-select pvid 231
 - lldp tlv-select vlan-name 232
 - lldp tx 233
 - lldp tx-delay 234
 - show lldp 235
 - show lldp local-device 236
 - show lldp med 237
 - show lldp neighbor 239
 - show lldp statistics 240
 - show lldp tlv-overloading 242
14. Logging 244
- clear logging 244
 - logging 244
 - logging host 245
 - logging severity 245
 - show logging 246
15. MAC Address Table 247
- clear mac address-table 247
 - mac address-table aging-time 248
 - mac address-table static 248
 - show mac address-table 249
 - show mac address-table counters 250
 - show mac address-table aging-time 251
16. MAC VLAN 251
- vlan mac-vlan group (Global) 251
 - vlan mac-vlan group (Interface) 252
 - show vlan mac-vlan groups 252
 - show vlan mac-vlan interfaces 253
17. Management ACL 254
- management access-list 254
 - management access-class 254
 - deny 255
 - permit 255
 - no sequence 256
 - show management access-class 257
 - show management access-list 257
18. Mirror 258
- mirror session destination interface 258
 - mirror session source interface 258
 - show mirror 259
19. MLD Snooping 260
- ipv6 mld snooping 260
 - ipv6 mld snooping report-suppression 260
 - ipv6 mld snooping version 261
 - ipv6 mld snooping unknown-multicast action 261
 - ipv6 mld snooping vlan 262
 - ipv6 mld snooping vlan parameters 263
 - ipv6 mld snooping vlan fastleave 264
 - ipv6 mld snooping vlan last-member-query-count 265
 - ipv6 mld snooping vlan last-member-query-interval 265
 - ipv6 mld snooping vlan query-interval 266
 - ipv6 mld snooping vlan response-time 267
 - ipv6 mld snooping vlan robustness-variable 267
 - ipv6 mld snooping vlan router 268

- ipv6 mld snooping vlan static-port 268
 - ipv6 mld snooping vlan forbidden-router-port 269
 - ipv6 mld snooping vlan forbidden-router-port 269
 - ipv6 mld snooping vlan static router port 270
 - ipv6 mld snooping vlan static-group 270
 - ipv6 mld snooping vlan group 271
 - profile range 272
 - ipv6 mld profile 272
 - ipv6 mld filter 273
 - ipv6 mld max-groups 273
 - ip igmp max-groups action 274
 - clear ipv6 mld snooping groups 274
 - clear ipv6 mld snooping statistics 275
 - show ipv6 mld snooping groups counters 275
 - show ipv6 mld snooping groups 276
 - show ipv6 mld snooping router 276
 - show ipv6 mld snooping 277
 - show ipv6 mld snooping vlan 278
 - show ipv6 mld snooping forward-all 279
 - show ipv6 mld profile 279
 - show ipv6 mld filter 280
 - show ipv6 mld max-group 280
 - show ipv6 mld port max-group action 281
20. MVR 282
- mvr 282
 - mvr vlan 282
 - mvr group 283
 - mvr mode 284
 - mvr query-time 285
 - mvr port type 285
 - mvr port immediate 286
 - mvr static group 287
 - clear mvr members 288
 - show mvr members 289
 - show mvr interface 289
 - show mvr 289
21. Port 290
- back-pressure 290
 - clear interface 291
 - description 292
 - duplex 292
 - eee 293
 - flowcontrol 294
 - jumbo-frame 295
 - media-type 295
 - protected 296
 - show interface 296
 - speed 297
 - shutdown 298
22. Port Error Disable 299
- errdisable recovery cause 299
 - errdisable recovery interval 300
 - show errdisable recovery 300
23. Port Security 301
- port-security (Global) 301
 - port-security (Interface) 302
 - port-security address-limit 302
 - show port-security 303
 - show port-security interface 304
24. Protocol VLAN 304
- vlan protocol-vlan group (Global) 304
 - vlan protocol-vlan group (Interface) 305
 - show vlan protocol-vlan 306
 - show vlan protocol-vlan interfaces 306
25. QoS 307
- qos 307
 - qos cos 308

- qos map 308
 - qos queue 311
 - qos remark 312
 - qos trust 313
 - qos trust (Interface) 314
 - show qos 314
 - show qos interface 315
 - show qos map 315
 - show qos queueing 317
26. Rate Limit 318
- rate limit egress 318
 - rate limit egress queue 319
 - rate limit ingress 319
27. RMON 320
- rmon event 320
 - rmon alarm 321
 - rmon history 322
 - clear rmon interfaces statistics 323
 - show rmon interfaces statistics 324
 - show rmon event 325
 - show rmon event log 325
 - show rmon alarm 326
 - show rmon history 327
 - show rmon history statistic 327
 - show snmp community 329
 - show snmp engineid 330
 - show snmp group 330
 - show snmp host 331
 - show snmp trap 331
 - show snmp view 332
 - show snmp user 332
 - snmp 333
 - snmp community 333
 - snmp engineid 334
 - snmp engineid remote 335
 - snmp group 335
 - snmp host 336
 - snmp trap 337
 - snmp user 338
 - snmp view 339
29. Spanning Tree 339
- instance (MST) 339
 - name (MST) 340
 - revision (MST) 340
 - show spanning-tree 341
 - show spanning-tree interface 342
 - show spanning-tree mst 342
 - show spanning-tree mst configuration 344
 - show spanning-tree mst interface 344
 - spanning-tree 345
 - spanning-tree bpdu 346
 - spanning-tree bpdu-filter 346
 - spanning-tree bpdu-guard 347
 - spanning-tree cost 347
 - spanning-tree forward-time 348
 - spanning-tree hello-time 348
 - spanning-tree edge 349
 - spanning-tree link-type 349
 - spanning-tree max-hops 350
 - spanning-tree maximum-age 350
 - spanning-tree mcheck 351
 - spanning-tree mode 351
 - spanning-tree mst configuration 352
 - spanning-tree mst cost 352
 - spanning-tree mst port-priority 353
 - spanning-tree mst priority 354
 - spanning-tree pathcost method 354
 - spanning-tree port-priority 355
 - spanning-tree priority 356

- spanning-tree tx-hold-count 356
- 30. Storm Control 357
 - show storm-control 357
 - storm-control 358
 - storm-control action 359
 - storm-control ifg 359
 - storm-control level 360
 - storm-control unit 361
- 31. System File 362
 - boot system 362
 - copy 362
 - delete 364
 - restore-defaults 365
 - save 365
 - show bootvar 366
 - show config 366
 - show flash 368
- 32. Surveillance VLAN 369
 - surveillance-vlan (Global) 369
 - surveillance-vlan (Interface) 369
 - surveillance-vlan vlan 370
 - surveillance-vlan oui-table 371
 - surveillance-vlan cos (Global) 372
 - surveillance-vlan cos (Interface) 372
 - surveillance-vlan mode 373
 - surveillance-vlan aging-time 374
 - show surveillance-vlan 375
- 33. Time 376
 - clock set 376
 - clock timezone 377
 - clock source 378
 - clock summer-time 379
 - show clock 380
 - sntp 381
 - show sntp 382
- 34. UDLD 382
 - errdisable recovery cause udld 382
 - udld 383
 - udld aggressive 384
 - udld message time 385
 - udld reset 385
 - show udld 386
- 35. VLAN 386
 - vlan 386
 - Name (vlan) 387
 - switchport mode 388
 - switchport hybrid pvid 389
 - switchport hybrid ingress-filtering 389
 - switchport hybrid acceptable-frame-type 390
 - switchport hybrid allowed vlan 391
 - switchport access vlan 392
 - switchport tunnel vlan 393
 - switchport trunk native vlan 394
 - switchport trunk allowed vlan 395
 - switchport default-vlan tagged 396
 - switchport forbidden default-vlan 397
 - switchport forbidden vlan 398
 - switchport vlan tpid 399
 - management-vlan 400
 - show vlan 400
 - show vlan interface membership 401
 - show interface switchport 401
 - show management-vlan 402
- 36. Voice VLAN 403
 - voice-vlan (Global) 403
 - voice-vlan (Interface) 403

- voice-vlan vlan 404
- voice-vlan oui-table 405
- voice-vlan cos (Global) 406
- voice-vlan cos (Interface) 406
- voice-vlan mode 407
- voice-vlan aging-time 408
- show voice-vlan 409

- 37. Static Routing 410
 - IPv4 Interface 410
 - IPv4 Routes 411
 - IPv4 ARP 411
 - IPv6 Interface 412
 - IPv6 Address 413
 - IPv6 Routes 413
 - IPv6 Neighbors 414

- 38. POE 415
 - POE Port Setting 415
 - POE Port Schedule Setting 415

- 40.ERPS 416
 - Erps (global) 416
 - Erps instance (Global) 416
 - Control-vlan 417
 - wtr-timer 417
 - guard-timer 418
 - work-mode 418
 - ring<ID> 418
 - ring-level 419
 - port 419
 - mel 420
 - Ring enable 420
 - protected-instance 420
 - Show erps instance 421

- 41.OSPF 421
 - Ospf (global) 421
 - router-id 423
 - timers throttle spf 423
 - refresh timer 424
 - auto-cost reference-bandwidth 424
 - default-metric 425
 - passive-interface vlan-interface 425
 - passive-interface default 425
 - area 426
 - network 426
 - default-cost 427
 - authentication 427
 - ospf authentication 428
 - ospf authentication-key 428
 - ospf authentication-digest-key 428
 - ospf cost 429
 - ospf priority 429
 - ospf hello-interval 430
 - ospf dead-interval 430
 - ospf retransmit-interval 430
 - ospf transmit-delay 431
 - ospf network 431
 - ospf mtu-ignore 432

- 42.RIP 432
 - rip (Global) 432
 - network 433
 - route 433
 - version 433
 - distance 434
 - distance 434
 - distribute-list 435
 - access-list 435
 - show ip route rip 435
 - log 436

43.VRRP 436

- vrrp vrid 436**
- vrrp priority 437**
- preempt-mode 437**
- advertise 437**
- track 438**
- show 438**

44.DHCP SERVER 439

- dhcp-server 439**
- dhcp-server group(global) 439**
- ip pool 439**
- gateway 440**
- section 440**
- dhcp-server group(if-vlan) 440**
- show dhcp-server 441**

45.DNS 441

- ip domain 441**
- ip domain name 442**
- ip name-server 442**
- ip host 442**
- show hosts 443**

AAA

aaa authentication

Syntax `aaa authentication (login | enable) (default | LISTNAME) METHODLIST [METHODLIST] [METHODLIST] [METHODLIST]`
`no aaa authentication (login | enable) LISTNAME`

Parameter login Add/Edit login authentication list

enable Add/Edit enable authentication list

default Edit default authentication list

LISTNAME Specify the list name for authentication type

METHODLIST Specify the authenticate method, including none, local, enable, tacacs+, radius.

Default Default authentication list name for type login is “default” and default method is “local”. Default authentication list name for type enable is “default” and default method is “enable”

Mode Global Configuration

Usage Login authentication is used when user try to login into the switch. Such as CLI login dialog and WEBUI login web page.
 Enable authentication is used only on CLI for user trying to switch from User EXEC mode to Privileged EXEC mode.

Both of them support following authenticate methods.

Local: Use local user account database to authenticate. (This method is not supported for enable authentication)

Enable: Use local enable password database to authenticate.

Tacacs+: Use remote Tacacs+ server to authenticate.

Radius: Use remote Radius server to authenticate.

None: Do nothing and just make user to be authenticated.

Each list allows you to combine these methods with different orders. For example, we want to authenticate login user with remote Tacacs+ server, but server may be crashed. Therefore, we need a backup plan, such as another Radius server. So we can configure the list with Tacacs+ server as first authentication method and Radius server as second one.

Use no form to delete the existing list. However, “default” list is not allowed to remove.

Example

This example shows how to add a login authentication list to authenticate with order tacacs+, radius, local.

```
Switch(config) # aaa authentication login test1 tacacs+ radius local
```

This example shows how to show existing login authentication lists Switch#

```
show aaa authentication login lists Login List Name | Authentication Method List
```

```
-----+-----
default | local
test1 | tacacs+ radius local
```

This example shows how to add an enable authentication list to authenticate with order tacacs+, radius, enable.

```
Switch(config) # aaa authentication enable test1 tacacs+ radius enable
```

This example shows how to show existing enable authentication lists Switch#

```
show aaa authentication login lists Enable List Name | Authentication Method List
```

```
-----+-----
default | enable
test2 | tacacs+ radius enable
```

login authentication

Syntax **login authentication** *LISTNAME*
 no login authentication

Parameter *LISTNAME* Specify the login authentication list name to use.

Default Default login authentication list for each line is “default”.

Mode Line Configuration

Usage Different access methods are allowed to bind different login authentication lists. Use “**login authentication**” command to bind the list to specific line (console, telnet, ssh).

Use no form to bind the “default” list back.

Example This example shows how to create a new login authentication list and bind to telnet line.

```
Switch(config) # aaa authentication login test1
```

tacacs+ radius local

```
Switch(config)# line telnet
Switch(config-line)# login authentication test1
```

This example shows how to show line binding lists.

```
Switch# show line lists
Line Type | AAA Type | List Name
-----+-----+-----
console | login | default
| enable | default
telnet | login | test1
| enable | default
ssh | login | default
| enable | default http | login | default
https | login | default
```

ip http login authentication

Syntax **ip (http | https) login authentication LISTNAME**
 no ip (http | https) login authentication

http	Bind login authentication list to user access WEBUI with http protocol
https	Bind login authentication list to user access WEBUI with https protocol
LISTNAME	Specify the login authentication list name to use.

Default Default login authentication list for each line is “default”.

Mode Global Configuration

Usage Different access methods are allowed to bind different login authentication lists. Use “**ip (http | https) login authentication**” command to bind the list to WEBUI access from http or https.

Use no form to bind the “default” list back.

Example This example shows how to create two new login authentication lists and bind to http and https.

```
Switch(config)# aaa authentication login test1 tacacs+ radius local
Switch(config)# aaa authentication login test2
```

radius local

```
Switch(config)# ip http login authentication test1
Switch(config)# ip https login authentication test2
```

This example shows how to show line binding lists.

```
Switch# show line lists
Line Type | AAA Type | List Name
-----+-----+-----
console | login | default
| enable | default
telnet | login | default
| enable | default
ssh | login | default
| enable | default http | login | test1
https | login | test2
```

enable authentication

Syntax **enable authentication** *LISTNAME*
no enable authentication

Parameter *LISTNAME* Specify the enable authentication list name to use.

Default Default enable authentication list for each line is “default”.

Mode Line Configuration

Usage Different access methods are allowed to bind different enable authentication lists. Use “**enable authentication**” command to bind the list to specific line (console, telnet, ssh).

Use no form to bind the “default” list back.

Example This example shows how to create a new enable authentication list and bind to telnet line.

```
Switch(config)# aaa authentication enable test1 tacacs+
radius enable
Switch(config)# line telnet
Switch(config-line)# enable authentication test1
```

This example shows how to show line binding lists.

```
Switch# show line lists
Line Type | AAA Type | List Name
```

```
console | login | default
| enable | default
telnet | login | default
| enable | test1
ssh | login | default
| enable | default http | login | default
https | login | default
```

show aaa authentication

Syntax `show aaa authentication (login | enable) lists`

Parameter	login	Show login authentication list
	enable	Show enable authentication list

Default No default value for this command

Mode Privileged EXEC

Usage Use “**show aaa authentication**” command to show login authentication or enable authentication method lists.

Example

```
This example shows how to show existing login authentication lists Switch#
show aaa authentication login lists Login List Name |
Authentication Method List
-----+-----
default | local
test1 | tacacs+ radius local
```

```
This example shows how to show existing enable authentication lists Switch#
show aaa authentication login lists Enable List Name |
Authentication Method List
-----+-----
default | enable
test2 | tacacs+ radius enable
```


show line lists

Syntax **show line lists**

Parameter

Default No default value for this command

Mode Privileged EXEC

Usage Use “**show line lists**” command to show all lines’ binding list of all authentication, authorization, and accounting function.

Example

This example shows how to show line binding lists.

```
Switch# show line lists
```

```
Line Type | AAA Type | List Name
```

```
-----+-----+-----
console | login | default
| enable | default
| exec | default
| commands | default
| accounting-exec | default
telnet | login | default
| enable | default
| exec | default
| commands | default
| accounting-exec | default ssh | login | default
| enable | default
| exec | default
| commands | default
| accounting-exec | default http | login | default
https | login | default
```

tacacs default-config

Syntax **tacacs default-config [key *TACACSKEY*] [timeout <1-30>]**

Parameter **key *TACACSKEY*** Specify default tacacs+ server key string

timeout <1-30> Specify default tacacs+ server timeout value

Default Default tacacs+ key is “”.
Default tacacs+ timeout is 5 seconds.

Mode Global Configuration

Usage Use “**tacacs default-config**” command to modify default values of tacacs+ server. These default values will be used when user try to create a new tacacs+ server and not assigned these values.

Example This example shows how modify default tacacs+ configuration

```
Switch(config)# tacacs default-config timeout 20
Switch(config)# tacacs default-config key tackey
```

This example shows how to show default tacacs+ configurations.

```
Switch# show tacacs default-config
```

```
Timeout | Key
-----+-----
10 | tackey
```

This example shows how to create a new tacacs+ server with above default config and show results.

```
Switch(config)# tacacs host 192.168.1.111
```

```
Switch# show tacacs
```

```
Prio | Timeout | IP Address | Port | Key
-----+-----+-----+-----+-----
---
1 | 10 | 192.168.1.111 | 49 |
  tackey
```

tacacs host

Syntax **tacacs host** *HOSTNAME* [**port** <0-65535>] [**key** *TACPLUSKEY*] [**priority** <0-65535>] [**timeout** <1-30>]
no tacacs [**host** *HOSTNAME*]

Parameter	host <i>HOSTNAME</i>	Specify tacacs+ server host name, both IP address and domain name are available.
	port <0-65535>	Specify tacacs+ server udp port
	key <i>TACPLUSKEY</i>	Specify tacacs+ server key string
	priority <0-65535>	Specify tacacs+ server priority
	timeout <1-30>	Specify tacacs+ server timeout value

Default Default tacacs+ key is “”.
Default tacacs+ timeout is 5 seconds.

Mode Global Configuration

Usage Use “**tacacs host**” command to add or edit tacacs+ server for authentication, authorization or accounting.

Use no form to delete one or all tacacs+ servers from database.

Example This example shows how to create a new tacacs+ server
Switch(config)# **tacacs host 192.168.1.111 port 12345**
key tacacs+ priority 100 timeout 10

This example shows how to show existing tacacs+ server.

Switch# **show tacacs**

Prio | Timeout | IP Address | Port | Key

-----+-----+-----+-----+-----+-----

100 | 10 | 192.168.1.111 | 12345 |

tacacs+

show tacacs default-config

Syntax show tacacs default-config

Parameter

Default No default value for this command

Mode Privileged EXEC

Usage Use “**show tacacs default-config**” command to show tacacs+ default configurations.

Example This example shows how to show default tacacs+ configurations.
Switch# **show tacacs default-config**
Timeout | Key
-----+-----
10 | tackey

show tacacs

Syntax **show tacacs**

Parameter

Default No default value for this command

Mode Privileged EXEC

Usage Use “**show tacacs**” command to show existing tacacs+ servers.

Example

This example shows how to show existing tacacs+ server.
 Switch# **show tacacs**
 Prio | Timeout | IP Address | Port | Key
 -----+-----+-----+-----+-----

 100 | 10 | 192.168.1.111 | 12345 |
 tacacs+

show default-config

Syntax **radius default-config [key RADIUSKEY] [retransmit <1-10>] [timeout <1-30>]**

Parameter

key RADIUSKEY	Specify default radius server key string
retransmit <1-10>	Specify default radius server retransmit value
timeout <1-30>	Specify default radius server timeout value

Default Default radius key is “”.
 Default radius retransmit is 3 times. Default radius timeout is 3 seconds.

Mode Global Configuration

Usage Use “**radius default-config**” command to modify default values of radius server. These default values will be used when user try to create a new radius server and not assigned these

values.

Example This example shows how modify default radius configuration

```
Switch(config)# radius default-config timeout 20
Switch(config)# radius default-config key radiuskey
Switch(config)# radius default-config retransmit 5
```

This example shows how to show default radius configurations. Switch# **show radius default-config**

Retries	Timeout	Key
5	20	radiuskey

```
-----+-----+-----
```

```
5 | 20 | radiuskey
```

radius host

Syntax **radius host** *HOSTNAME* [**auth-port** <0-65535>] [**key** *RADIUSKEY*] [**priority** <0-65535>] [**retransmit** <1-10>] [**timeout** <1-30>] [**type** (login|802.1x|all)]

no radius [**host** *HOSTNAME*]

This example shows how to create a new radius server with above default config and show results.

```
Switch(config)# radius host 192.168.1.111
Switch# show radius
```

Prio	IP Address	Auth-Port	Retries	Timeout	Usage-Type	Key
1	192.168.1.111	1812	5			
20	All					radiuskey

Parameter	Configuration	Description
host <i>HOSTNAME</i>		Specify radius server host name, both IP address and domain name are available.
auth-port <0-65535>		Specify radius server udp port
key <i>RADIUSKEY</i>		Specify radius server key string
priority <0-65535>		Specify radius server priority
retransmit <1-10>		Specify radius server retransmit times
timeout <1-30>		Specify radius server timeout value

type login 802.1X	Usage type of this server Use for login
all	Use for 802.1X authentication Use for both login and 802.1X authentication

Default	Default radius key is “”. Default radius timeout is 3 seconds.
----------------	---

Mode	Global Configuration
-------------	----------------------

Usage	Use “ radius host ” command to add or edit an existing radius server. Use no form to delete one or all radius servers from database.
--------------	--

Example	This example shows how to create a new radius server Switch(config)# radius host 192.168.1.111 auth-port 12345 key radiuskey priority 100 retransmit 5 timeout 10 type all
----------------	--

This example shows how to show existing radius server.

```
Switch# show radius
Prio | IP Address | Auth-Port| Retries| Timeout| Usage-
Type| Key
-----+-----+-----+-----+-----+-----
+-----+-----
100 | 192.168.1.111 | 12345 | 5 | 10
| All | radiuskey
```

show radius default-config

Syntax	show radius default-config
---------------	-----------------------------------

Parameter

Default	No default value for this command
----------------	-----------------------------------

Mode	Privileged EXEC
-------------	-----------------

Usage	Use “ show radius default-config ” command to show radius default configurations.
--------------	--

Example

```
This example shows how to show default radius configurations. Switch# show radius default-config Retries| Timeout| Key
-----+-----+-----
5 | 20 | radiuskey
```

show radius

Syntax `show radius`

Parameter

Default No default value for this command

Mode Privileged EXEC

Usage Use “**show radius**” command to show existing radius servers.

Example

```
This example shows how to show existing radius server.
Switch# show radius
Prio | IP Address | Auth-Port| Retries| Timeout| Usage-
Type| Key
-----+-----+-----+-----+-----
+-----+-----+-----+-----+-----
100 | 192.168.1.111 | 12345 | 5 | 10
| All | radiuskey
```

ACL

mac acl

Syntax `mac acl NAME no mac acl NAME`

Parameter `NAME` Specify the name of MAC ACL

Default No default is defined

Mode Global Configuration

Usage Use the **mac acl** command to create a MAC access list and to enter mac-acl configuration mode. The name of ACL must be unique that can not have same name with other ACL or QoS policy. Once an ACL is created, an implicit “deny any” ACE created at the end of the ACL. That is, if there are no matches, the packets are denied. Use the no form of this command to

delete.

Example

The example shows how to create a mac acl. You can verify settings by the following **show acl** command

```
Switch334455(config)# mac acl test
Switch334455(mac-al)# show acl
MAC access list test
```

permit (MAC)

Syntax

```
[sequence <1-2147483647>] permit (A:B:C:D:E:F/A:B:C:D:E:F|any)
(A:B:C:D:E:F/A:B:C:D:E:F|any) [vlan <1-4094>] [cos <0-7> <0-7>]
[ethype <0x0600-0xFFFF>]
```

no sequence <1-2147483647>

Parameter

<1-2147483647>	(Optional) Specify sequence index of ACE, the sequence index represent the priority of an ACE in ACL.
(A:B:C:D:E:F/A:B:C:D:E:F any)	Specify the source MAC address and mask of packet or any MAC address.
(A:B:C:D:E:F/A:B:C:D:E:F any)	Specify the destination MAC address and mask of packet or any MAC address
[vlan <1-4094>]	(Optional) Specify the vlan ID of packet.
[cos <0-7> <0-7>]	(Optional) Specify the Class of Service value and mask of packet.
[ethype <0x0600-0xFFFF>]	(Optional) Specify Ethernet protocol number of <u>packet</u>

Default

No default is defined.

Mode

MAC ACL Configuration

Usage Use the permit command to add permit conditions for a mac ACE that bypass those packets hit the ACE. The “**sequence**” also represents hit priority when ACL bind to an interface. An ACE not specifies “**sequence**” index would assign a sequence index which is the largest existed index plus 20. If packet content can match more than one ACE, the lowest sequence ACE is hit. An ACE can not be added if has the same conditions as existed ACE.

Example

The example shows how to add an ACE that permit packets with source MAC address 22:33:44:55:66:77 、 VLAN 3 and Ethernet type 1999. You can verify settings by the following **show acl** command

```
Switch334455(config)# mac acl test
Switch334455(mac-al)# sequence 999 permit
22:33:44:55:66:77/FF:FF:FF:FF:FF:FF any vlan 3 ethtype 0x2800
Switch334455(mac-al)# show acl
MAC access list test
sequence 999 permit 22:33:44:55:66:77/FF:FF:FF:FF:FF:FF any vlan 3 ethtype
0x2800
```

deny (MAC)

Syntax [sequence <1-2147483647>] deny (A:B:C:D:E:F/A:B:C:D:E:F|any) (A:B:C:D:E:F/A:B:C:D:E:F|any) [vlan <1-4094>] [cos <0-7> <0-7>] [ethtype <0x0600-0xFFFF>] [shutdown] no sequence <1-2147483647>

Parameter	<1-2147483647>	(Optional) Specify sequence
-----------	----------------	-----------------------------

index of ACE, the sequence index represent the priority of an ACE in ACL.

(A:B:C:D:E:F/A:B:C:D:E:F any)	Specify the source MAC address and mask of packet or any MAC address.
-------------------------------	---

(A:B:C:D:E:F/A:B:C:D:E:F any)	Specify the destination MAC address and mask of packet or any MAC address.
-------------------------------	--

[vlan <1-4094>]	(Optional) Specify the vlan ID of packet.
-----------------	---

[cos <0-7> <0-7>]	(Optional) Specify the Class of Service value and mask of packet.
-------------------	---

[ethtype <0x0600-0xFFFF>]	(Optional) Specify Ethernet protocol number of packet
---------------------------	---

[shutdown]	(Optional) Shutdown interface while ACE hit
------------	---

Default	No default is defined.
---------	------------------------

Mode	MAC ACL Configuration
------	-----------------------

Usage Use the deny command to add deny conditions for a mac ACE that drop those packets hit the ACE. The “**sequence**” also represents hit priority when ACL bind to an interface.

An ACE not specifies “**sequence**” index would assign a sequence index which is the largest existed index plus 20. If packet content can match more than one ACE, the lowest sequence ACE is hit. An ACE cannot be added if has the same conditions as existed ACE. Use “**shutdown**” to shutdown interface while ACE hit.

Example

The example shows how to add an ACE that denies packets with destination MAC address aa:bb:cc:xx:xx:xx and VLAN 9. You can verify settings by the following **show acl** command

```
Switch334455(config)# mac acl test
Switch334455(mac-al)# sequence 30 permit any any
Switch334455(mac-al)# deny any aa:bb:cc:00:0:00/FF:FF:FF:00:00:00 vlan 9
shutdown
Switch334455(mac-al)# show acl
MAC access list test
sequence 30 permit any any
sequence 50 deny any AA:BB:CC:00:00:00/FF:FF:FF:00:00:00 vlan 9 shutdown
```

ip acl

Syntax **ip acl NAME no ip acl NAME**

Parameter	NAME	Specify the name of IPv4 ACL
Default	No default is defined	
Mode	Global Configuration	

Usage Use the **ip acl** command to create an IPv4 access list and to enter ip-acl configuration mode. The name of ACL must be unique that can not have same name with other ACL or QoS policy. Once an ACL is created, an implicit “deny any” ACE created at the end of the ACL. That is, if there are no matches, the packets are denied. Use the no form of this command to delete.

Example

The example shows how to create an IP ACL. You can verify settings by the following **show acl** command

```
Switch334455(config)#ip acl iptest
Switch334455(ip-al)# show acl
IP access list iptest
```

```
65535>|echo|discard|daytime|ftp-
data|ftp|telnet|smtp|time|hostname|whois|
tacacs-
ds|domain|www|pop2|pop3|syslog|talk|klogin|kshell|sunrpc|dri
p|PORT_RANGE|any)
[match-all TCP_FLAG] [(dscp|precedence) VALUE]
```

```
[sequence <1-2147483647>] permit udp
(A.B.C.D/A.B.C.D|any) (<0-65535>|echo|discard|
time|nameserver|tacacs-
ds|domain|bootps|bootpc|tftp|sunrpc|ntp|netbios-ns|snmp|
snmptrap|who|syslog|talk|rip|PORT_RANGE|any)
(A.B.C.D/A.B.C.D|any) (<0-65535>|echo|
discard|time|nameserver|tacacs-
ds|domain|bootps|bootpc|tftp|sunrpc|ntp|netbios-ns|
snmp|snmptrap|who|syslog|PORT_RANGE|any)
[(dscp|precedence) VALUE]
```

```
no sequence <1-2147483647>
```

permit (IP)

Syntax

```
[sequence <1-2147483647>] permit (<0- 255>|ipinip|egp|igmp|hmp|rdp|ipv6|
ipv6:rout|ipv6:frag|rsvp|ipv6:icmp|ospf|pim|l2tp|ip) (A.B.C.D/A.B.C.D|any)
(A.B.C.D/A.B.C.D|any)
[(dscp|precedence) VALUE]]
```

```
[sequence <1-2147483647>] permit icmp (A.B.C.D/A.B.C.D|any)
(A.B.C.D/A.B.C.D|any) (<0-
255>|echo-reply|destination-unreachable|source-quench|echo- request|
router-advertisement|router-solicitation|time- exceeded|timestamp| timestamp-
reply|traceroute|any) (<0- 255>|any) [(dscp|precedence) VALUE]
```

```
[sequence <1-2147483647>] permit tcp (A.B.C.D/A.B.C.D|any) (<0-65535>|echo|
discard|daytime|ftp- data|ftp|telnet|smtp|time|hostname|whois|tacacs- ds|domain|www|
pop2|pop3|syslog|talk|klogin|kshell|sunrpc|drip|PORT_RANG E|any)
(A.B.C.D/A.B.C.D|any) (<0-
```

Parameter	<1-2147483647>	(Optional) Specify sequence index of ACE, the sequence index represent the priority of an ACE in ACL.
	(A.B.C.D/A.B.C.D any)	Specify the source IPv4 address and mask of packet or any IPv4 address.
	(A.B.C.D/A.B.C.D any)	Specify the destination IPv4 address and mask of packet or any IPv4 address.
	[dscp VALUE]	(Optional) Specify the DSCP of packet.
	[precedence VLAUE]	(Optional) Specify the IP precedence of packet.
	icmp-type	Specify ICMP message type for filtering ICMP packet. Enter a type name of list or a number of ICMP message type.
	icmp-code	Specify ICMP message code for filtering ICMP packet.
	l4-source-port	Specify TCP/UDP source port of for filtering TCP/UDP packet. Enter a port name of list or a number of TCP/UDP port.
	l4-destination-port	Specify TCP/UDP destination port of for filtering TCP/UDP packet. Enter a port name of list or a number of TCP/UDP port.
	match-all	Specify tcp flag for TCP packet. If a flag should be set it is prefixed by "+" .If a flag should be unset it is prefixed by "-". Available options

are +urg, +ack, +psh, +rst, +syn, +fin, -urg, -ack, -psh, -rst, -syn and -fin.To define more than 1 flag - enter additional flags one after another without a space (example +syn-ack).

Default No default is defined.

Mode IP ACL Configuration

Usage Use the permit command to add permit conditions for an IP ACE that bypasses those packets hit the ACE. The “**sequence**” also represents hit priority when ACL bind to an interface. An ACE not specifies “**sequence**” index would assign a sequence index which is the largest existed index plus 20. If packet content can match more than one ACE, the lowest sequence ACE is hit. An ACE can not be added if has the same conditions as existed ACE.

Example

The example shows how to add a set of ACEs. You can verify settings by the following **show acl** command.

This command shows how to permit a source IP address subnet. Switch334455(ip-al)# **permit ip 192.168.1.0/255.255.255.0**

This command shows how to permit ICMP echo-request packet with any IP address.

Switch334455(ip-al)# **permit icmp any any echo-request any**

This command shows how to permit any IP address HTTP packets with DSCP 5. Switch334455(ip-al)# **permit tcp any any any www dscp 5**

This command shows how to permit any source IP address SNMP packet connect to destination IP address 192.168.1.1.

Switch334455(ip-al)# **permit udp any any 192.168.1.1/255.255.255.255 snmp**

Switch334455(ip-al)# **show acl**

IP access list iptest

sequence 1 permit ip 192.168.1.0/255.255.255.0 any sequence 21 permit icmp any

any echo-request any sequence 41 permit tcp any any any www dscp 5

sequence 61 permit udp any any 192.168.1.1/255.255.255.255 snmp

deny (IP)

Syntax

```
[sequence <1-2147483647>] deny (<0- 255>|ipinip|egp|igp|hmp|rdp|ipv6|
ipv6:rout|ipv6:frag|rsvp|ipv6:icmp|ospf|pim|l2tp|ip) (A.B.C.D/A.B.C.D|any)
(A.B.C.D/A.B.C.D|any)
[[dscp|precedence) VALUE]] [shutdown]
```

```
[sequence <1-2147483647>] deny icmp (A.B.C.D/A.B.C.D|any)
(A.B.C.D/A.B.C.D|any) (<0-
255>|echo-reply|destination-unreachable|
source-quench|echo-request|router-advertisement|router- solicitation|
time-exceeded|timestamp| timestamp-reply|traceroute|any) (<0-255>|any)
[[dscp|precedence) VALUE] [shutdown]
```

```
[sequence <1-2147483647>] deny tcp (A.B.C.D/A.B.C.D|any) (<0-65535>|echo|
discard|daytime|ftp- data|ftp|telnet|smtp|time|hostname|whois|tacacs-ds|
domain|www|pop2|pop3|syslog|talk|klogin|kshell|sunrpc|drip|
PORT_RANGE|any)
(A.B.C.D/A.B.C.D|any) (<0-65535>|echo|discard|daytime|ftp- data|ftp|telnet|
smtp|time|hostname|whois|tacacs- ds|domain|www|pop2|pop3|syslog|talk|
klogin|kshell|sunrpc|drip|PORT_RANGE|any)
```

```
[match-all TCP_FLAG] [[dscp|precedence) VALUE] [shutdown]
```

```
[sequence <1-2147483647>] deny udp (A.B.C.D/A.B.C.D|any) (<0-
65535>|echo|discard|time|nameserver|tacacs- ds|domain|bootps|
bootpc|tftp|sunrpc|ntp|netbios-ns|snmp|snmptrap|who|syslog|
talk|rip|PORT_RANGE|any) (A.B.C.D/A.B.C.D|any) (<0- 65535>|echo|
discard|time|nameserver|tacacs-ds|domain|bootps|bootpc|tftp| sunrpc|ntp|netbios-
ns|snmp|snmptrap|who|syslog|PORT_RANGE|any) [[dscp|precedence) VALUE]
[shutdown]
```

```
no sequence <1-2147483647>
```

Parameter

<1-2147483647>	(Optional) Specify sequence index of ACE, the sequence index represent the priority of an ACE in ACL.
(A.B.C.D/A.B.C.D any)	Specify the source IPv4 address and mask of packet or any IPv4 address.
(A.B.C.D/A.B.C.D any)	Specify the destination IPv4 address and mask of packet or any IPv4 address.
[dscp VALUE]	(Optional) Specify the DSCP of

	packet.
[precedence VLAUE]	(Optional) Specify the IP precedence of packet.
icmp-type	Specify ICMP message type for filtering ICMP packet. Enter a type name of list or a number of ICMP message type.
icmp-code	Specify ICMP message code for filtering ICMP packet.
l4-source-port	Specify TCP/UDP source port of for filtering TCP/UDP packet. Enter a port name of list or a number of TCP/UDP port.
l4-destination-port	Specify TCP/UDP destination port of for filtering TCP/UDP packet. Enter a port name of list or a number of TCP/UDP port.
match-all	Specify tcp flag for TCP packet. If a flag should be set it is prefixed by "+" .If a flag should be unset it is prefixed by "-". Available options are +urg, +ack, +psh, +rst, +syn, +fin, -urg, -ack, -psh, -rst, -syn and -fin.To define more than 1 flag - enter additional flags one after another without a space (example +syn-ack).
[shutdown]	(Optional) Shutdown interface while <u>ACE hit</u>
Default	No default is defined.
Mode	IP ACL Configuration

Usage Use the deny command to add deny conditions for an IP ACE that drop those packets hit the ACE. The “**sequence**” also represents hit priority when ACL bind to an interface. An ACE not specifies “**sequence**” index would assign a sequence index which is the largest existed index plus 20. If packet content can match more than one ACE, the lowest sequence ACE is hit. An ACE can not be added if has the same conditions as existed ACE. Use “**shutdown**” to shutdown interface while ACE hit.

Example The example shows how to add an ACE that denies packets with source IP address 192.168.1.80. You can verify settings by the following **show acl** command

```
Switch334455(config)# ip acl iptest
Switch334455(ip-al)# deny ip 192.168.1.80/255.255.255.255 any
```

```
Switch334455(ip-al)# show acl
```

IP access list iptest
sequence 1 deny ip 192.168.1.80/255.255.255.255 any

ipv6 acl

Syntax **ipv6 acl NAME**
no ipv6 acl NAME

Parameter	NAME	Specify the name of IPv6 ACL
Default	No default is defined	
Mode	Global Configuration	

Usage Use the **ipv6 acl** command to create an IPv6 access list and to enter ipv6-acl configuration mode. The name of ACL must be unique that can not have same name with other ACL or QoS policy. Once an ACL is created, an implicit “deny any” ACE created at the end of the ACL. That is, if there are no matches, the packets are denied. Use the no form of this command to delete.

Example The example shows how to create an IPv6 ACL. You can verify settings by the following **show acl** command

```
Switch334455(config)#ipv6 acl ipv6test
Switch334455(ipv6-acl)# show acl
IPv6 access list iptest
```

permit (IPv6)

Syntax **[sequence <1-2147483647>] permit (<0-255>|ipv6) (X:X::X:X/<0-128>|any) (X:X::X:X/<0-128>|any) [(dscp|precedence) VALUE]**

[sequence <1-2147483647>] permit icmp (X:X::X:X/<0-128>|any) (<0-255>|destination-unreachable|packet-too-big|time-exceeded|parameter-problem|echo-request|echo-reply| mld-query|mld-report|mldv2-report|mld-done| router-solicitation|router-advertisement|nd-ns|nd-na|any) (<0-255>|any)[(dscp|precedence) VALUE]

[sequence <1-2147483647>] permit tcp (X:X::X:X/<0-128>|any) (<0-65535>|echo|discard|daytime|ftp-

data|ftp|telnet|smtp| time|hostname|whois|tacacs- ds|domain|www|pop2|pop3|syslog| talk|klogin|kshell|sunrpc|drip|PORT_RANGE|any) (X:X::X:X/<0-128>|any) (<0-


```
65535>|echo|discard|daytime|ftp- data|ftp|
telnet|smtp|time|hostname|whois|tacacs-ds|domain|www|pop2|
pop3|syslog|talk|klogin|kshell|sunrpc|drip|PORT_RANGE|an
y) [match-all TCP_FLAG] [(dscp|precedence) VALUE]
```

```
[sequence <1-2147483647>] permit udp (X:X::X:X/<0- 128>|any)
(<0-65535>|echo|discard|time|nameserver|tacacs-ds|domain|
bootps|bootpc|tftp|sunrpc|ntp|netbios-
ns|snmp|snmptrap|who|syslog|
talk|rip|PORT_RANGE|any) (X:X::X:X/<0-128>|any) (<0- 65535>|echo|discard|time|nameserver|tacacs-
ds|domain| bootps|bootpc|tftp|sunrpc|ntp|netbios-ns| snmp|snmptrap|who|syslog|PORT_RANGE|any)
[(dscp|precedence) VALUE]
```

no sequence <1-2147483647>

Parameter		
	<1-2147483647>	(Optional) Specify sequence index of ACE, the sequence index represent the priority of an ACE in ACL.
	(X:X::X:X/<0-128> any)	Specify the source IPv6 address and prefix of packet or any IPv6 address.
	(X:X::X:X/<0-128> any)	Specify the destination IPv6 address and prefix of packet or any IPv6 address.
	[dscp VALUE]	(Optional) Specify the DSCP of packet.
	[precedence VLAUE]	(Optional) Specify the IP precedence of packet.
	icmp-type	Specify ICMP message type for filtering ICMP packet. Enter a type name of list or a number of ICMP message type.
	icmp-code	Specify ICMP message code for filtering ICMP packet.
	i4-source-port	Specify TCP/UDP source port of for filtering TCP/UDP packet. Enter a port name of list or a number of TCP/UDP port.
	i4-destination-port	Specify TCP/UDP destination port of for filtering TCP/UDP packet. Enter a port name of list or a number of TCP/UDP port.

match-all Specify tcp flag for TCP packet. If a flag should be set it is prefixed by "+" and "\". If a flag should be unset it is prefixed by "-" and "\". Available options are +urg, +ack, +psh, +rst, +syn, +fin, -urg, -ack, -psh, -rst, -syn and -fin. To define more than 1 flag - enter additional flags one after another without a space (example +syn-ack).

Default No default is defined.

Mode IPv6 ACL Configuration

Usage Use the permit command to add permit conditions for an IPv6 ACE that bypasses those packets hit the ACE. The “**sequence**” also represents hit priority when ACL bind to an interface. An ACE not specifies “**sequence**” index would assign a sequence index which is the largest existed index plus 20. If packet content can match more than one ACE, the lowest sequence ACE is hit. An ACE can not be added if has the same conditions as existed ACE.

Example The example shows how to add a set of ACEs. You can verify settings by the following **show acl** command.

This command shows how to permit a source IP address subnet.
 Switch334455(ipv6-al)# **permit permit ipv6 fe80:1122:3344:5566::1/64 any**

```
Switch334455(ipv6-al)# show acl
IPv6 access list ipv6test
sequence 1 permit ipv6 fe80:1122:3344:5566::1/64 any
```

deny (IPv6)

Syntax

```
[sequence <1-2147483647>] deny (<0-255>|ipv6) (X:X::X:X/<0-128>|any)
(X:X::X:X/<0-128>|any) [(dscp|precedence) VALUE] [shutdown]

[sequence <1-2147483647>] deny icmp (X:X::X:X/<0-128>|any) (X:X::X:X/<0-128>|any) (<0-255>|destination- unreachable|packet-too-big|
time-exceeded|parameter-problem|echo-request|echo-reply| mld-query|mld-report|mldv2-report|mld-done| router- solicitation|router-advertisement|nd-ns|nd-na|any) (<0- 255>|any)[(dscp|precedence) VALUE] [shutdown]

[sequence <1-2147483647>] deny tcp (X:X::X:X/<0-128>|any) (<0-65535>|echo|discard|daytime|ftp-data|ftp|telnet|smtp| time|hostname|whois|tacacs-ds|domain|www|pop2|pop3|syslog| talk|klogin|kshell|sunrpc|drip|PORT_RANGE|any) (X:X::X:X/<0-128>|any) (<0-65535>|echo|discard|daytime|ftp- data|ftp|telnet|smtp|time|hostname|whois|tacacs-ds|domain|www|pop2|pop3|syslog|talk|klogin|kshell|sunrpc|drip|PORT_RANGE|any) [match-all TCP_FLAG] [(dscp|precedence) VALUE] [shutdown]

[sequence <1-2147483647>] deny udp (X:X::X:X/<0-128>|any) (<0-65535>|echo|discard|time|nameserver|tacacs-ds|domain|bootps|bootpc|tftp|sunrpc|ntp|netbios- ns|snmp|snmptrap|who|syslog|talk|rip|PORT_RANGE|any) (X:X::X:X/<0-128>|any) (<0-65535>|echo|discard|time|nameserver|tacacs-ds|domain|bootps|bootpc|tftp|sunrpc|ntp|netbios-ns|snmp|snmptrap|who|syslog|PORT_RANGE|any) [(dscp|precedence) VALUE] [shutdown]

no sequence <1-2147483647>
```

Parameter	<1-2147483647>	(Optional) Specify sequence index of ACE, the sequence index represent the priority of an ACE in ACL.
	(A.B.C.D/A.B.C.D any)	Specify the source IPv4 address and mask of packet or any IPv4 address.
	(A.B.C.D/A.B.C.D any)	Specify the destination IPv4 address and mask of packet or any IPv4

	address.
[dscp VALUE]	(Optional) Specify the DSCP of packet.
[precedence VLAUE]	(Optional) Specify the IP precedence of packet.
icmp-type	Specify ICMP message type for filtering ICMP packet. Enter a type name of list or a number of ICMP message type.
icmp-code	Specify ICMP message code for filtering ICMP packet.
l4-source-port	Specify TCP/UDP source port of for filtering TCP/UDP packet. Enter a port name of list or a number of TCP/UDP port.
l4-destination-port	Specify TCP/UDP destination port of for filtering TCP/UDP packet. Enter a port name of list or a number of TCP/UDP port.
match-all	Specify tcp flag for TCP packet. If a flag should be set it is prefixed by "+" and if a flag should be unset it is prefixed by "-". Available options are +urg, +ack, +psh, +rst, +syn, +fin, -urg, -ack, -psh, -rst, -syn and -fin. To define more than 1 flag - enter additional flags one after another without a space (example +syn-ack).
[shutdown]	(Optional) Shutdown interface while <u>ACE hit</u>
Default	No default is defined.
Mode	IP ACL Configuration

Usage Use the deny command to add deny conditions for an IPv6 ACE that drop those packets hit the ACE. The “**sequence**” also represents hit priority when ACL bind to an interface. An ACE not specifies “**sequence**” index would assign a sequence index which is the largest existed index plus 20. If packet content can match more than one ACE, the lowest sequence ACE is hit. An ACE can not be added if has the same conditions as existed ACE. Use “**shutdown**” to shutdown interface while ACE hit.

Example The example shows how to add an ACE that denies packets with destination IP address fe80::abcd. You can verify settings by the following **show acl** command

```
Switch334455(config)# ipv6 acl ipv6test Switch334455(ip-al)# deny ipv6 any fe80::abcd/128 Switch334455(ip-al)# show acl
```

IPv6 access list ipv6test
sequence 1 deny ipv6 any fe80::abcd/128

bind acl

Syntax	(mac ip ipv6) acl NAME [no] (mac ip ipv6) acl NAME
Parameter	<u>(mac ip ipv6)</u> Specify a type of ACL to binding to interface <u>NAME</u> Specify the name of ACL
Default	No default is defined
Mode	Interface Configuration

Usage Use the **(mac|ip|ipv6) acl NAME** command to bind an ACL to interfaces. An interface can bind only one ACL or QoS policy. Use the **no** form of this command to return to unbind an ACL from interface.

Example	The example shows how to bind an existed ACL to interface. <pre>switch(config)# interface fa1 switch(config-if)# mac acl test switch(config-if)# do show running-config interfaces fa1 interface fa1 mac acl test</pre>
----------------	---

show acl

Syntax	show acl show (mac ip ipv6) acl show (mac ip ipv6) acl NAME
Parameter	<u>(mac ip ipv6)</u> Specify a type of ACL to show <u>NAME</u> Specify the name of ACL
Default	No default is defined
Mode	Global Configuration Context Configuration

Usage Use the **show acl** command to show created ACLs. You can specify mac ` ip or ipv6 to show specific type ACL or specify unique name string to show ACL with the name.

Example The example shows how to show all IP ACL. Switch334455(config)# **show ip acl**
IP access list iptest
sequence 1 deny ip 192.168.1.80/255.255.255.255 any

show acl utilization

Syntax show acl utilization

Parameter None

Default No default is defined

Mode Global Configuration

Usage Use the **show acl utilization** command to show the usage of PIE of ASIC. When an ACL bind to interface, it needs ASIC resource to help to filter packet. An ASIC has limited resource. This command help user to know the PIE usage of AISC.

Example The example shows how to show utilization

Switch(config-if)# do show acl utilization Type: sys usage: 128 Type: mac ACL
usage: 128
Type: IPv4 ACL usage: 128
Type: IPv6 ACL usage: 128

Administration

configure

Syntax **configure**

Parameter

Default No default value for this command.

Mode Privileged EXEC

Usage Use “**configure**” command to enter global configuration mode. In global configuration mode, the prompt will show as “**Switch(config)#**”.

Example This example shows how to enter global configuration mode.
 Switch# **configure**
 Switch(config)#

clear arp-cache

Syntax **clear arp** arp-cache

Usage Use “**clear arp** arp-cache” command to clear all or specific one arp entry.

Example This example shows how to clear all arp entries.
 Switch(config)# **clear arp**

enable

Syntax **enable** [<1-15>]
disable [<1-14>]

Parameter <1-15> Specify privileged level to enable
 <1-14> Specify privileged level to disable

Default Default privilege level is 15 if no privilege level is specified on enable command.
 Default privilege level is 1 if no privilege level is specified on disable command.

Mode User EXEC

Usage In User EXEC mode, user only allows to do a few actions. Most of commands are only available in privileged EXEC mode. Use “**enable**” command to enter the privileged mode to do more actions on switch.

In privileged EXEC mode, use “**exit**” command is able to go back to user EXEC mode with original user privilege level. If you need to go back to user EXEC mode with different privilege level, use “**disable**” command to specify the privilege level you need.

In privileged EXEC mode, the prompt will show “**Switch#**”

Example

This example shows how to enter privileged EXEC mode and show current privilege level.

```
Switch> enable
Switch# show privilege
Current CLI Username:
```

```
Current CLI Privilege: 15
```

end

This example show how to enter user EXEC mode with privilege 3.

```
Switch# disable 3 Switch> show privilege Current CLI Username:
Current CLI Privilege: 3
```

Syntax **end**

Parameter

Default No default value for this command.

Mode Privileged EXEC

Global Configuration Interface Configuration Line Configuration

.....

Usage Use “**end**” command to return to privileged EXEC mode directly. Every mode except User EXEC mode has the “end” command.

Example

This example shows how to enter Interface Configuration mode and use end command to go back to privileged EXEC mode

```
Switch# configure Switch(config)# interface fa1 Switch(config-
if)# end
Switch#
```

exit

Syntax **exit**

Parameter

Default No default value for this command.

Mode User EXEC
Privileged EXEC Global Configuration

Interface Configuration Line Configuration

.....

Usage In User EXEC mode, “**exit**” command will close current CLI session. In other modes, “**exit**” command will go to the parent mode. And every mode has the “**exit**” command.

Example This example shows how to enter privileged EXEC mode and use exit command to go back to user EXEC mode.

```
Switch> enable
Switch# exit
Switch>
```

Hostname

Syntax **hostname** *WORD*

Parameter *WORD* Specify the hostname of the switch.

Default Default name string is “Switch”.

Mode Global Configuration

Usage Use “**hostname**” command to modify hostname of the switch. The system name is also used to be CLI prompt.

Example

This example shows how to modify contact information `Switch(config)#
hostname myname myname(config)#`

interface

Syntax `interface IF_PORTS`
`interface range IF_PORTS`

Parameter	IF_PORTS	
		Specify the port to select. This parameter allows partial port name and ignore case. For Example: fa1 FastEthernet3 Gigabit4
		If port range is specified, the list format is also available. For Example: fa1,3,5 fa2,gi1-3

Default No default value for this command.

Mode Global Configuration

Usage Some configurations are port based. In order to configure these configurations, we need to enter Interface Configuration mode to configure them. Use “**interface**” command to enter the Interface Configuration mode and select the port to be configured.

In Interface Configuration mode, the prompt will show as “**Switch(config-if)#**”

Example This example shows how to enter Interface Configuration mode

```
Switch# configure
Switch(config)# interface fa1
Switch(config-if)#
```

ip service

Syntax `ip (telnet | ssh | http | https)`
`no ip (telnet | ssh | http | https)`

Parameter	telnet	Enable/Disable telnet service
	ssh	Enable/Disable ssh service
	http	Enable/Disable http service
	https	Enable/Disable https service

Default Default telnet service is disabled.

Default ssh service is disabled. Default http service is enabled. Default https service is disabled.

Mode Global Configuration

Usage Use “**ip service**” command to enable all kinds of ip services. Such as telnet, ssh, http and https. Use no form to disable service.

Example This example shows how to enable telnet service and show current telnet service status.

```
Switch(config)# ip telnet
Telnetd daemon enabled. Switch(config)# exit Switch# show line telnet
Telnet =====
Telnet Server : enabled Session Timeout : 10 (minutes) History Count :
128
Password Retry : 3
Silent Time : 0 (seconds)
```

This example shows how to enable https service and show current https service status.

```
Switch(config)# ip https
```

```
Switch(config)# exit
Switch# show ip https
HTTPS daemon : enabled
Session Timeout : 10 (minutes)
```

ip session-timeout

Syntax ip (http | https) session-timeout <0-86400>

Parameter http Specify session timeout for http service.

https Specify session timeout for https service.

<0-86400> Specify session timeout minutes. 0 means never timeout.

Default Default session timeout for http and https is 10 minutes.

Mode Global Configuration

Usage Use “**ip session-timeout**” command to specify the session timeout value for http or https service. When user login into WEBUI and do not do any action after session timeout will be logged out.

Example

This example shows how to change http session timeout to 15min and https session timeout to 20min

```
Switch(config)# ip http session-timeout 15
Switch(config)# ip https session-timeout 20
```

This example shows how to enable https service and show current https service status.

```
Switch# show ip http
HTTPS daemon : enabled Session Timeout : 15 (minutes)
Switch# show ip https
HTTPS daemon : disabled
Session Timeout : 20 (minutes)
```

ip ssh

Syntax

```
ip ssh (v1|v2|all)
no ip ssh (v1|v2|all)
```

Parameter

v1	Generate/Delete version 1 key files
v2	Generate/Delete version 2 key files
all	Generate/Delete version 1 and 2 key files

Default

Version 2 key files will be generated by default

Mode

Global Configuration

Usage Use “**ip ssh**” command to generate the key files for ssh connection.
 Use no form to delete key files. SSH connection may not connect if no any v1 or v2 ssh key files exist.

Example

This example shows how to delete and re-generate ssh version 2 key files.

```
Switch(config)# no ip ssh v2
Switch(config)# do show flash
```

```
File Name File Size Modified
-----
startup-config 1913 2000-01-01 08:29:10
rsa1 976 2000-01-05 23:28:38
ssl_cert 875 2000-01-05 23:03:20
image0 (active) 4856825 2014-04-02 15:17:34
```

```
Switch(config)# ip ssh v2
```

Generating a SSHv2 default RSA Key.

This may take a few minutes, depending on the key size.

Generating a SSHv2 default DSA Key.

This may take a few minutes, depending on the key size.

```
Switch(config)# do show flash
```

```
File Name File Size Modified
-----
startup-config 1913 2000-01-01 08:29:10
rsa1 976 2000-01-05 23:28:38
rsa2 1675 2000-01-05 23:34:43
dsa2 668 2000-01-05 23:34:58
ssl_cert 875 2000-01-05 23:03:20
image0 (active) 4856825 2014-04-02 15:17:34
```

line

Syntax **line (console | telnet | ssh)**

Parameter	console	Select console line to configure.
	telnet	Select telnet line to configure.
	ssh	Select ssh line to configure.

Default No default value for this command.

Mode Global Configuration

Usage Some configurations are line based. In order to configure these configurations, we need to enter Line Configuration mode to configure them. Use “**line**” command to enter the Line Configuration mode and select the line to be configured.

In Line Configuration mode, the prompt will show as “**Switch(config-line)#**”

Example

This example shows how to enter Interface Configuration mode

```
Switch# configure
Switch(config)# line console
Switch(config-line)#
```

reboot

Syntax `reboot`

Parameter

Default No default value for this command.

Mode Privileged EXEC

Usage Use “**reboot**” command to make system hot restart.

Example This example shows how to restart the system
Switch# **reboot**

exec-timeout

Syntax `exec-timeout <0-65535>`

Parameter `<0-65535>` Specify session timeout minutes. 0 means never
timeout

Default Default session timeout for all lines are 10 minutes.

Mode Line Configuration

Usage Use “**exec-timeout**” command to specify the session timeout value for CLI running on console, telnet or ssh service. When user login into CLI and do not do any action after session timeout will be logged out from the CLI session.

Example This example shows how to change console session timeout to 15min ,telnet session timeout to 20min and ssh session timeout to 25min.
Switch(config)# **line console**

```
Switch(config-line)# exec-timeout 15 Switch(config-line)# exit Switch(config)# line telnet
Switch(config-line)# exec-timeout 20 Switch(config-line)# exit Switch(config)# line ssh
Switch(config-line)# exec-timeout 25 Switch(config-line)# exit
```

This example shows how show line information.

```
Switch# show line
Console =====
Session Timeout : 15 (minutes) History Count : 128
Password Retry : 3
Silent Time : 0 (seconds) Telnet =====
Telnet Server : disabled Session Timeout : 20 (minutes) History Count : 128
Password Retry : 3
Silent Time : 0 (seconds)
SSH =====
SSH Server : disabled Session Timeout : 25 (minutes) History Count : 128
Password Retry : 3
Silent Time : 0 (seconds)
```

password-thresh

Syntax `password-thresh <0-120>`

Parameter `<0-120>` Specify password fail retry number. 0 means no limit.

Default Default password fail retry number is 3.

Mode Line Configuration

Usage Use “**password-thresh**” command to specify the password fail retry number for CLI running on console, telnet or ssh service. When user input password to login and authenticate failed, the fail retry number will increase one. After fail retry number exceed configured one, the CLI will block login for the period of silent time which configured by the command “**silent-time**”.

Example This example shows how to change console fail retry number to 4, telnet fail retry number to 5 and ssh fail retry number to 6.

```
Switch(config)# line console Switch(config-line)# password-thresh 4
Switch(config-line)# exit
Switch(config)# line telnet
```

Ping

```
Switch(config-line)# password-thresh 5 Switch(config-line)# exit Switch(config)# line ssh
Switch(config-line)# password-thresh 6 Switch(config-line)# exit
```

This example shows how show line information.

```
Switch# show line
Console =====
Session Timeout : 10 (minutes) History Count : 128
Password Retry : 4
Silent Time : 0 (seconds) Telnet =====
Telnet Server : disabled Session Timeout : 10 (minutes) History Count : 128
Password Retry : 5
Silent Time : 0 (seconds)
SSH =====
SSH Server : disabled Session Timeout : 10 (minutes) History Count : 128
Password Retry : 6
Silent Time : 0 (seconds)
```

Syntax ping *HOSTNAME* [count <1-999999999>]

Parameter *HOSTNAME* Specify IPv4/IPv6 address or domain name to ping.

count <1- Specify how many times to ping.
999999999>

Default No default value for this command.

Mode User EXEC
Privileged EXEC

Usage Use “ping” command to do network ping diagnostic.

Example This example shows how to ping remote host 192.168.1.111.

```
Switch# ping 192.168.1.111
PING 192.168.1.111 (192.168.1.111): 56 data bytes
64 bytes from 192.168.1.111: icmp_seq=0 ttl=128 time=10.0 ms
64 bytes from 192.168.1.111: icmp_seq=1 ttl=128 time=0.0 ms
64 bytes from 192.168.1.111: icmp_seq=2 ttl=128 time=0.0 ms
64 bytes from 192.168.1.111: icmp_seq=3 ttl=128 time=0.0 ms

--- 192.168.1.111 ping statistics ---
4 packets transmitted, 4 packets received, 0% packet loss
round-trip min/avg/max = 0.0/2.5/10.0 ms
```


traceroute

Syntax `traceroute A.B.C.D [max_hop <2-255>]`

Parameter *A.B.C.D* Specify IPv4 to trace.

max_hop <2-255> Specify maximum hop to trace.

Default No default value for this command.

Mode User EXEC
Privileged EXEC

Usage Use “**traceroute**” command to do network trace route diagnostic.

Example This example shows how to trace route host 192.168.1.111.

```
Switch# traceroute 192.168.1.111
traceroute to 192.168.1.111 (192.168.1.111), 30 hops max, 40 byte
packets
 1 192.168.1.111 (192.168.1.111) 0 ms 10 ms 0 ms
```

show arp

Syntax `show arp`

Parameter

Default No default value for this command.

Mode User EXEC
Privileged EXEC

Usage Use “**show arp**” command to show all arp entries.

Example This example shows how to show arp entries.

```
Switch# show arp
Address HWtype HWaddress Flags Mask Iface
192.168.1.111 ether 00:0E:2E:F1:4B:3C C eth0
```

show cpu utilization

Syntax **show cpu utilization**

Parameter

Default No default value for this command.

Mode Privileged EXEC

Usage Use “**show cpu utilization**” command to show current CPU utilization.

Example

This example shows how to show current CPU utilization.
 Switch# **show cpu utilization**
 CPU utilization

 Current: 30%

show history

Syntax **show history**

Parameter

Default No default value for this command.

Mode User EXEC Privileged EXEC Global Configuration

Usage Use “**show history**” to show commands we input before.

Example

This example shows how show history commands.
 Switch# **show history**
 Maximun History Count: 100

 enable
 configure
 3. line console

show info

```

exit
show history
line
exit
show history
configure
line
line console
exit
line console
history 100
exit
show history
exit
18. show history

```

Syntax **show info**

Parameter

Default No default value for this command.

Mode User EXEC
Privileged EXEC

Usage Use “**show info**” command to show system summary information.

Example

This example shows how to show system version.

```

Switch# show info
System Name : Switch
System Location : Default Location System Contact : Default Contact
MAC Address : DE:AD:BE:EF:01:02 IP Address : 192.168.1.1
Subnet Mask : 255.255.255.0 Loader Version : 1.3.0.26225
Loader Date : Thu May 17 15:19:42 CST 2012 Firmware Version :
2.5.0-beta.32811
Firmware Date : Mon Sep 24 19:33:42 CST 2012 System Object ID :
1.3.6.1.4.1.27282.3.2.10
System Up Time : 0 days, 1 hours, 49 mins, 29 secs

```

show ip

Syntax **show ip**

Parameter

Default No default value for this command.

Mode User EXEC
Privileged EXEC

Usage Use “**show ip**” command to show system IPv4 address, net mask and default gateway.

Example This example shows how to show current ipv4 address of the switch.

```
Switch# show ip
IP Address: 192.168.1.200
Subnet Netmask: 255.255.255.0
Default Gateway: 192.168.1.254
```

show ip http

Syntax **show ip (http|https)**

Parameter

Default No default value for this command.

Mode Privileged EXEC

Usage Use “**show ip http**” command to show HTTP/HTTPS information.

Example This example shows how to show current ipv4 address of the switch.

```
Switch# show ip http
HTTP daemon : enabled
Session Timeout : 10 (minutes)

Switch# show ip https
HTTPS daemon : enabled
Session Timeout : 10 (minutes)
```

show line

Syntax `show line [(console | telnet | ssh)]`

Parameter	console	Select console line to show.
	telnet	Select telnet line to show.
	ssh	Select ssh line to show.

Default No default value for this command.

Mode Privileged EXEC

Usage Use “**show line**” command to show all line configurations including session timeout, history count, password retry number and silent time. For telnet and ssh, it also shows the service enable/disable state.

Example

This example shows how show all lines’ information.

```
Switch# show line
Console =====
Session Timeout : 15 (minutes) History Count : 128
Password Retry : 3
Silent Time : 0 (seconds) Telnet =====
Telnet Server : disabled Session Timeout : 20 (minutes) History
Count : 128
Password Retry : 3
Silent Time : 0 (seconds)
SSH =====
SSH Server : disabled Session Timeout : 25 (minutes) History
Count : 128
Password Retry : 3
Silent Time : 0 (seconds)
```

show memory statistics

Syntax `show memory statistics`

Parameter

Default No default value for this command.

Mode Privileged EXEC

Usage Use “**show memory statistics**” command to show current memory utilization.

Example This example show how to show current system memory statistics.

```
Switch# show memory statistics
total(KB) used(KB) free(KB) shared(KB) buffer(KB) cache(KB)
-----+-----+-----+-----+-----+-----
Mem: 62408 56424 5984 0 1320 19328
-/+ buffers/cache: 35776 26632
Swap: 0 0
```

show privilege

Syntax show privilege

Parameter

Default No default value for this command.

Mode User EXEC
Privileged EXEC

Usage Use “**show privilege**” command to show the privilege level of the current user.

Example This example shows how to show arp entries.

```
Switch# show privilege
Current CLI Username: admin
Current CLI Privilege: 15
```

show username

Syntax show username

Parameter

Default No default value for this command

Mode Privileged EXEC

Usage Use “**show username**” command show all user accounts in local database.

Example This example shows how to show existing user accounts.

```
Switch# show username
Priv | Type | User Name | Password
-----+-----+-----+-----
01 | secret | | dnXencJRwflV6
15 | secret | admin | FzjrGO6vfbERY
15 | secret | test | 7p57T9yMkViSUS
```

show users

Syntax **show users**

Parameter

Default No default value for this command

Mode Privileged EXEC

Usage Use “**show users**” command show information of all active users.

Example This example shows how to show existing user accounts.

```
Switch# show users
Username Protocol Location
-----+-----+-----
admin console 0.0.0.0
admin telnet 192.168.1.111
admin ssh 192.168.1.111
```

show version

Syntax **show version**

Parameter

Default No default value for this command.

Mode User EXEC
Privileged EXEC

Usage Use “**show version**” command to show loader and firmware version and build date.

Example This example shows how to show system version.

```
Switch# show version
Loader Version : 1.3.0.26225
Loader Date : Thu May 17 15:19:42 CST 2012 Firmware Version :
2.5.0-beta.32811
Firmware Date : Mon Sep 24 19:33:42 CST 2012
```

system name

Syntax `system name NAME`

Parameter `NAME` Specify system name string.

Default Default name string is “Switch”.

Mode Global Configuration

Usage Use “**system name**” command to modify system name information of the switch. The system name is also used to be CLI prompt.

Example This example shows how to modify contact information

```
Switch(config)#
system name myname myname(config)#
```

This example shows how to show system name information

```
Switch# show info
System Name : myname
System Location : Default Location System Contact : Default Contact
MAC Address : DE:AD:BE:EF:01:02 IP Address : 192.168.1.1
Subnet Mask : 255.255.255.0 Loader Version : 1.3.0.26225
Loader Date : Thu May 17 15:19:42 CST 2012 Firmware Version :
2.5.0-beta.32811
Firmware Date : Mon Sep 24 19:33:42 CST 2012 System Object ID :
1.3.6.1.4.1.27282.3.2.10
System Up Time : 0 days, 0 hours, 2 mins, 37 secs
```


system contact

Syntax `system contact CONTACT`

Parameter `CONTACT` Specify contact string.

Default Default contact string is “Default Contact”.

Mode Global Configuration

Usage Use “**system contact**” command to modify contact information of the switch.

Example This example shows how to modify contact information
 Switch(config)# **system contact callme**

This example shows how to show system contact information

Switch# **show info**

System Name : Switch

System Location : Default Location System Contact : callme

MAC Address : DE:AD:BE:EF:01:02 IP Address : 192.168.1.1

Subnet Mask : 255.255.255.0 Loader Version : 1.3.0.26225

Loader Date : Thu May 17 15:19:42 CST 2012 Firmware Version :
 2.5.0-beta.32811

Firmware Date : Mon Sep 24 19:33:42 CST 2012 System Object ID :
 1.3.6.1.4.1.27282.3.2.10

System Up Time : 0 days, 0 hours, 2 mins, 37 secs

system location

Syntax `system location LOCATION`

Parameter `CONTACT` Specify location string.

Default Default location string is “Default Location”.

Mode Global Configuration

Usage Use “**system location**” command to modify location information of the switch.

Example

This example shows how to modify contact information
 Switch(config)# **system location home**

This example shows how to show system location information

```
Switch# show info
System Name : SwitchEF0102 System Location : home
System Contact : Default Contact MAC Address : DE:AD:BE:EF:01:02
IP Address : 192.168.1.1
Subnet Mask : 255.255.255.0 Loader Version : 1.3.0.26225
Loader Date : Thu May 17 15:19:42 CST 2012 Firmware Version :
2.5.0-beta.32811
Firmware Date : Mon Sep 24 19:33:42 CST 2012 System Object ID :
1.3.6.1.4.1.27282.3.2.10
System Up Time : 0 days, 0 hours, 2 mins, 37 secs
```

terminal length

Syntax

terminal length <0-24>

Parameter

<0-24> Specify terminal length value. 0 means no limit.

Default

Default terminal length is 24.

Mode

User EXEC
 Privileged EXEC

Usage

Use “**terminal length**” command to specify the maximum line number the terminal is able to print.

Example

```
This example shows how to change terminal length.
Switch# terminal length 3 Switch# show running-config SYSTEM
CONFIG FILE ::= BEGIN
! System Description: RTK RTL8380-24FE-4GEC Switch
! System Version: v3.0.4.46766
--More--
```

username

Syntax

username WORD<0-32> [**privilege** (admin|user|<0-15>)] (**nopassword** | **password** UNENCRYPTY-PASSWORD | **secret** UNENCRYPTY-PASSWORD | **secret encrypted** ENCRYPT-PASSWORD)

no username WORD<0-32>

Parameter	username	Specify user name to add/delete/edit. <i>WORD</i> <0-32>
	privilege admin	Specify privilege level to be admin (privilege 15)
	privilege user	Specify privilege level to be user (privilege 1)
	privilege <0-15>	Specify custom privilege level
	password	Specify password string and make it not encrypted. <i>UNENCRYPY-PASSWORD</i>
	secret	Specify password string and make it encrypted. <i>UNENCRYPY-PASSWORD</i>
	secret encrypted	Enter an encrypted password. Use this keyword to enter a password that is already encrypted (for instance, a password that you copied from another the

configuration file of another device).

Default Default username “admin” has password “admin” with privilege 15.

Mode Global Configuration

Usage Use “**username**” command to add a new user account or edit an existing user account. And use “**no username**” to delete an existing user account. The user account is a local database for login authentication.

Example This example shows how to add a new user account.
Switch(config)# **username test secret passwd**

This example shows how to show existing user accounts.

```
Switch# show username
Priv | Type | User Name | Password
-----+-----+-----+-----
01 | secret | | dnXencJRwflV6
15 | secret | admin | FzjrGO6vfbERY
15 | secret | test | 7p57T9yMkViSUS
```

Authentication Manager

authentication

Syntax **authentication (dot1x|mac|web)**
no authentication (dot1x|mac|web)

Parameter

Default Default is disabled for all type

Mode Global Configuration

Usage Use “**authentication**” command to enable the global setting of 802.1x/MAC/WEB authentication network access control.
Use the **no** form of this command to disable 802.1x/MAC/WEB authentication.

Example The following example shows how to enable 802.1x/MAC/WEB authentication.

```
Switch(config)# authentication dot1x
```

```
Switch(config)# authentication mac Switch(config)# authentication web Switch# show authentication
Authentication dot1x state : enabled Authentication mac state : enabled
Authentication web state : enabled
Guest VLAN : enabled (3) Mac-auth Radius User ID Format: XXXXXXXXXXXXX
```

authentication (Interface)

Syntax **authentication (dot1x|mac|web)**
no authentication (dot1x|mac|web)

Parameter

Default Default is disabled for all type

Mode Interface Configuration

Usage Use “**authentication**” interface command to enable the port setting of 802.1x/MAC/WEB authentication network access control.
Use the **no** form of this command to disable 802.1x/MAC/WEB authentication.

Example

The following example shows how to enable 802.1x/MAC/WEB authentication.

```
Switch(config)# interface fa1 Switch(config-if)# authentication
dot1x Switch(config-if)# authentication mac Switch(config-if)#
authentication web Switch# show authentication interface fa1
Interface FastEthernet1
Admin Control : disable
Host Mode : multi-auth
Type dot1x State : enabled
Type mac State : enabled
Type web State : enabled
.....
```

authentication mac radius

Syntax authentication mac radius [mac-case (lower|upper)] [mac-delimiter

(colon|dot|hyphen|none) [gap (2|4|6)]]

Parameter	mac-case (lower upper)	Select radius user id to be upper case or lower case.
	mac-delimiter (colon dot hyphen none)	Select radius user id delimiter colon: XX:XX:XX:XX:XX:XX dot: XX.XX.XX.XX.XX.XX hyphen: XX-XX-XX-XX-XX none: XXXXXXXXXXXXX
	gap (2 4 6)	Select delimiter gap 2: XX-XX-XX-XX-XX-XX 4: XXXX-XXXX-XXXX 6: XXXXXX-XXXXXX

Default Default radius id format is upper case with none delimiter.

Mode Global Configuration

Usage Use “**authentication mac radius**” command to configure the radius user id format used by MAC authentication Radius method.

Example

The following example shows how to configure MAC authentication radius id format to be upper case with colon delimiter every 2 chars

```
Switch(config)# authentication mac radius mac-case upper
Switch(config)# authentication mac radius mac-delimiter colon gap
2
Switch# show authentication
Authentication dot1x state : enabled
Authentication mac state : disabled
Authentication web state : disabled
Guest VLAN : disabled
Mac-auth Radius User ID Format: XX:XX:XX:XX:XX:XX
.....
```

authentication mac local

Syntax

```
authentication mac local mac-addr control auth [vlan <1-4094>] [reauth-period <300-4294967294>] [inactive-timeout <60-65535>]
authentication mac local mac-addr control unauth no authentication mac local
mac-addr
```

Parameter

<i>mac-addr</i>	MAC Authentication local MAC address
control auth	Host with this MAC address will be

control unauth	Host with this MAC address will be force-unauthorized
vlan <1-4094>	MAC Authentication host assigned VLAN
reauth-period <300-4294967294>	MAC Authentication host reauthentication period
inactive-timeout <60-65535>	MAC authentication host inactive timeout

Default

Default is no local MAC Authentication entry.

Mode

Global Configuration

Usage Use “**authentication mac local**” command to add local MAC authentication hosts in database. This local host database is used when MAC authentication method is configured as “local”. The MAC authentication module will find host in this local database and authenticated it. Use the **no** form of this command to delete local host from database.

Example

The following example shows how to add a new local mac authentication host.

```
Switch(config)# authentication mac local 00:11:22:33:00:01 control
auth vlan 3 reauth-period 500 inactive-timeout 300 Switch# show
authentication
.....

Mac-auth Local Entry :
Reauth Inactive MAC Address Control VLAN Period Timeout
-----
00:11:22:33:00:01 Authorized 3 500 300
.....
```

authentication guest-vlan

Syntax `authentication guest-vlan <1-4094>`
`no authentication guest-vlan`

Parameter `<1-4094>` Guest VLAN ID

Default Default guest VLAN is disabled

Mode Global Configuration

Usage Use “**authentication guest-vlan**” command to enable the global setting of guest VLAN and specify guest VLAN ID.
 Use the **no** form of this command to disable guest VLAN.

Example

The following example shows how to create guest VLAN.

```
Switch(config)# vlan 3
Switch(config-vlan)# exit
Switch(config)# authentication guest-vlan 3 Switch# show
authentication
Authentication dot1x state : enabled Authentication mac state :
disabled Authentication web state : disabled Guest VLAN : enabled
(3) Mac-auth Radius User ID Format: XXXXXXXXXXXXX
.....
```

authentication guest-vlan (Interface)

Syntax authentication guest-vlan
no authentication guest-vlan

Parameter

Default Default guest VLAN is disabled

Mode Interface Configuration

Usage Use “**authentication guest-vlan**” command to enable the port setting of guest VLAN.

Use the **no** form of this command to disable guest VLAN.

Example The following example shows how to enable guest VLAN.
Switch(config)# **interface fa1**
Switch(config-if)# **authentication guest-vlan**

authentication host-mode

Syntax authentication host-mode (multi-auth|multi-host|single-host)
no authentication host-mode

Parameter	multi-auth	Multiple Authentication Mode. In this mode, every client need to pass authenticate procedure individually.
multi-host	Multiple Host Mode. In this mode, only one client need to be authenticated and other clients will get the same access accessibility.	
single-host	Single Host Mode. In this mode, only one host is allowed to be authenticated. It is the same as multi-auth mode with max hosts number configure to be 1.	
Default	Default is multi-auth mode.	
Mode	Interface Configuration	

Usage Use “**authentication host-mode**” command to configure the port authentication host mode.

Use the **no** form of this command to restore default value.

Example The following example shows how to modify port host mode to multi-host.

```
Switch(config)# interface fa1
Switch(config-if)# authentication host-mode multi-host
Switch# show authentication interface fa1
Interface FastEthernet1
Admin Control : auto
Host Mode : multi-host
Type dot1x State : disabled
Type mac State : disabled
Type web State : disabled
.....
```

authentication max-hosts

Syntax **authentication max-hosts** <1-256>

no authentication max-hosts

Parameter	<1-256>	Available max host number in multi-auth mode.
------------------	---------	---

Default	Default max host number is 256
----------------	--------------------------------

Mode	Interface Configuration
-------------	-------------------------

Usage Use “**authentication max-hosts**” command to configure the port max hosts number for multi-auth mode. The host exceed the max host number is not allowed to create authentication session and do authenticating.

Use **no** form of this command to restore default value.

Example The following example shows how to change port max hosts number.

```
Switch(config)# interface fa1
Switch(config-if)# authentication max-hosts 100
Switch# show mac-auth interface fa1
Interface FastEthernet1
Admin Control : disable
Host Mode : multi-auth
Type dot1x State : disabled
Type mac State : disabled
Type web State : disabled
Type Order : dot1x MAC/WEB Method Order : radius Guest VLAN :
disabled
Reauthentication : disabled
Max Hosts : 100
.....
```

authentication method

Syntax	authentication method (local [radius] radius [local]) no authentication order				
Parameter	<table border="1"> <tr> <td>local</td> <td>Use local account to authenticate</td> </tr> <tr> <td>radius</td> <td>Use remote RADIUS server to authenticate</td> </tr> </table>	local	Use local account to authenticate	radius	Use remote RADIUS server to authenticate
local	Use local account to authenticate				
radius	Use remote RADIUS server to authenticate				
Default	Default is RADIUS method in first place and no other method.				
Mode	Interface Configuration				

Usage Use “**authentication method**” command to configure the port authentication method order. Use the **no** form of this command to restore default value.

Example The following example shows how to modify port authentication order to local and then RADIUS.

```
Switch(config)# interface fa1
Switch(config-if)# authentication method local radius
Switch# show authentication interface fa1
Interface FastEthernet1
Admin Control : auto
Host Mode : multi-host
Type dot1x State : disabled
Type mac State : disabled
Type web State : disabled
```

```
Type Order : dot1x mac web MAC/WEB Method Order : local radius
.....
```

authentication order

Syntax	authentication order (dot1x [mac] [web] mac [dot1x] [web] web) no authentication order						
Parameter	<table border="1"> <tr> <td>dot1x</td> <td>Authenticating user by IEEE 802.1X</td> </tr> <tr> <td>mac</td> <td>Authenticating user by mac based authentication</td> </tr> <tr> <td>web</td> <td>Authenticating user by web based authentication</td> </tr> </table>	dot1x	Authenticating user by IEEE 802.1X	mac	Authenticating user by mac based authentication	web	Authenticating user by web based authentication
dot1x	Authenticating user by IEEE 802.1X						
mac	Authenticating user by mac based authentication						
web	Authenticating user by web based authentication						
Default	Default is dot1x type in first place and no other types.						
Mode	Interface Configuration						

Usage Use “**authentication order**” command to configure the port authentication type order.
Use the **no** form of this command to restore default value.

Example The following example shows how to modify port authentication order to dot1x, mac and web.

```
Switch(config)# interface fa1
Switch(config-if)# authentication order dot1x mac web
Switch# show authentication interface fa1
Interface FastEthernet1
Admin Control : auto
Host Mode : multi-host
Type dot1x State : disabled
Type mac State : disabled
Type web State : disabled
Type Order : dot1x mac web
.....
```

authentication port-control

Syntax **authentication port-control (auto|force-auth|force-unauth)**
no authentication port-control

Parameter	auto	Need passing authentication procedure to get network accessibility
	force-auth	Port is force authorized and all clients have network accessibility.
	force-unauth	Port is force unauthorized and all clients

have no network accessibility.

Default Default is disabled.

Mode Interface Configuration

Usage Use “**authentication port-control**” command to enable the port authentication control mode.
Use the **no** form of this command to disable authentication port control.

Example The following example shows how to configure port control to auto mode.

```
Switch(config)# interface fa1
Switch(config-if)# authentication port-control auto
Switch# show authentication interface fa1
Interface FastEthernet1
Admin Control : auto
Host Mode : multi-auth
Type dot1x State : disabled
Type mac State : disabled
Type web State : disabled
.....
```

authentication radius-attributes vlan

Syntax	authentication radius-attributes vlan (reject static) no authentication radius-attributes vlan				
Parameter	<table border="1"> <tr> <td>reject</td> <td>If get VLAN authorized information, just use it. However, if there is no VLAN authorized information, reject the host and make it unauthorized.</td> </tr> <tr> <td>static</td> <td>If get VLAN authorized information, just use it. If there is no VLAN authorized information, keep original VLAN of host.</td> </tr> </table>	reject	If get VLAN authorized information, just use it. However, if there is no VLAN authorized information, reject the host and make it unauthorized.	static	If get VLAN authorized information, just use it. If there is no VLAN authorized information, keep original VLAN of host.
reject	If get VLAN authorized information, just use it. However, if there is no VLAN authorized information, reject the host and make it unauthorized.				
static	If get VLAN authorized information, just use it. If there is no VLAN authorized information, keep original VLAN of host.				
Default	Default radius attributes VLAN assign mode is static.				
Mode	Interface Configuration				
Usage	Use “ authentication radius-attributes vlan ” command to configure the port RADIUS VLAN assign mode. Use the no form of this command to disable the port RADIUS VLAN assign.				
Example	<p>The following example shows how to configure port VLAN assign to reject mode.</p> <pre>Switch(config)# interface fa1 Switch(config-if)# authentication radius-attributes vlan reject Switch# show authentication interface fa1 Interface FastEthernet1 Admin Control : disable Host Mode : multi-auth Type dot1x State : disabled Type mac State : disabled Type web State : disabled Type Order : dot1x MAC/WEB Method Order : radius Guest VLAN : disabled Reauthentication : disabled Max Hosts : 256 VLAN Assign Mode : reject</pre>				

authentication reauth

Syntax	authentication reauth no authentication reauth
Parameter	
Default	Default is disabled.

Mode Interface Configuration

Usage Use “**authentication reauth**” command to enable the port reauthentication.
Use the **no** form of this command to disable reauthentication.

Example

```
The following example shows how to enable port reauthentication.
Switch(config)# interface fa1 Switch(config-if)# authentication
reauth Switch# show authentication interface fa1 Interface
FastEthernet1
Admin Control : disable
Host Mode : multi-auth
Type dot1x State : disabled
Type mac State : disabled
Type web State : disabled
Type Order : dot1x MAC/WEB Method Order : radius Guest VLAN :
disabled
Reauthentication : enabled
.....
```

authentication timer inactive

Syntax **authentication timer inactive** <60-65535>
no authentication timer inactive

Parameter <60-65535> Interval in seconds after which if there is no activity from the client then it will be unauthorized

Default Default inactive timeout is 60 seconds.

Mode Interface Configuration

Usage Use “**authentication timer inactive**” command to configure the port inactive timeout value. Sometimes, we may assign a long aging time for a host, but in fact, it is not active. This inactive timeout will detect the host is active or not. If the host is inactive exceed this timeout, it should be removed. Use **no** form of this command to restore default value.

Example

The following example shows how to configure port inactive period.

```
Switch(config)# interface fa1
Switch(config-if)# authentication timer inactive 300
Switch# show authentication interface fa1
Interface FastEthernet1
.....
Common Timers
Reauthenticate Period: 300 Inactive Timeout : 300 Quiet Period : 60
802.1x Parameters
EAP Max Request : 2
EAP TX Period : 30 Supplicant Timeout : 30 Server Timeout : 30
Web-auth Parameters
Login Attempt : 3
```

authentication timer quiet

Syntax `authentication timer quiet <0-65535>`
no authentication timer quiet

Parameter	<code><0-65535></code>	Interval in seconds to wait following a failed <u>authentication exchange</u>
------------------	------------------------------	---

Default	Default quiet period is 60 seconds.
----------------	-------------------------------------

Mode	Interface Configuration
-------------	-------------------------

Usage Use “**authentication timer quiet**” command to configure the port quiet period value.

After authenticating fail many times and the port is guest VLAN disabled, the port/host will enter lock state until quiet period expired. In lock state, the port/host is not allowed to do authenticating.

Use **no** form of this command to restore default value.

Example

The following example shows how to configure port quiet period.

```
Switch(config)# interface fa1
Switch(config-if)# authentication timer quiet 300
Switch# show authentication interface fa1
Interface FastEthernet1
.....
Common Timers
Reauthenticate Period: 300 Inactive Timeout : 300 Quiet Period : 300
802.1x Parameters
EAP Max Request : 2
EAP TX Period : 30 Supplicant Timeout : 30 Server Timeout : 30
Web-auth Parameters
Login Attempt : 3
```

authentication timer reauth

Syntax `authentication timer reauth <300-4294967294>`
`no authentication timer reauth`

Parameter	<code><300-4294967294></code>	Time in seconds after which an automatic re-authentication should be initiated
------------------	-------------------------------------	--

Default Default reauthentication period is 3600 seconds.

Mode Interface Configuration

Usage Use “**authentication timer reauth**” command to configure the port reauthentication period value with unit second if the reauthentication time is not assigned by local database or remote authentication server. On the other

hand, if the reauthentication time is assigned by local database or remote server, this configured reauthentication time will be ignored.

Use **no** form of this command to restore default value.

Example The following example shows how to configure port reauthentication period.

```
Switch(config)# interface fa1
Switch(config-if)# authentication timer reauth 300
Switch# show authentication interface fa1
Interface FastEthernet1
.....
Common Timers
Reauthenticate Period: 300 Inactive Timeout : 60
Quiet Period : 60 802.1x Parameters
EAP Max Request : 2
EAP TX Period : 30 Supplicant Timeout : 30 Server Timeout : 30
Web-auth Parameters
Login Attempt : 3
```

authentication web local

Syntax `authentication web local username USERNAME password (encrypted CRYPT-PASSWORD | PASSWORD) [vlan <1-4094>] [reauth-period <300-4294967294>] [inactive-timeout <60-65535>]`
`no authentication web local username USERNAME`

Parameter	<i>USERNAME</i>	Local account user name
------------------	-----------------	-------------------------

encrypted <i>CRYPT-PASSWORD</i>	Encrypted password.
<i>PASSWORD</i>	Un-encrypted password.
vlan <1-4094>	Assigned VLAN of this local account
reauth-period <300-4294967294>	Reauthentication period of this local account
inactive-timeout <60-65535>	Inactive timeout of this local account

Default Default is no local authentication entry.

Mode Global Configuration

Usage Use “**authentication web local**” command to add local account in database. This local account database is used when web authentication method is configured as “local”. The web authentication module will find account in this local database and authenticated it.

Use the **no** form of this command to delete local account from database.

Example

```
The following example shows how to add/delete a new local account.
Switch(config)# authentication web local username acct1 password
acct1 vlan 3 reauth-period 301 inactive-timeout 61 Switch# show
authentication
.....
Web-auth Local Entry :
Reauth Inactive
User Name VLAN Period Timeout
-----
acct1 3 301 61
.....
```

authentication web max-login-attempts

Syntax authentication web max-login-attempts (infinite|<3-10>)
no authentication web max-login-attempts

Parameter	infinite	Do not care user login fail number
	<3-10>	Allow user login fail number

Default Default max login attempt number is 3.

Mode Interface Configuration

Usage Use “**authentication web max-login-attempts**” command to configure the port WEB authentication max login attempt number. After login fail number exceed, the host will enter Lock state and is not able to authenticate until quiet period exceed.

Use **no** form of this command to restore default value.

Example

The following example shows how to configure port max login attempt number.

```
Switch(config)# interface fa1
Switch(config-if)# authentication web max-login-attempts 5
Switch# show authentication interface fa1
Interface FastEthernet1
.....
Common Timers
Reauthenticate Period: 300 Inactive Timeout : 300 Quiet Period : 300
802.1x Parameters
EAP Max Request : 1
EAP TX Period : 10 Supplicant Timeout : 120 Server Timeout : 150
Web-auth Parameters
```

Login Attempt : 5

clear authentication sessions

Syntax

```
clear authentication sessions
clear authentication sessions interfaces IF_PORTS
clear authentication sessions mac mac-addr
clear authentication sessions session-id WORD
clear authentication sessions type (dot1x|mac|web)
```

Parameter

interfaces	Clear sessions on specific interface
IF_PORTS	
mac mac-addr	Clear session with specific MAC address
session-id WORD	Clear session with specific session ID
type	Clear session with specific authentication
(dot1x mac web)	type

Default

Default is no local authentication entry.

Mode

Privileged EXEC

Usage Use “**clear authentication sessions**” command to delete existing authentication sessions. If no parameter is specified, all sessions will be deleted.

After authentication session is deleted, host need to do authentication procedure again.

Example The following example shows how to clear all authentication sessions.

```
Switch# clear authentication sessions
Switch# show authentication sessions
No Auth Manager sessions currently exist
```

dot1x

Syntax `dot1x`
`no dot1x`

Parameter

Default Default 802.1x is disabled

Mode Global Configuration

Usage Use “**dot1x**” command to enable the global setting of 802.1x. The “**authentication dot1x**” command has the same effect as this one. This command is a backward compatible command.

Use the **no** form of this command to disable 802.1x authentication.

Example The following example shows how to enable 802.1x authentication.

```
Switch(config)# dot1x
Switch# show authentication Authentication dot1x state : enabled
Authentication mac state : disabled Authentication web state :
disabled
Guest VLAN : enabled (3) Mac-auth Radius User ID Format:
XXXXXXXXXXXXX
.....
```

dot1x guest-vlan

Syntax `dot1x guest-vlan <1-4094>`
`no dot1x guest-vlan`

Parameter `<1-4094>` Guest VLAN ID

Default Default guest VLAN is disabled

Mode Global Configuration

Usage Use “**dot1x guest-vlan**” command to enable the global setting of guest VLAN and specify guest VLAN ID. Use the **no** form of this command to disable guest VLAN.

Example

The following example shows how to create guest VLAN.
 Switch(config)# **vlan 3** Switch(config-vlan)# exit Switch(config)#
 dot1x guest-vlan 3 Switch# **show authentication**
 Authentication dot1x state : enabled Authentication mac state :
 disabled Authentication web state : disabled Guest VLAN : enabled
 (3) Mac-auth Radius User ID Format: XXXXXXXXXXXXX

dot1x max-req

Syntax **dot1x max-req** <1-10>
no dot1x max-req

Parameter	<1-10>	The maximum number of EAP requests that can be sent. If a response is not received after the defined period (supplicant timeout), <u>the authentication process is restarted.</u>
------------------	--------	---

Default	Default EAP max request number is 2.
----------------	--------------------------------------

Mode	Interface Configuration
-------------	-------------------------

Usage Use “**dot1x max-req**” command to configure the port 802.1x max EAP request value. The max request is the maximum number of EAP requests that can be sent. If a response is not received after the defined period (supplicant timeout), the authentication process is restarted.

Use **no** form of this command to restore default value.

Example

The following example shows how to configure port 802.1x EAP TX period.

```
Switch(config)# interface fa1 Switch(config-if)# dot1x max-req 1
Switch# show authentication interface fa1 Interface FastEthernet1
.....
Common Timers
Reauthenticate Period: 300 Inactive Timeout : 300 Quiet Period : 300
802.1x Parameters
EAP Max Request : 1
EAP TX Period : 10 Supplicant Timeout : 120 Server Timeout : 150
Web-auth Parameters
Login Attempt : 3
```

dot1x port-control

Syntax dot1x port-control (auto|force-auth|force-unauth)
no dot1x port-control

Parameter	auto	Need passing authentication procedure to get network accessibility
	force-auth	Port is force authorized and all clients have network accessibility.
	force-unauth	Port is force unauthorized and all clients <u>have no network accessibility.</u>

Default Default is disabled.

Mode Interface Configuration

Usage Use “**dot1x port-control**” command to enable the port authentication control mode. The “**authentication port-control**” command has the same effect. Use the **no** form of this command to disable authentication port control.

Example

The following example shows how to configure port control to auto mode.

```
Switch(config)# interface fa1 Switch(config-if)# dot1x port-
control auto Switch# show authentication interface fa1 Interface
FastEthernet1
Admin Control : auto
Host Mode : multi-auth
Type dot1x State : enabled
Type mac State : disabled
Type web State : disabled
.....
```

dot1x reauth

Syntax `dot1x reauth`
`no dot1x reauth`

Parameter

Default Default is disabled.

Mode Interface Configuration

Usage Use “**dot1x reauth**” command to enable the port reauthentication. The “**authentication reauth**” command has the same effect, it is a backward compatible command
 Use the **no** form of this command to disable reauthentication.

Example

The following example shows how to enable port reauthentication.

```
Switch(config)# interface fa1
Switch(config-if)# dot1x reauth
Switch# show authentication interface fa1
Interface FastEthernet1
Admin Control : disable
Host Mode : multi-auth
Type dot1x State : disabled
Type mac State : disabled
Type web State : disabled
Type Order : dot1x MAC/WEB Method Order : radius Guest VLAN :
disabled
Reauthentication : enabled
.....
```

dot1x timeout reauth-period

Syntax `dot1x timeout reauth-period <300-4294967294>`
`no dot1x timeout reauth-period`

Parameter `<300-4294967294>` Time in seconds after which an automatic re-authentication should be initiated

Default Default reauthentication period is 3600 seconds.

Mode Interface Configuration

Usage Use “**dot1x timeout reauth**” command to configure the port reauthentication period value with unit second if the reauthentication time is not assigned by local database or remote authentication server. On the other hand, if the

reauthentication time is assigned by local database or remote server, this configured reauthentication time will be ignored.

The “**authentication timer reauth**” command has the same effect and it is a backward compatible command.

Use **no** form of this command to restore default value.

Example

The following example shows how to configure port 802.1x reauthentication period.

```
Switch(config)# interface fa1
Switch(config-if)# dot1x timeout reauth-period 300 Switch# show
authentication interface fa1 Interface FastEthernet1
```

```
.....
Common Timers
Reauthenticate Period: 300 Inactive Timeout : 60
Quiet Period : 60
```

802.1x Parameters

EAP Max Request : 2

EAP TX Period : 30 Supplicant Timeout : 30 Server Timeout : 30

Web-auth Parameters

Login Attempt : 3

dot1x timeout quiet-period

Syntax dot1x timeout quiet-period <0-65535>

no dot1x timeout quiet-period

Parameter	<0-65535>	Interval in seconds to wait following a failed authentication exchange
------------------	------------------------	--

Default	Default quiet period is 60 seconds.
----------------	-------------------------------------

Mode	Interface Configuration
-------------	-------------------------

Usage Use “**dot1x timeout quiet-period**” command to configure the port quiet period value. The “**authentication timer quiet**” command has the same effect and it is backward compatible command.

After authenticating fail many times and the port is guest VLAN disabled, the port/host will enter lock state until quiet period expired. In lock state, the port/host is not allowed to do authenticating.

Use **no** form of this command to restore default value.

Example

The following example shows how to configure port 802.1x quiet period.

```
Switch(config)# interface fa1
Switch(config-if)# dot1x timeout quiet-period 300 Switch# show
authentication interface fa1 Interface FastEthernet1
.....
Common Timers
Reauthenticate Period: 300 Inactive Timeout : 300 Quiet Period : 300
802.1x Parameters
EAP Max Request : 2
EAP TX Period : 30 Supplicant Timeout : 30 Server Timeout : 30
Web-auth Parameters
Login Attempt : 3
```

dot1x timeout server-timeout

Syntax `dot1x timeout server-timeout <1-65535>`

no dot1x timeout server-timeout

Parameter	<1-65535>	Number of seconds that lapses before the device resends a request to the authentication <u>server.</u>
------------------	-----------	--

Default	Default server timeout is 30 seconds.
----------------	---------------------------------------

Mode	Interface Configuration
-------------	-------------------------

Usage Use “**dot1x timeout server-timeout**” command to configure the port 802.1x server timeout value. The server timeout is the number of seconds that lapses before the device resends a request to the authentication server. Use **no** form of this command to restore default value.

Example

The following example shows how to configure port 802.1x server timeout.

```
Switch(config)# interface fa1
Switch(config-if)# dot1x timeout supp-timeout 150 Switch# show
authentication interface fa1 Interface FastEthernet1
.....
Common Timers
Reauthenticate Period: 300 Inactive Timeout : 300 Quiet Period : 300
802.1x Parameters
EAP Max Request : 2
EAP TX Period : 30 Supplicant Timeout : 120 Server Timeout : 150
Web-auth Parameters
Login Attempt : 3
```

dot1x timeout supp-timeout

Syntax `dot1x timeout supp-timeout <1-65535>`
`no dot1x timeout supp-timeout`

Parameter	<1-65535>	Number of seconds that lapses before EAP requests are resent to the supplicant
------------------	-----------	--

Default	Default supplicant timeout is 30 seconds.
----------------	---

Mode	Interface Configuration
-------------	-------------------------

Usage Use “`dot1x timeout supp-timeout`” command to configure the port supplicant timeout value. The supplicant timeout is the number of seconds that lapses before EAP requests are resent to the supplicant. Use **no** form of this command to restore default value.

Example

The following example shows how to configure port 802.1x supplicant timeout.

```
Switch(config)# interface fa1
Switch(config-if)# dot1x timeout supp-timeout 120 Switch# show
authentication interface fa1 Interface FastEthernet1
.....
Common Timers
Reauthenticate Period: 300 Inactive Timeout : 300 Quiet Period : 300
802.1x Parameters
EAP Max Request : 2
EAP TX Period : 30 Supplicant Timeout : 120 Server Timeout : 30
Web-auth Parameters
Login Attempt : 3
```


dot1x timeout tx-period

Syntax **dot1x timeout tx-period** <1-65535>

no dot1x timeout tx-period

Parameter	<1-65535>	Number of seconds that the device waits for a response to an Extensible Authentication Protocol (EAP) request/identity frame from the supplicant (client) before resending the <u>request</u> .
------------------	-----------	---

Default	Default EAP TX period is 30 seconds.
----------------	--------------------------------------

Mode	Interface Configuration
-------------	-------------------------

Usage Use “**dot1x timeout tx-period**” command to configure the port 802.1x EAP TX period value. The TX period is the number of seconds that the device waits for a response to an Extensible Authentication Protocol (EAP) request/identity frame from the supplicant (client) before resending the request.

Use **no** form of this command to restore default value.

Example	The following example shows how to configure port 802.1x EAP TX period.
----------------	---

```
Switch(config)# interface fa1
Switch(config-if)# dot1x timeout tx-period 10
```

```
Switch# show authentication interface fa1
Interface FastEthernet1
.....
Common Timers
Reauthenticate Period: 300 Inactive Timeout : 300 Quiet Period : 300
802.1x Parameters
EAP Max Request : 2
EAP TX Period : 10 Supplicant Timeout : 120 Server Timeout : 150
Web-auth Parameters
Login Attempt : 3
```

show authentication

Syntax	show authentication show authentication interfaces <i>IF_PORTS</i>
---------------	---

Parameter	interfaces Specify port list to show port configurations. <u><i>IF_PORTS</i></u>
------------------	--

Default	No default value for this command.
----------------	------------------------------------

Mode Privileged EXEC

Usage Use “**show authentication**” command to show all authentication manager configurations.
 Use “**show authentication interface**” command to show authentication manager configuration of specific port.

Example

This example shows how to show the mac authentication configurations of port fa1.

```
Switch# show authentication
Authentication dot1x state : enabled
Authentication mac state : disabled
Authentication web state : disabled
Guest VLAN : disabled
Mac-auth Radius User ID Format: XXXXXXXXXXXXX

Mac-auth Local Entry :
Reauth Inactive MAC Address Control VLAN Period Timeout
----- 00:11:22:33:44:55
Authorized 3 30000 123

Web-auth Local Entry :
Reauth Inactive
User Name VLAN Period Timeout
----- acct1 5 12345 333
```

Interface Configurations Interface FastEthernet1

```
Admin Control : disable
Host Mode : multi-auth
Type dot1x State : disabled
Type mac State : disabled
Type web State : disabled
Type Order : dot1x MAC/WEB Method Order : radius Guest VLAN : disabled
Reauthentication : disabled
Max Hosts : 256
VLAN Assign Mode : static Common Timers
Reauthenticate Period: 3600 Inactive Timeout : 60
Quiet Period : 60 802.1x Parameters
EAP Max Request : 2
EAP TX Period : 30 Supplicant Timeout : 30 Server Timeout : 30
Web-auth Parameters
Login Attempt : 3
```

Switch# **show authentication interface fa7**

Interface Configurations

```
Interface FastEthernet7 Admin Control : auto
Host Mode : multi-auth Type dot1x State : enabled Type mac State : disabled Type web State : disabled Type Order : dot1x MAC/WEB Method Order : radius Guest VLAN :
disabled Reauthentication : disabled Max Hosts 256
VLAN Assign Mode : static Common Timers Reauthenticate Period: 3600 Inactive Timeout 60
Quiet Period 60
802.1x Parameters
EAP Max Request 2
EAP TX Period 30
Supplicant Timeout 30
Server Timeout : 65535 Web-auth Parameters
Login Attempt : 3
```

show authentication sessions

Syntax **show authentication sessions [detail]**
show authentication sessions interface IF_PORTS show authentication sessions session-id WORD show authentication session type (dot1x|mac|web)

Parameter	detail	Show session detail information.
	interface	Show session detail information of specific

	IF_PORTS	port
	session-id WORD	Show session detail information of specific session id
	type (dot1x mac web)	Show session detail information of specific authentication type

Default No default value for this command.

Mode Privileged EXEC

Usage Use “**show authentication sessions**” command to show authentication detail session information.

Example This example shows how to show current authentication session brief and detail information.

```
Switch# show authentication sessions
Interface MAC Address Type Status Session ID
-----
00:01:6C:CB:29:4A dot1x Authorized 000000010000A028 fa7
Switch# show authentication sessions detail
Interface : FastEthernet7
MAC Address : 00:01:6C:CB:29:4A
Session ID : 000000010000A028
Current Type : dot1x
Status : Authorized Authorized Information
VLAN : 5 (from RADIUS)
Reauthenticate Period: 301 (from RADIUS) Inactive Timeout : 600
(from RADIUS)
Operational Information VLAN : 5
Session Time : 1143
Inactive Time : 168
Quiet Time : N/A
```

Diagnostic show cable-diag

Syntax `show cable-diag interfaces IF_NMLPORTS`

Parameter	interfaces <i>IF_NMLPORTS</i>	Display the cable diagnostic information of the copper media for an interface ID or a list of interfaces IDs.
------------------	---	---

Default N/A

Mode Privileged EXEC

Usage To show the estimated copper cable length attached to a specific interface, use the command **show cable-diag** in the Privileged EXEC mode. For the proper information of the cable length, the interface must be active and linked up.

Example The following example shows the result of cable diagnostic for the interface fa1 and fa2.

```
Switch# show cable-diag interfaces fa1-2
Port | Speed | Local pair | Pair length | Pair status
-----+-----+-----+-----+-----
fa1 | auto | Pair A | 0.88 | Open
Pair B | 0.82 | Open Pair C | 0.80 | Open Pair D | 0.78 | Open

fa2 | auto | Pair A | 0.81 | Open
Pair B | 0.81 | Open Pair C | 0.77 | Open
Pair D | 0.81 | Open
```

show fiber-transceiver

Syntax `show fiber-transceiver interfaces IF_NMLPORTS`

Parameter	interfaces <i>IF_NMLPORTS</i>	Display the diagnostic information of the fiber transceiver for an interface ID or a list of interface IDs.
------------------	---	---

Default N/A

Mode Privileged EXEC

Usage To show the diagnostic information of the fiber transceiver use the command **show fiber-transceiver** in the Privilege EXEC mode.

Example The following example shows the diagnostic information for the interface gi1 and gi2, where the int fiber media ports with the transceiver inserted.

```
Switch# show fiber-transceiver interfaces gi1-2
Port | Temperature | Voltage | Current | Output power | Input power |
| [C] | [Volt] | [mA] | [mWatt] | [mWatt] |
=====
gi1 | N/S | N/S | N/S | N/S | N/S | Insert |
gi2 | N/S | N/S | N/S | N/S | N/S | Insert |
```

Temp - Internally measured transceiver temperature Voltage - Internally measured supply voltage
 Current - Measured TX bias current
 Output Power - Measured TX output power in milliWatts Input Power - Measured RX received power in milliWatts
 OE-Present - SFP Present or Not Present
 LOS - Loss of signal
 N/A - Not Available, N/S - Not Supported, W - Warning, E - Error

DHCP Snooping

ip dhcp snooping

Syntax ip dhcp snooping

no ip dhcp snooping

Parameter None

Default DHCP snooping is disabled

Mode Global Configuration

Usage Use the ip dhcp snooping command to enable DHCP Snooping function. Use the no form of this command to disable.

Example

The example shows how to enable DHCP Snooping on VLAN 1. You can verify settings by the following show ip dhcp snooping command.

```
switch(config)# ip dhcp snooping
switch(config)# ip dhcp snooping vlan 1
switch(config)# show ip dhcp snooping
```

DHCP Snooping : enabled Enable on following Vlans 1
 circuit-id default format : vlan-port
 remote-id : 00:11:22:33:44:55 (Switch Mac in Byte Order)

ip dhcp snooping vlan

Syntax ip dhcp snooping vlan VLAN-LIST

Parameter	VLAN-LIST	Specify VLAN ID or a range of VLANs to enable or <u>disable dynamic Arp inspection</u>
------------------	------------------	--

Default Default is disabled on all VLANs

Mode Global Configuration

Usage Use the **ip dhcp snooping vlan** command to enable VLANs on DHCP Snooping function. Use the **no** form of this command to disable VLANs on DHCP Snooping function.

Example

The example shows how to enable VLAN 1-100 on DHCP Snooping, and then disable VLAN 30-40 on DHCP Snooping. You can verify settings by the following **show ip dhcp snooping** command.

```
switch(config)# vlan 1-100 switch(config)# exit switch(config)# ip dhcp snooping
switch(config)# ip dhcp snooping vlan 1-100 switch(config)# show ip dhcp snooping
DHCP Snooping : enabled
Enable on following Vlans : 1-100 circuit-id default format : vlan-port
remote-id: 00:11:22:33:44:55 (Switch Mac in Byte Order)
```

```
switch(config)# no ip dhcp snooping vlan 30-40
switch(config)# show ip dhcp snooping
DHCP Snooping : enabled
Enable on following Vlans : 1-29,41-100 circuit-id default format : vlan-port
remote-id : 00:11:22:33:44:55 (Switch Mac in Byte Order)
```

ip dhcp snooping trust

Syntax ip dhcp snooping trust no ip dhcp snooping trust

Parameter	None
Default	DHCP snooping trust is disabled
Mode	Interface Configuration

Usage Use the **ip dhcp snooping trust** command to set trusted interface. The switch does not check DHCP packets that are received on the trusted interface; it simply forwards it. Use the **no** form of this command to set untrusted interface.

Example

The example shows how to set interface gi1 to trust. You can verify settings by the following **show ip dhcp snooping interface** command.

```
switch(config)# interface gi1
switch(config-if)# ip dhcp snooping trust
switch(config-if)# do show ip dhcp snooping interface gi1
Interfaces | Trust State | Rate (pps) | hwaddr Check | Insert Option82 |
-----+-----+-----+-----+-----+
gi1 | Trusted | None | disabled | disabled |
```

ip dhcp snooping verify

Syntax ip dhcp snooping verify mac-address [no] ip dhcp snooping verify mac-address

Parameter	None
Default	DHCP snooping verify mac-address is disabled
Mode	Interface Configuration

Usage Use the **ip dhcp snooping verify** command to verify MAC address function on interface. The “**mac-address**” drop DHCP packets that chaddr and ethernet-source-mac is not match.

Example The example shows how to set interface **gi1** to validate “**mac-address**”. You can verify settings by the following **show ip dhcp snooping interface** command.

```
switch(config)# interface gi1
switch(config-if)# ip dhcp snooping verify mac-address
switch(config-if)# do show ip dhcp snooping interface gi1 Interfaces
| Trust State | Rate (pps) | hwaddr Check | Insert Option82 |
-----+-----+-----+-----+-----+
gi1 | Untrusted | None | disabled | disabled |
```

ip dhcp snooping rate-limit

Syntax ip dhcp snooping rate-limit <1-300> [no] ip dhcp snooping rate-limit

Parameter	<1-300>	Set 1 to 300 PPS of DHCP packet rate limitation
Default		Default is un-limited of DHCP packet
Mode		Interface Configuration

Usage Use the **ip dhcp snooping rate-limit** command to set rate limitation on interface. The switch drop DHCP packets after receives more than configured rate of packets per second. Use the **no** form of this command to return to default settings.

Example The example shows how to set rate limit to 30 pps on interface gi1. You can verify settings by the following **show ip dhcp snooping interface** command.

```
switch(config)# interface gi1
switch(config-if)# ip dhcp snooping rate-limit 30
switch(config-if)# do show ip dhcp snooping interfaces gi1
Interfaces|Trust State|Rate (pps)|hwaddr Check|Insert Option82|
-----+-----+-----+-----+-----+
gi1 | Untrusted | 30 | disabled | disabled |
```

clear ip dhcp snooping statistics

Syntax clear ip dhcp snooping interfaces IF_PORTS statistics

Parameter IF_PORTS specifies ports to clear statistics

Default No default is defined

Mode Privileged EXEC

Usage Use the **clear ip dhcp snooping interfaces statistics** command to clear statistics that are recorded on interface.

Example The example shows how to clear statistics on interface gi1. You can verify settings by the following **show ip dhcp snooping interface statistics** command.

```
switch# clear ip dhcp snooping interfaces gi1 statistics
switch# show ip dhcp snooping interfaces gi1 statistics
Interfaces | Forwarded | Chaddr Check Dropped | Untrust Port Dropped | Untrust Port With Option82 Dropped | Invalid Drop
-----+-----+-----+-----+-----+
gi1 | 0 | 0 | 0 | 0 | 0
```

show ip dhcp snooping

Syntax show ip dhcp snooping

Parameter None

Default No default is defined

Mode Privileged EXEC

Usage Use the **show ip dhcp snooping** command to show settings of DHCP Snooping.

Example The example shows how to show settings of DHCP Snooping

```
switch(config)# show ip dhcp snooping DHCP Snooping : enabled Enable on
following Vlans : 1
circuit-id default format: vlan-port
remote-id: : 00:11:22:33:44:55 (Switch Mac in Byte Order)
```

show ip dhcp snooping interface

Syntax **show ip dhcp snooping interfaces IF_PORTS**
show ip dhcp snooping interfaces IF_PORTS statistics

Parameter **IF_PORTS** specifies ports to show statistics

Default No default is defined

Mode Privileged EXEC

Usage Use the **show ip dhcp snooping interfaces** command to show settings or statistics of interface.

Example The example shows how to show settings of interface gi1.

```
switch# show ip dhcp snooping interface gi1
Interfaces | Trust State | Rate (pps) | hwaddr Check | Insert Option82 |
-----+-----+-----+-----+-----+
gi1 | Untrusted | None | enabled | disabled |
```

The example shows how to show statistics of interface gi1. switch#

```
show ip dhcp snooping interfaces gi1 statistics Interfaces | Forwarded
| Chaddr Check Dropped | Untrust Port Dropped | Untrust Port With Option82
Dropped | Invalid Drop
-----+-----+-----+-----+-----+
gi1 | 0 | 0 | 0 | 0 | 0
```

show ip dhcp snooping binding

Syntax **show ip dhcp snooping binding**

Parameter None

Default No default is defined

Mode Privileged EXEC

Usage Use the **show ip dhcp snooping binding** command to show binding entries that learned by DHCP Snooping.

Example The example shows how to show binding entries that learned by DHCP Snooping.

```
switch# show ip dhcp snooping binding
Bind Table: Maximun Binding Entry Number 192
Port | VID | MAC Address | IP | Type | Lease Time
-----+-----+-----+-----+-----+-----
48:5B:39:C7:12:62 | 192.168.1.100(255.255.255.255)|DHCP Snooping | 86400
```

ip dhcp snooping option

Syntax **ip dhcp snooping option**
no ip dhcp snooping option

Parameter None

Default DHCP snooping option82 is disabled

Mode Interface Configuration

Usage Use the **ip dhcp snooping option** command to enable that insert option82 content into packet. Use the **no** form of this command to disable.

Example The example shows how to enable option82 insertion. You can verify settings by the following **show ip dhcp snooping interface** command.

```
switch(config)# interface gi1
switch(config-if)# ip dhcp snooping option
switch(config-if)# do show ip dhcp snooping interfaces gi1
Interfaces | Trust State | Rate (pps) | hwaddr Check | Insert Option82 |
-----+-----+-----+-----+-----+
gi1 | Untrusted | None | disabled | enabled |
```

ip dhcp snooping option action

Parameter	Drop	Drop packets with option82 that are received from un trusted port
	Keep	Keep original option82 content in packet
	Replace	Replace option82 content by switch setting

Default DHCP snooping option82 is drop

Mode Interface Configuration

Usage Use the **ip dhcp snooping option action** command to set the action when receive packets that with option82 content. Use the **no** form of this command to default setting.

Example The example shows how to set action to replace option82 content. You can verify settings by the following **show running-config** command.

```
switch(config)# interface gi1
switch(config-if)# ip dhcp snooping option action replace
```

ip dhcp snooping option circuit-id

Syntax **ip dhcp snooping [vlan <1-4094>] option circuit-id STRING**
no ip dhcp snooping [vlan <1-4094>] option circuit-id

Parameter	Vlan <1-4094>	VLAN ID to set user defined circuit-id string
	STRING	Circuit-id string, 1 to 63 ASCII characters, no spaces.

Default Default circuit-id is port id + vlan id in byte format.

Mode Interface Configuration

Usage Use the **ip dhcp snooping option circuit-id** command to set user-defined circuit-id string. Circuit-id is per port per VLAN setting. If a VLAN is not found user-defined circuit-id then use per port circuit-id string. Use the **no** form of this command to default setting.

Syntax **ip dhcp snooping option action (drop|keep|replace)**
no ip dhcp snooping option action

Example

The example shows how to set a user-defined circuit-id string on interface gi1 and VLAN 1. You can verify settings by the following **show running-config** command

```
switch(config)# interface gi1
switch(config-if)# ip dhcp snooping vlan 1 option circuit-id test
```

ip dhcp snooping option remote-id

Syntax ip dhcp snooping option remote-id STRING

no ip dhcp snooping option remote-id

Parameter

STRING Remote-id string, 1 to 63 ASCII characters, no spaces.

Default

Default remote-id is the switch MAC address in byte order

Mode

Global Configuration

Usage Use the **ip dhcp snooping option remote-id** command to set user-defined remote-id string. Remote-id is a global and unique string. Use the **no** form of this command to default setting.

Example

The example shows how to set a user-defined remote-id string on switch. You can verify settings by the following **show ip dhcp snooping option remote-id**

```
switch(config)# ip dhcp snooping option remote-id test_remote
switch(config)# do show ip dhcp snooping option remote-id Remote ID:
test_remote
```

show ip dhcp snooping option

Syntax

show ip dhcp snooping option remote-id

Parameter

None

Default

No default is defined

Mode

Privileged EXEC

Usage

Use the **show ip dhcp snooping option remote-id** command to show remote-id string.

Example

The example shows how to show remote-id string

```
switch(config)# do show ip dhcp snooping option remote-id
Remote ID: test_remote
```

ip dhcp snooping database

Syntax

```
ip dhcp snooping database flash
ip dhcp snooping database tftp (A.B.C.D|HOSTNAME) NAME no
ip dhcp snooping database
```

Parameter

(A.B.C.D HOSTNAME)	Specify the IP address or hostname of remote TFTP server
NAME	Input name of backup file

Default

DHCP snooping database is disabled

Mode

Global Configuration

Usage Use the **ip dhcp snooping database** command to enable DHCP Snooping database agent. The “**flash**” means that write backup file to switch local drive. The “**tftp**” means that write backup file to remote TFTP server. Use the **no** form of this command to disable.

Example

The example shows how to enable DHCP Snooping database agent and write backup file to remote TFTP server with file name “backup_file”. You can verify settings by the following **show ip dhcp snooping database** command.

```
switch(config)# ip dhcp snooping database tftp 192.168.1.50 backup_file
switch(config)# do show ip dhcp snooping database
Type : tftp: 192.168.1.50 FileName : backup_file
Write delay Timer : 300 seconds Abort Timer : 300 seconds
```

```
Agent Running : Running
Delay Timer Expiry : 300 seconds Abort Timer Expiry : 299
```

```
Last Succeeded Time : None Last Failed Time : None
Last Failed Reason : No failure recorded.
```

```
Total Attempts : 1
Successful Transfers : 0 Failed Transfers : 0 Successful Reads : 0 Failed Reads :
0 Successful Writes : 0 Failed Writes : 0
```

ip dhcp snooping database write-delay

Syntax ip dhcp snooping database write-delay <15-86400> no ip dhcp snooping database write-delay

Parameter	<15-86400>	Specifies the seconds of timeout. Specify the duration for which the transfer should be delayed after the <u>binding database changes</u>
------------------	------------	---

Default	DHCP snooping database write-delay is 300 seconds	
----------------	---	--

Mode	Global Configuration	
-------------	----------------------	--

Usage	Use the ip dhcp snooping database write-delay command to modify the write-delay timer. Use the no form of this command to default setting.	
--------------	--	--

Example	The example shows how to set write-delay timer to 60 seconds. You can verify settings by the following show ip dhcp snooping database command.	
----------------	---	--

```
switch(config)# ip dhcp snooping database write-delay 60
switch(config)# do show ip dhcp snooping database
Type : tftp: 192.168.1.50 FileName : backup_file
Write delay Timer : 60 seconds Abort Timer : 300 seconds
```

```
Agent Running : Running
Delay Timer Expiry : 300 seconds Abort Timer Expiry : 299
```

```
Last Succeeded Time : None Last Failed Time : None
Last Failed Reason : No failure recorded.
```

```
Total Attempts : 1
Successful Transfers : 0 Failed Transfers : 0 Successful Reads : 0 Failed Reads :
0 Successful Writes : 0 Failed Writes : 0
```

ip dhcp snooping database timeout

Syntax ip dhcp snooping database timeout <0-86400>

no ip dhcp snooping database timeout

Parameter	<15-86400>	Specifies the seconds of timeout ° Specify (in seconds) how long to wait for the database transfer process to finish before stopping the process. Use 0 to define an infinite duration, which means to continue trying the <u>transfer indefinitely</u>
------------------	------------	---

Default	DHCP snooping database timeout is 300 seconds
----------------	---

Mode	Global Configuration
-------------	----------------------

Usage	Use the ip dhcp snooping database timeout command to modify the timeout timer. Use the no form of this command to default setting.
--------------	--

Example	The example shows how to set timeout timer to 60 seconds. You can verify settings by the following show ip dhcp snooping database command.
----------------	---

```

switch(config)# ip dhcp snooping database timeout 60 switch(config)# do
show ip dhcp snooping database Type : tftp: 192.168.1.50
FileName : backup_file
Write delay Timer : 300 seconds Abort Timer : 60 seconds

Agent Running : Running
Delay Timer Expiry : 300 seconds Abort Timer Expiry : 299

Last Succeeded Time : None Last Failed Time : None
Last Failed Reason : No failure recorded.

Total Attempts : 1
Successful Transfers : 0 Failed Transfers : 0 Successful Reads : 0 Failed Reads :
0 Successful Writes : 0 Failed Writes : 0

```

clear ip dhcp snooping database statistics

Syntax clear ip dhcp snooping database statistics

Parameter None

Default No default is defined

Mode Privileged EXEC

Usage Use the **clear ip dhcp snooping database statistics** command to clear statistics of DHCP Snooping database.

Example The example shows how to clear statistics of DHCP Snooping agent. You can verify settings by the following **show ip dhcp snooping database** command.

```
switch# clear ip dhcp snooping database statistics
switch# show ip dhcp snooping database
Type : tftp: 192.168.1.50 FileName : backup_file
Write delay Timer : 300 seconds Abort Timer : 60 seconds

Agent Running : Running
Delay Timer Expiry : 300 seconds Abort Timer Expiry : 299

Last Succeeded Time : None Last Failed Time : None
Last Failed Reason : No failure recorded.

Total Attempts : 0
Successful Transfers : 0 Failed Transfers : 0 Successful Reads : 0
Failed Reads : 0 Successful Writes : 0 Failed Writes : 0
```

renew ip dhcp snooping database

Syntax renew ip dhcp snooping database

Parameter None

Default No default is defined

Mode Privileged EXEC

Usage Use the **renew ip dhcp snooping database** command to renew DHCP Snooping database from backup file.

Example The example shows how to renew DHCP Snooping database. You can verify settings by the following **show ip dhcp snooping database** and **show ip dhcp snooping binding** command.

```
switch# show ip dhcp snooping database
Type : tftp: 192.168.1.50 FileName : backup_file
Write delay Timer : 300 seconds Abort Timer : 60 seconds
```

```
Agent Running : Running
Delay Timer Expiry : 300 seconds Abort Timer Expiry : 299
```

```
Last Succeeded Time : None Last Failed Time : None
Last Failed Reason : No failure recorded.
```

```
Total Attempts : 1
Successful Transfers : 1 Failed Transfers : 0 Successful Reads : 1
Failed Reads : 0 Successful Writes : 0 Failed Writes : 0
```

```
switch# show ip dhcp snooping binding
Bind Table: Maximun Binding Entry Number 192
Port | VID | MAC Address | IP | Type | Lease Time
-----+-----+-----+-----+-----+-----
| 48:5B:39:C7:12:62 | 192.168.1.100(255.255.255.255)|DHCP Snooping | 86400
-----+-----+-----+-----+-----+-----
fa1 | 1
```

show ip dhcp snooping database

Syntax show ip dhcp snooping database

Parameter None

Default No default is defined

Mode Privileged EXEC

Usage Use the **show ip dhcp snooping database** command to show settings of DHCP Snooping agent.

Example

The example shows how to show settings of DHCP Snooping agent.

```
switch(config)# show ip dhcp snooping database
Type : tftp: 192.168.1.50 FileName : backup_file
Write delay Timer : 300 seconds Abort Timer : 60 seconds

Agent Running : Running
Delay Timer Expiry : 300 seconds Abort Timer Expiry : 299

Last Succeeded Time : None Last Failed Time : None
Last Failed Reason : No failure recorded.

Total Attempts : 1
Successful Transfers : 1 Failed Transfers : 0 Successful Reads : 1 Failed Reads :
0 Successful Writes : 0 Failed Writes : 0
```

DoS

dos

Syntax **dos** (daeqlsa-deny|icmp-frag-pkts-deny|icmpv4-ping-max-check|icmpv6-ping-max-check|ipv6-min-frag-size-check|land-deny|nullscan-deny|pod-deny|smurf-deny|syn-sport1024-deny|synfin-deny|synrst-deny|tcp-frag-off-min-check|tcpblat-deny|tcphdr-min-check|udpblat-deny|xmas-deny)
dos icmp-ping-max-length *MAX_LEN*
dos ipv6-min-frag-size-length *MIN_LEN*
dos smurf-netmask *MASK*
dos tcphdr-min-length *HDR_MIN_LEN*
no dos (tcp-frag-off-min-check|synrst-deny|synfin-deny|xma-deny|nullscan-deny|syn-sport1024-deny|tcphdr-min-check|smurf-deny|icmpv6-ping-max-check|icmpv4-ping-max-check|icmp-frag-pkts-deny|ipv6-min-frag-size-check|pod-deny|tcpblat-deny|udpblat-deny|land-deny|daeqlsa-deny)

Parameter

daeqlsa-deny	Drops the packets if the destination MAC address is equal to the source MAC address.
icmp-frag-pkts-deny	Drops the fragmented ICMP packets.
icmpv4-ping-max-check	Checks the maximum size of ICMP ping packets, and drops the packets larger than the maximum packet size defined by the command dos icmp-ping-max-length

icmpv6-ping-max-check	Checks the maximum size of ICMPv6 ping packets, and drops the packets larger than the maximum packet size defined by the command dos icmp-ping-max-length MAX_LEN .
ipv6-min-frag-size-check	Checks the minimum size of IPv6 fragments, and drops the packets smaller than the minimum size defined by the command dos ipv6-min-frag-size-length MIN_LEN .
land-deny	Drops the packets if the source IP address is equal to the destination IP address.
nullscan-deny	Drops the packets with NULL scan.
pod-deny	Avoids ping of death attack.
smurf-deny	Avoids smurf attack.
syn-sport1024-deny	Drops SYN packets with sport less than 1024.
synfin-deny	Drops the packets with SYN and FIN bits set.
synrst-deny	Drops the packets with SYN and RST bits set.
tcp-frag-off-min-check	Drops the TCP fragment packets with offset equals to one.
tcpblat-deny	Drops the packages if the TCP source port is equal to the TCP destination port.
tcphdr-min-check	Checks the minimum TCP header and drops the TCP packets with the header smaller than the minimum size defined by the command dos tcphdr-min-length HDR_MIN_LEN .
udpblat-deny	Drops the packets if the UDP source port equals to the UDP destination port.
xmas-deny	Drops the packets if the sequence number is zero, and the FIN, URG and PSH bits are set.
icmp-ping-max-length MAX_LEN	Specify the maximum size of the ICMPv4/ICMPv6 ping packets. The valid range is from 0 to 65535 bytes, and the default value is 512 bytes.
ipv6-min-frag-size-length MIN_LEN	Specify the minimum size of IPv6 fragments. The valid range is from 0 to 65535 bytes, and default value is 1240 bytes.
smurf-netmask MASK	Specify the netmask of smurf attack. The length range is from 0 to 323 bytes, and default length is 0 bytes.
tcphdr-min-length HDR_MIN_LEN	Specify the minimum TCP header length. The length range is from 0 to 31 bytes, and default length is 20 bytes.

Default

All of DoS protections are enabled by default. The default parameter are:

The maximum size of ICMP ping packages is 512 bytes

The minimum size of IPv6 fragments is 1240 bytes.

The Smurf netmask length is 0 bytes.

The minimum TCP header length is 20 bytes.

Mode

Global Configuration

Usage To enable the specific Deniel of Service (DoS) protection, use the command **dos** in the Global Configuration mode. Otherwise, use the **no** form of the command to disable the specific DoS protection.

Example The following example sets the minimum fragment size to 1024 bytes, and enables the minimum size of IPv6 fragments validation.

```
Switch(config)# dos ipv6-min-frag-size-length 1024
Switch(config)# dos ipv6-min-frag-size-check
```

dos (interface)

Syntax dos

no dos

Parameter N/A

Default DoS protection is disabled on each interface.

Mode Interface Configuration

Usage To enable the DoS on the specific interface, use the command **dos** in the Interface Configuration mode. Otherwise, use the **no** form of the command to disable the DoS on the interface.

Example The following example enables the DoS on the interface fa1.

```
Switch(config)# interface fa1
Switch(config-if)# dos
```

show dos

Syntax show dos

show dos interface IF_PORTS

Parameter **interface** An interface ID or the list of interface IDs.
IF_PORTS

Default N/A

Mode Privileged EXEC

Usage To show the DoS protection configuration, use the command **show dos** in the Privileged EXEC mode. For the status of DoS protection on each interface, use the command **show dos interface** in the Priveleged EXEC mode.

Example

The following example shows the global DoS protection configuration.

```
Switch# show dos
Type | State (Length)
-----+-----
DMAC equal to SMAC | enabled
Land (DIP = SIP) | enabled UDP Blat (DPORT = SPORT) | enabled TCP
Blat (DPORT = SPORT) | enabled POD (Ping of Death) | enabled
IPv6 Min Fragment Size | enabled (1024 Bytes) ICMP Fragment Packets
| enabled
IPv4 Ping Max Packet Size | enabled (512 Bytes) IPv6 Ping Max
Packet Size | enabled (512 Bytes)
Smurf Attack | enabled (Netmask Length: 0) TCP Min Header Length
| enabled (20 Bytes)
TCP Syn (SPORT < 1024) | enabled Null Scan Attack | enabled
X-Mas Scan Attack | enabled
TCP SYN-FIN Attack | enabled
TCP SYN-RST Attack | enabled TCP Fragment (Offset = 1) | enabled

Switch# show dos
```

The following example shows the status of DoS protection on the interface fa1.

```
Switch# show dos interfaces fa1 Port | DoS Protection
-----+-----
fa1 | disabled
```

Dynamic ARP Inspection

ip arp inspection

Syntax ip arp inspection no ip arp inspection

Parameter	None
Default	Dynamic Arp inspection is disabled
Mode	Global Configuration
Usage	Use the ip arp inspection command to enable Dynamic Arp Inspection function. Use the no form of this command to disable.

Example

The example shows how to enable Dynamic Arp Inspection on VLAN 1. You can verify settings by the following **show ip arp inspection** command.

```
switch(config)# ip arp inspection switch(config)# ip arp inspection vlan 1 switch(config)#
show ip arp inspection
Dynamic ARP Inspection : enabled Enable on Vlans 1
```

ip arp inspection vlan

Syntax ip arp inspection vlan VLAN-LIST no ip arp inspection vlan VLAN-LIST

Parameter	VLAN-LIST	Specify VLAN ID or a range of VLANs to enable or disable dynamic Arp inspection
------------------	-----------	---

Default	Default is disabled on all VLANs
----------------	----------------------------------

Mode	Global Configuration
-------------	----------------------

Usage Use the **ip arp inspection vlan** command to enable VLANs on Dynamic Arp Inspection function. Use the **no** form of this command to disable VLANs on Dynamic Arp Inspection function.

Example

The example shows how to enable VLAN 1-100 on Dynamic Arp Inspection, and then disable VLAN 30-40 on Dynamic Arp Inspection. You can verify settings by the following **show ip arp inspection** command.

```
switch(config)# vlan 1-100 switch(config)# exit switch(config)# ip arp inspection
switch(config)# ip arp inspection vlan 1-100 switch(config)# show ip arp inspection
Dynamic ARP Inspection : enabled
Enable on Vlans : 1-100
```

```
switch(config)# no ip arp inspection vlan 30-40
switch(config)# show ip arp inspection
Dynamic ARP Inspection : enabled Enable on Vlans : 1-29,41-100
```

ip arp inspection trust

Syntax ip arp inspection trust

no ip arp inspection trust

Parameter	None
------------------	------

Default	Dynamic Arp inspection trust is disabled
----------------	--

Mode Interface Configuration

Usage Use the **ip arp inspection trust** command to set trusted interface. The switch does not check ARP packets that are received on the trusted interface; it simply forwards it. Use the **no** form of this command to set untrusted interface.

Example The example shows how to set interface gi1 to trust. You can verify settings by the following **show ip arp inspection interface** command.

```
switch(config)# interface gi1
switch(config)# ip arp inspection trust
switch(config)# do show ip arp inspection interface gi1
Interfaces | Trust State | Rate (pps) | SMAC Check | DMAC Check | IP Check/Allow Zero
|
-----+-----+-----+-----+-----+-----+
gi1 | Trusted | None | disabled | disabled | disabled/disabled
```

ip arp inspection validate

Syntax **ip arp inspection validate src-mac ip arp inspection validate dst-mac**
ip arp inspection validate ip [allow-zeros] no ip arp inspection validate src-mac
no ip arp inspection validate dst-mac
no ip arp inspection validate ip [allow-zeros]

Parameter None

Default Default is disabled of all validation

Mode Interface Configuration

Usage Use the **ip arp inspection validate** command to enable validate function on interface. The '**src-mac**' drop ARP requests and reply packets that arp-sender-mac and ethernet- source-mac is not match. The '**dst-mac**' drops ARP reply packets that arp-target-mac and ethernet-dst-mac is not match. The '**ip**' drop ARP request and reply packets that sender-ip is invalid such as broadcast 、 multicast 、 all zero IP address and drop ARP reply packets that target-ip is invalid. The '**allow-zeros**' means won't drop all zero IP address. Use the **no** form of this command to disable validation.

Example

The example shows how to set interface gi1 to validate 'src-mac', 'dst-mac' and 'ip allow zeros'. You can verify settings by the following **show ip arp inspection interface** command.

```
switch(config)# interface gi1
switch(config-if)# ip arp inspection validate src-mac switch(config-if)# ip arp
inspection validate dst-ma switch(config-if)# ip arp inspection validate ip allow-
zeros switch(config)# do show ip arp inspection interface gi1
Interfaces | Trust State | Rate (pps) | SMAC Check | DMAC Check | IP Check/Allow Zero
|
-----+-----+-----+-----+-----+-----+-----+
gi1 | Untrusted | None | enabled | enabled | enabled/ enabled
```

ip arp inspection rate-limit

Syntax ip arp inspection rate-limit <1-50> [no] ip arp inspection rate-limit

Parameter	<1-50>	Set 1 to 50 PPS of DHCP packet rate limitation
Default		Default is un-limited of ARP packet
Mode		Interface Configuration

Usage Use the **ip arp inspection rate-limit** command to set rate limitation on interface. The switch drop ARP packets after receives more than configured rate of packets per second. Use the **no** form of this command to return to default settings.

Example

The example shows how to set rate limit to 30 pps on interface gi1. You can verify settings by the following **show ip arp inspection interface** command.

```
switch(config)# interface gi1
switch(config)# ip arp inspection rate-limit 30
switch(config)# do show ip arp inspection interface gi1
Interfaces | Trust State | Rate (pps) | SMAC Check | DMAC Check | IP Check/Allow Zero
|
-----+-----+-----+-----+-----+-----+-----+
gi1 | Untrusted | 30 | disabled | disabled | disabled/disabled
```

clear ip arp inspection statistics

Syntax clear ip arp inspection interfaces IF_PORTS statistics

Parameter	IF_PORTS	specifies ports to clear statistics
Default		No default is defined
Mode		Privileged EXEC

Usage Use the **clear ip arp inspection interfaces statistics** command to clear statistics that are recorded on interface.

Example The example shows how to clear statistics on interface gi1. You can verify settings by the following **show ip arp inspection interface statistics** command.

```
switch# clear ip arp inspection interfaces gi1 statistics switch# show ip arp inspection
interfaces gi1 statistics Port| Forward |Source MAC Failures|Dest MAC Failures|
SIP Validation Failures|DIP Validation Failures|IP-MAC Mismatch Failures
-----+-----+-----+-----+-----+-----+-----+-----+-----+-----+
gi1| 0 | 0 | 0 | 0 | 0 | 0 | 0 |
```

show ip arp inspection

Syntax **show ip dhcp snooping**

Parameter **None**

Default No default is defined

Mode Privileged EXEC

Usage Use the **show ip arp inspection** command to show settings of Dynamic Arp Inspection

Example The example shows how to show settings of Dynamic Arp Inspection
switch(config)# **show ip arp inspection** Dynamic ARP Inspection : enabled Enable on Vlans 1

show ip arp inspection interface

Syntax **show ip arp inspection interfaces IF_PORTS**
show ip arp inspection interfaces IF_PORTS statistics

Parameter **IF_PORTS** specifies ports to show statistics

Default No default is defined

Mode Privileged EXEC

Usage Use the **show ip arp inspection interfaces** command to show settings or statistics of interface.

Example

The example shows how to show settings of interface gi1.

```
switch# show ip arp inspection interface gi1
Interfaces | Trust State | Rate (pps) | SMAC Check | DMAC Check | IP Check/Allow Zero
|
-----+-----+-----+-----+-----+-----+
gi1 | Trusted | None | disabled | disabled | disabled/disabled
```

The example shows how to show statistics of interface gi1. switch# **show ip arp inspection interfaces gi1 statistics**

```
Port| Forward |Source MAC Failures|Dest MAC Failures|
SIP Validation Failures|DIP Validation Failures|IP-MAC Mismatch Failures
-----+-----+-----+-----+-----+
gi1| 0 | 0 | 0 | 0 | 0 | 0
```

GVRP

gvrp (Global)

Syntax **gvrp**
no gvrp

Parameter None

Default GVRP is disabled

Mode Global Configuration

Usage Disable gvrp will clear all learned dynamic vlan entry and do not learn dynamic vlan anymore.
Use 'show gvrp' to show configuration.

Example The following example specifies that set global gvrp test. Switch(config)# **gvrp**
Switch# show gvrp

GVRP Status

gvrp (Interface)

GVRP : Enabled
 Join time : 200 ms
 Leave time : 600 ms
 LeaveAll time : 10000 ms

Syntax **gvrp**
 no gvrp

Parameter none

Default GVRP is disabled on interface

Mode Interface mode

Usage ‘no gvrp’ will remove dynamic port from vlan.
 ‘gvrp’ must work at port mode is trunk.

Example The following example specifies that set port gvrp test. The port gvrp enable must set port mode is trunk firstly. Switch(config)#**interface gi1**
 Switch(config-if)# **switchport mode trunk**
 Switch(config)#**gvrp**
 Switch# **show gvrp configuration interfaces gi1**
 Port | GVRP-Status | Registration | Dynamic VLAN Creation
 -----+-----+-----+-----
 gi1 Enabled Normal Disabled

gvrp registration-mode

Syntax `gvrp registration-mode (normal | fixed | forbidden)`

Parameter	(normal fixed forbidden)	normal: register dynamic vlan, and transmit all vlan attribute. fixed: do not register dynamic vlan, and only transmit static vlan attribute. forbidden: do not register dynamic vlan, and only transmit default vlan attribute.
------------------	------------------------------	--

Default Default is Normal

Mode Interface mode

Usage When set registration-mode is fixed or forbidden, will remove the port from vlan witch is dynamic port. And do not learning vlan.

Example

```
The following example specifies that set gvrp registration mode test.
Switch(config)# interface gi1
Switch(config-if)# gvrp registration-mode fixed
Switch# show gvrp configuration interfaces gi1
Port | GVRP-Status | Registration | Dynamic VLAN Creation
-----+-----+-----+-----
gi1 Enabled Fixed Disabled
```

gvrp vlan-create-forbid

Syntax `gvrp vlan-creation-forbid`
`no gvrp vlan-creation-forbid`

Parameter	none
------------------	------

Default Default is disabled.

Mode Interface mode

Usage ‘gvrp vlan-creation-forbid’ will not remove dynamic port from vlan immediate.

Example

The following example specifies that set port gvrp vlan-creation-forbid test.

```
Switch(config)#interface gi1
Switch(config-if)# gvrp vlan-creation-forbid
Switch(config-if)#exit
Switch# show gvrp configuration interfaces gi1
Port | GVRP-Status | Registration | Dynamic VLAN Creation
-----+-----+-----+-----
gi1 Enabled Normal Enabled
```

clear gvrp statistics

Syntax **clear gvrp (error-statistics | statistics) [interfaces IF_PORTS]**

Parameter (error-statistics | statistics) [interfaces

Error-statistics: error gvrp packet statistics

Statistics: gvrp event message statistics Specifies posts to clear statistics

IF_PORTS]

Default none

Mode Privileged EXEC

Usage This command will clear the ports error statistics or statistics info.

Example

The following example specifies that clear gvrp error statistics and statistics test.

```
Switch# clear gvrp statistics
Switch# clear gvrp error-statistics
```

show gvrp statistics

Syntax `show gvrp (statistics | error-statistics) [interfaces IF_PORTS]`

Parameter none Display all ports
(statistics| error- statistics) [interfaces

statistics – GVRP statistics

error-statistics GVRP error statistics Specifies posts
[IF_PORTS]

Default Display all ports statistics info

Mode Privileged EXEC

Usage This command will display the ports error statistics or statistics info.

Example The following example specifies that display gvrp error statistics and statistics test.

```
Switch# show gvrp statistics
```

```
Port id : fa1
```

```
Total RX : 0 JoinEmpty RX : 0 JoinIn RX : 0
```

```
Empty RX : 0 LeaveIn RX : 0 LeaveEmpty RX : 0 LeaveAll RX : 0 Total TX : 0
```

```
JoinEmpty TX : 0 JoinIn TX : 0
```

```
Empty TX : 0 LeaveIn TX : 0 LeaveEmpty TX : 0 LeaveAll TX : 0
```

```
Port id : fa2
```

```
Total RX : 0 JoinEmpty RX : 0 JoinIn RX : 0
```

```
Empty RX : 0 LeaveIn RX : 0 LeaveEmpty RX : 0 LeaveAll RX : 0 Total TX : 0
```

```
...
```

```
Switch# show gvrp error-statistics
```

```
INVPROT : Invalid protocoal Id
```

```
INVATYP : Invalid Attribute Type INVALEN : Invalid Attribute Length
```

```
INVAVAL : Invalid Attribute Value INVEVENT: Invalid Event
```

```
Port | INVPROT | INVATYP | INVALEN | INVAVAL | INVEVENT gi1 0 0 0 0  
0
```

```
gi2 0 0 0 0 0
```

```
gi3 0 0 0 0 0
```

```
gi4 0 0 0 0 0
```

```
gi5 0 0 0 0 0
```

```
gi6 0 0 0 0 0
```

show gvrp

Syntax show gvrp

Parameter none

Default None

Mode Privileged EXEC

Usage This command will display the gvrp global info.

Example The following example specifies that display gvrp test. Switch# **show gvrp**
GVRP Status

GVRP : Disabled
Join time : 200 ms
Leave time : 600 ms
LeaveAll time : 10000 ms

show gvrp configuration

Syntax show gvrp configuration [interface IF_PORTS]

Parameter none Display all ports configuration
[interfaces Display Specifies posts configuration
IF_PORTS]

Default Display all ports configuration info

Mode Privileged EXEC

Usage This command will display the ports configuration info.

Example

The following example specifies that display gvrp port configuration test. Switch#

show gvrp configuration

Port | GVRP-Status | Registration | Dynamic VLAN Creation

-----+-----+-----+-----

gi1 Disabled Normal Enabled gi 2 Disabled Normal Enabled

gi 3	Disabled	Normal	Enabled
gi 4	Disabled	Normal	Enabled
gi 5	Disabled	Normal	Enabled
gi 6	Disabled	Normal	Enabled
gi 7	Disabled	Normal	Enabled

--More--

IGMP Snooping

ip igmp snooping

Syntax ip igmp snooping no ip igmp snooping

Parameter	None
------------------	------

Default	Default is enabled
----------------	--------------------

Mode	Global Configuration
-------------	----------------------

Usage Use the **ip igmp snooping** command to enable IGMP snooping function. Use the **no** form of this command to disable. You can verify settings by the **show ip igmp snooping** command.

Example

The following example specifies that set ip igmp snooping test. Switch(config)#

no ip igmp snooping

ip igmp snooping report-suppression

**Syntax ip igmp snooping report-suppression
_no ip igmp snooping report-suppression**

Parameter	None
------------------	------

Default	Default is enabled
----------------	--------------------

Mode Global Configuration

Usage Use the **ip igmp snooping report-suppression** command to enable IGMP snooping report-suppression function.

Use the **no** form of this command to disable. Disable report-suppression will forward all received reports to the vlan router ports.

You can verify settings by the **show ip igmp snooping** command.

Example The following example specifies that disable ip igmp snooping report-suppression test.

ip igmp snooping version

Syntax ip igmp snooping version (2|3)

Parameter (2|3) IGMP version 2 or IGMP version 3 basic mode

Default Default is version 2

Mode Global Configuration

Usage Use the **ip igmp snooping version** command to change IGMP support version. Only basic mode is supported in v3. When change version from v3 to v2, all querier version will update to version 2.

You can verify settings by the **show ip igmp snooping** command.

Example The following example specifies that set ip igmp snooping version 3.
Switch(config)# **ip igmp snooping version 3**

ip igmp snooping unknown-multicast action

Syntax ip igmp snooping unknown-multicast action (drop | flood |router-port)

_no ip igmp snooping unknown-multicast action

Parameter (drop | flood | router- port) Drop 、 flood in vlan or forward to router port of unknown multicast packet

Default Default is flood.

Mode Global Configuration

Usage When igmp and mld snooping disabled, it can't set action router-port.

When disable igmp snooping & mld snooping, it set unknown multicast action flood. When action is router-port to flood or drop, it will delete the unknown multicast group entry.

Use the **ip igmp snooping unknown-multicast action** command to change action.

Use the **no** form of this command to restore to default.

You can verify settings by the **show ip igmp snooping** command.

Example The following example specifies that set ip igmp unknown multicast action router-port test.

```
Switch(config)# ip igmp snooping
Switch(config)# ip igmp snooping unknown-multicast action router-port
```

ip igmp snooping querier

Syntax **ip igmp snooping vlan <VLAN-LIST> querier [version (2|3)]**
no ip igmp snooping [vlan <VLAN-LIST>] querier

Parameter	VLAN-LIST	specifies VLAN ID list to set
	(2 3)	Query version 2 or 3

Default No ip igmp snooping querier by default

Mode Global Configuration

Usage When enable ip igmp vlan querier, there will process router select, the select successful will send general and specific query.

Use the **ip igmp snooping querier** command to add querier. Use the **no** form of this command to delete querier.

You can verify settings by the **show ip igmp snooping querier** command.

Example The following example specifies that set ip igmp snooping querier test.

```
Switch(config)# ip igmp snooping vlan 2 querier version 3
```

ip igmp snooping vlan

Syntax **ip igmp snooping vlan VLAN-LIST**

no ip igmp snooping vlan VLAN-LIST

Parameter	VLAN-LIST	specifies VLAN ID list to set
-----------	-----------	-------------------------------

Default Default is disabled for all VLANs

Mode Global Configuration

Usage Disable will clear all ip igmp snooping dynamic group and dynamic router port and make all static ip igmp group invalid of this vlan. Will not learn dynamic group and router port by igmp message any more.
Use the **ip igmp snooping vlan** command to enable IGMP on VLAN. Use the **no** form of this command to disable
You can verify settings by the **show ip igmp snooping vlan** command.

Example The following example specifies that set ip igmp snooping vlan test.

```
Switch(config)# ip igmp snooping
Switch(config)# ip igmp snooping vlan 2
```

ip igmp snooping vlan fastleave

Syntax **ip igmp snooping vlan <VLAN-LIST> fastleave**
_no ip igmp snooping vlan <VLAN-LIST> fastleave

Parameter VLAN-LIST specifies VLAN ID list to set

Default Default is disabled

Mode Global Configuration

Usage Use the **ip igmp snooping vlan fastleave** command to enable fastleave function. Group will remove port immediately when receive leave packet. Use the **no** form of this command to disable.
You can verify settings by the **show ip igmp snooping vlan** command

Example The following example specifies that set ip igmp snooping vlan **fastleave** test.
Switch(config)# **ip igmp snooping vlan 1 fastleave**

ip igmp snooping vlan last-member-query-count

Syntax **ip igmp snooping vlan <VLAN-LIST> last-member-query-count <1-7>**
no ip igmp snooping vlan <VLAN-LIST> last-member-query-count

Parameter VLAN-LIST specifies VLAN ID list to set

last-member-query-count <1-7> specifies last member query count to set.

Default Default is 2

Mode Global Configuration

Usage Use the **ip igmp snooping vlan last-member-query-count** command to change how many query packets will send.

Use the **no** form of this command to restore to default.

You can verify settings by the **show ip igmp snooping vlan** command

Example The following example specifies that set **ip igmp snooping vlan last-member-query-count** test.
Switch(config)# **ip igmp snooping vlan 1 last-member-query-count 5**

ip igmp snooping vlan last-member-query-interval

Syntax **ip igmp snooping vlan <VLAN-LIST> last-member-query-interval <1- 60>**

no ip igmp snooping vlan <VLAN-LIST> last-member-query-interval

Parameter VLAN-LIST specifies VLAN ID list to set

last-member-query-interval <1-60> specifies last member query interval to set

Default Default is 1

Mode Global Configuration

Usage Use the **ip igmp snooping vlan last-member-query-interval** command to set interval between each query packet.

Use the **no** form of this command to restore to default

You can verify settings by the **show ip igmp snooping vlan** command

Example

The following example specifies that set **ip igmp snooping vlan last-member-query-interval** test.

```
Switch(config)# ip igmp snooping vlan 1 last-member-query-interval 3
```

ip igmp snooping vlan query-interval

Syntax

```
ip igmp snooping vlan <VLAN-LIST> query-interval <30-18000>
no ip igmp snooping vlan <VLAN-LIST> query-interval
```

Parameter VLAN-LIST specifies VLAN ID list to set

query-interval <30-18000> specifies query interval to set

Default

Default is 125

Mode

Global Configuration

Usage Use the **ip igmp snooping vlan query-interval** command to set interval between each query.

Use the **no** form of this command to restore to default

You can verify settings by the **show ip igmp snooping vlan** command

Example

The following example specifies that set **ip igmp snooping vlan query-interval** test.

```
Switch(config)# ip igmp snooping vlan 1 query-interval 100
```

ip igmp snooping vlan response-time

Syntax

```
ip igmp snooping vlan <VLAN-LIST> response-time <5-20>
no ip igmp snooping vlan <VLAN-LIST> response-time
```

Parameter

VLAN-LIST specifies VLAN ID list to set

response-time <5-20> specifies a response time to set

Default

Default is 10

Mode

Global Configuration

Usage Use the **ip igmp snooping vlan response-time** command to set response time
 Use the **no** form of this command to restore to default.
 You can verify settings by the **show ip igmp snooping vlan** command

Example The following example specifies that set **ip igmp snooping vlan response-time** test.
 Switch(config)# **ip igmp snooping vlan 1 response-time 12**

ip igmp snooping vlan robustness-variable

Syntax **ip igmp snooping vlan <VLAN-LIST> robustness-variable <1-7>**
no ip igmp snooping vlan <VLAN-LIST> robustness-variable

Parameter **VLAN-LIST** specifies VLAN ID list to set
robustness-variable specifies a robustness value to set
<1-7>

Default Default is 2

Mode Global Configuration

Usage Use the **ip igmp snooping vlan robustness-variable** command to times to retry.
 Use the **no** form of this command to restore to default
 You can verify settings by the **show ip igmp snooping vlan** command

Example The following example specifies that set ip igmp snooping vlan parameters test.
 Switch(config)# **ip igmp snooping vlan 1 robustness-variable**

ip igmp snooping vlan router

Syntax **ip igmp snooping vlan VLAN-LIST router learn pim-dvmrp**
_no ip igmp snooping vlan VLAN-LIST router learn pim-dvmrp

Parameter **VLAN-LIST** specifies VLAN ID list to set

Default Default is enabled

Mode Global Configuration

Usage Use the **ip igmp snooping vlan router** command to enable learning router port by routing protocol packets such as PIM/PIMv2, DVMRP, MOSPF. Use the **no** form of this command to disable. You can verify settings by the **show ip igmp snooping vlan** command

Example The following example specifies that set **ip igmp snooping vlan router test**.
Switch(config)# **ip igmp snooping vlan 99 router**

ip igmp snooping vlan forbidden-port

Syntax **ip igmp snooping vlan <VLAN-LIST> forbidden-port IF_PORTS**
no ip igmp snooping vlan <VLAN-LIST> forbidden-port IF_PORTS

Parameter	VLAN-LIST	specifies VLAN ID list to set
	IF_PORTS	specifies a port list to set or remove

Default No forbidden ports by default

Mode Global Configuration

Usage ‘ip igmp snooping vlan 1 static-port gi1-2’ will add static port gi1-2 for vlan 1.the all known vlan 1 ipv4 group will add the static ports.
‘ip igmp snooping vlan 1 forbidden-port gi3-4’ will add forbidden port gi3-4 for vlan 1.the all known vlan 1 ipv4 group will remove the forbidden ports. The configure can use ‘show ip igmp snooping forward-all’.

Use the **ip igmp snooping vlan forbidden-port** command to add static non-forwarding port, all known vlan 1 ipv4 group will remove the forbidden ports. Use the **no** form of this command to delete forbidden port.
You can verify settings by the **show ip igmp snooping forward-all** command.

Example The following example specifies that set ip igmp snooping static/forbidden port test.
Switch(config)# **ip igmp snooping vlan 1 forbidden -port gi3-4**

ip igmp snooping vlan static-port

Syntax **ip igmp snooping vlan <VLAN-LIST> static-port IF_PORTS**
_no ip igmp snooping vlan <VLAN-LIST> static-port IF_PORTS

Parameter	VLAN-LIST	specifies VLAN ID list to set
	IF_PORTS	specifies a port list to set or remove

Default No static port by default

Mode Global Configuration

Usage

Use the **ip igmp snooping vlan static-port** command to add static forwarding port, all known vlan 1 ipv4 group will add the static ports.
 Use the **no** form of this command to delete static port.
 You can verify settings by the **show ip igmp snooping forward-all** command.

Example The following example specifies that set ip igmp snooping static port test.
 Switch(config)# **ip igmp snooping vlan 1 static -port gi1-2**

ip igmp snooping vlan forbidden-router-port

Syntax **ip igmp snooping vlan <VLAN-LIST> forbidden-router-port IF_PORTS**
no ip igmp snooping vlan <VLAN-LIST> forbidden-router-port
_IF_PORTS

Parameter	VLAN-LIST	specifies VLAN ID list to set
	IF_PORTS	specifies a port list to set or remove

Default No forbidden router ports by default

Mode Global Configuration

Usage Use the **ip igmp snooping vlan forbidden-router-port** command to add static forbidden router port. This will also remove port from static router port. The forbidden router port will not forward received query packet
 .Use the **no** form of this command to delete forbidden router port.
 You can verify settings by the **show ip igmp snooping router** command.

Example The following example specifies that set ip igmp snooping forbidden test.
 Switch(config)# **ip igmp snooping vlan 1 forbidden-router-port gi2**

Parameter	VLAN-LIST	specifies VLAN ID list to set
	IF_PORTS	specifies a port list to set or remove

**ip
igmp**

snooping vlan static-router-port

Syntax `ip igmp snooping vlan <VLAN-LIST> static-router-port IF_PORTS`
`no ip igmp snooping vlan <VLAN-LIST> static-router-port IF_PORTS`

Default No static router ports by default

Mode Global Configuration

Usage Use the **ip igmp snooping vlan static-router-port** command to add static router port. All query packets will forward to this port.
 Use the **no** form of this command to delete static router port.
 You can verify settings by the **show ip igmp snooping router** command.

Example The following example specifies that set ip igmp snooping static test.
 Switch(config)# **ip igmp snooping vlan 1 static-router-port gi1-2**

ip igmp snooping vlan static-group

Syntax `ip igmp snooping vlan <VLAN-LIST> static-group [<ip-addr>] interfaces IF_PORTS`
`no ip igmp snooping vlan <VLAN-LIST> static-group <ip-addr> interfaces IF_PORTS`

Parameter	VLAN-LIST	specifies VLAN ID list to set
------------------	-----------	-------------------------------

	ip-addr	specifies multicast group ipv4 address
--	---------	--

	IF_PORTS	specifies port list to set or remove
--	----------	--------------------------------------

Default No static group by default

Mode Global Configuration

Usage Use the **ip igmp snooping vlan static-group** command to add a static group. The static group will not learn other dynamic ports. If the dynamic group exists, then the static group will overlap

the dynamic group. The static group set to valid unless igmp snooping global and vlan enable.

Use the **no** form of this command to delete a port in static group. If remove the last member of static group, the static group will be delete.

You can verify settings by the **show ip igmp snooping group** command.

Example

The following example specifies that set ip igmp snooping static group test.
Switch(config)# **ip igmp snooping vlan 1 static-group 224.1.1.1 interfaces gi1-2**

ip igmp snooping vlan group

Syntax **no ip igmp snooping vlan <VLAN-LIST> group <ip-addr>**

Parameter	VLAN-LIST	specifies VLAN ID list to set
	ip-addr	specifies multicast group ipv4 address

Default None

Mode Global Configuration

Usage Use the **no ip igmp snooping vlan group** command to delete a group which could be static or dynamic. You can verify settings by the **show ip igmp snooping group** command.

Example

The following example specifies that set ip igmp snooping static group test.
Switch(config)# **no ip igmp snooping vlan 1 group 224.1.1.1**

profile range

Syntax **profile range ip <ip-addr> [ip-addr] action (permit | deny)**

<ip-addr>	Start ipv4 multicast address
[ip-addr]	End ipv4 multicast address
(permit deny)	Permit: allow Multicast address range ip address learning deny: do not allow Multicast address range ip address <u>learning</u>

Default None

Mode igmp profile configuration mode

Usage Use the **profile** command to generate IGMP profile.
You can verify settings by the **show ip igmp profile** command

Example The following example specifies that set ip igmp profile test. Switch(config)# **ip igmp profile 1**
Switch(config-igmp-profile)# **profile range ip 224.1.1.1 224.1.1.8 action permit**

ip igmp profile

Syntax **ip igmp profile <1-128>**
no ip igmp profile <1-128>

Parameter <1-128> specifies profile ID

Default No profile exist by default

Mode Global Configuration

Usage Use the **ip igmp profile** command to enter profile configuration
Use the **no** form of this command to delete profile
You can verify settings by the **show ip igmp profile** command

Example The following example specifies that set ip igmp profile test. Switch(config)# **ip igmp profile 1**

ip igmp filter

Syntax **ip igmp filter <1-128>**
[no] ip igmp filter

Parameter <1-128> specifies profile ID

Default None

Mode Port Configuration

Usage Use the **ip igmp filter** command to bind a profile for port. When the port bind a profile. Then the port learning group will update, if the group is not match the profile rule it will remove the port from the group. Static group is excluded.

Use the **no** form of this command to delete profile

You can verify settings by the **show ip igmp filter** command

Example The following example specifies that set ip igmp filter test.

```
Switch(config)# interface gi1
Switch(config-if)#ip igmp filter 1
```

ip igmp max-groups

Syntax **ip igmp max-groups <0-1024>**
no ip igmp max-groups

Parameter <0-1024> The maximum number of IGMP groups that an interface can join.

Default Default is 1024

Mode Port Configuration

Usage Use the **ip igmp max-groups** command to limit port learning max group number. When the port has reach limitation, new group will not add this port. Static group is excluded.

Use the **no** form of this command to restore to default

You can verify settings by the **show ip igmp max-groups** command.

Example The following example specifies that set ip igmp max-groups test. Switch(config-if)#**ip igmp max-groups 10**

ip igmp max-groups action

Syntax `ip igmp max-groups action (deny | replace)`

Parameter (deny | replace) Deny: current port igmp group arrived max-groups, don't add group.
 Replace: current port igmp group arrived max-groups, remove port for rand group, and add port to new group.

Default Default action is deny

Mode Port Configuration

Usage Use the **ip igmp max-groups action** command to set the action when the numbers of groups reach the limitation.

Use the **no** form of this command to restore to default

You can verify settings by the **show ip igmp max-groups** command.

Example The following example specifies that set action replace test. Switch(config-if)#**ip igmp max-groups action replace**

clear ip igmp snooping groups

Syntax `clear ip igmp snooping groups [(dynamic | static)]`

Parameter none Clear ip igmp groups include dynamic and static
(dynamic | static) Ip igmp group type is dynamic or static

Default None

Mode Privileged EXEC

Usage This command will clear the ip igmp groups for dynamic or static or all of type. You can verify settings by the **show ip igmp snooping groups** command.

Example

The following example specifies that clear ip igmp snooping groups test.

```
Switch# clear ip igmp snooping groups
Switch# show ip igmp snooping groups
VLAN | Group IP Address | Type | Life(Sec) | Port
-----+-----+-----+-----+-----

Total Number of Entry = 0
```

clear ip igmp snooping statistics

Syntax clear ip igmp snooping statistics

Parameter

none

Default

None

Mode

Privileged EXEC

Usage

This command will clear the igmp statistics.
You can verify settings by the **show ip igmp snooping** command.

Example

The following example specifies that clear ip igmp snooping statistics test.

```
Switch# clear ip igmp snooping statistics
Switch# show ip igmp snooping
IGMP Snooping Status
-----

Snooping : Enabled Report Suppression : Enabled
Operation Version : v2
Forward Method : mac Unknown IP Multicast Action : Flood

Packet Statistics
Total RX : 0
Valid RX : 0
Invalid RX : 0
Other RX : 0
Leave RX : 0
Report RX : 0
General Query RX : 0 Specail Group Query RX : 0 Specail Group & Source
Query RX : 0 Leave TX : 0
Report TX : 0
General Query TX : 0 Specail Group Query TX : 0
Specail Group & Source Query TX : 0
```

show ip igmp snooping groups counters

Syntax show ip igmp snooping groups

Parameter none

Default none

Mode Privileged EXEC

Usage This command will display the ip igmp group counter include static group.

Example The following example specifies that display ip igmp snooping group counter test.
Switch# show ip igmp snooping group counters

Total ip igmp snooping group number: 2
 Total ip igmp snooping static mac number: 0

show ip igmp snooping groups

Syntax show ip igmp snooping groups [(dynamic | static)]

Parameter none Show ip igmp groups include dynamic and static
 (dynamic | static) Display Ip igmp group type is dynamic or static

Default None

Mode Privileged EXEC

Usage This command will display the ip igmp groups for dynamic or static or all of type.

Example

The following example specifies that show ip igmp snooping groups. Switch#

```

show ip igmp snooping groups
VLAN | Group IP Address | Type | Life(Sec) | Port
-----+-----+-----+-----+-----
1 | 224.1.2.3 | Static | -- | fa9
1 | 224.1.2.4 | Static | -- | fa10

Total Number of Entry = 2
    
```

show ip igmp snooping router

Syntax

```
show ip igmp snooping router [(dynamic | forbidden |static )]
```

Parameter

none	Show ip igmp router include dynamic and static and forbidden
(dynamic forbidden static)	Display Ip igmp router info for different type

Default

None

Mode

Privileged EXEC

Usage

This command will display the ip igmp router info.

Example

The following example specifies that show ip igmp snooping router.

```

Switch# show ip igmp snooping router
Dynamic Router Table
VID | Port | Expiry Time(Sec)
-----+-----+-----

Total Entry 0

Static Router Table VID | Port Mask
-----+-----+-----
1 | fa4

Total Entry 1

Forbidden Router Table VID | Port Mask
-----+-----+-----
1 | fa8

Total Entry 1
    
```

show ip igmp snooping querier

Syntax show ip igmp snooping querier

Parameter none Show all vlan ip igmp querier info.

Default None

Mode Privileged EXEC

Usage This command will display all of the static vlan ip igmp querier info.

Example The following example specifies that show ip igmp snooping querier test. Switch#

```

show ip igmp snooping querier
VID | State | Status | Version | Querier IP
-----+-----+-----+-----+-----
1 | Disabled | Non-Querier | No | -----

Total Entry 1

```

show ip igmp snooping

Syntax show ip igmp snooping

Parameter None

Default None

Mode Privileged EXEC

Usage This command will display ip igmp snooping global info.

Example

The following example specifies that show ip igmp snooping test. Switch# **show ip igmp snooping**
 IGMP Snooping Status

Snooping : Enabled Report Suppression : Enabled
 Operation Version : v2
 Forward Method : mac Unknown Multicast Action : Flood

Packet Statistics

Total RX : 0
 Valid RX : 0
 Invalid RX : 0
 Other RX : 0
 Leave RX : 0
 Report RX : 0
 General Query RX : 0 Specail Group Query RX : 0 Specail Group & Source Query
 RX : 0 Leave TX : 0

Report TX : 0
 General Query TX : 0 Specail Group Query TX : 0
 Specail Group & Source Query TX : 0

show ip igmp snooping vlan

Syntax **show ip igmp snooping vlan [VLAN-LIST]**

Parameter none Show all ip igmp snooping vlan info
 [VLAN-LIST] Show specifies vlan ip igmp snooping info

Default None

Mode Privileged EXEC

Usage This command will display ip igmp snooping vlan info.

Example

The following example specifies that show ip igmp snooping vlan test. Switch#
show ip igmp snooping vlan 1
 IGMP Snooping is globally enabled
 IGMP Snooping VLAN 1 admin : disabled IGMP Snooping operation mode :
 disabled IGMP Snooping robustness: admin 2 oper 2
 IGMP Snooping query interval: admin 125 sec oper 125 sec IGMP Snooping
 query max response : admin 10 sec oper 10 sec IGMP Snooping last member
 query counter: admin 2 oper 2
 IGMP Snooping last member query interval: admin 1 sec oper 1 sec IGMP
 Snooping last immediate leave: disabled
IGMP Snooping automatic learning of multicast router ports: enabled

show ip igmp snooping forward-all

Syntax	show ip igmp snooping forward-all [vlan VLAN-LIST]
Parameter	none Show all ip igmp snooping vlan forward-all info <u>[vlan VLAN-LIST] Show specifies vlan of ip igmp forward info.</u>

Default	None
----------------	------

Mode	Privileged EXEC
-------------	-----------------

Usage	This command will display ip igmp snooping forward all info.
--------------	--

Example

The following example specifies that show ip igmp snooping forward-all test. Switch#
show ip igmp snooping forward-all 1
 IGMP Snooping VLAN 1
 IGMP Snooping static port : None
IGMP Snooping forbidden port : None

show ip igmp profile

Syntax	show ip igmp profile [<1-128>]
Parameter	none Show all ip igmp snooping profile info <u>[<1-128>] Show specifies index profile info</u>

Default	None
----------------	------

Mode	Privileged EXEC
-------------	-----------------

Usage	This command will display ip igmp profile info.
--------------	---

Example

The following example specifies that show ip igmp profile test. Switch# **show ip igmp profile**
 IP igmp profile index: 1
 IP igmp profile action: permit Range low ip: 224.1.1.1 Range high ip: 224.1.1.8

IP igmp profile index: 2
 IP igmp profile action: deny Range low ip: 225.1.1.0
Range high ip: 225.1.2.1

show ip igmp filter

Syntax show ip igmp filter [interfaces IF_PORTS]

Parameter	none	Show all port filter
-----------	------	----------------------

[interfaces IF_PORTS]	Show specifies ports filter
-----------------------	-----------------------------

Default None

Mode Privileged EXEC

Usage This command will display ip igmp port filter info.

Example

The following example specifies that show ip igmp filter test. Switch# **show ip igmp filter**
 Port ID | Profile ID
 -----+-----
 gi1 : 1
 gi2 : None gi3 : None gi4 : None gi5 : None
--More--

show ip igmp max-group

Syntax show ip igmp max-group [interfaces IF_PORTS]

Parameter	none	Show all port max-group
[interfaces IF_PORTS]	Show specifies ports max-group	

Default None

Mode Privileged EXEC

Usage This command will display ip igmp port max-group.

Example The following example specifies that show ip igmp max-group test.

```
Switch(config-if)#ip igmp max-groups 50
Switch# show ip igmp max-group
```

Port ID | Max Group

```
-----+-----
gi1 : 50
gi2 : 256
gi3 : 256
gi4 : 256
gi5 : 256
--More--
```

show ip igmp max-group action

Syntax **show ip igmp max-group action [interfaces IF_PORTS]**

Parameter

none	Show all port max-group action
[interfaces IF_PORTS]	Show specifies ports max-group action

Default None

Mode Privileged EXEC

Usage This command will display ip igmp port max-group action.

Example

The following example specifies that show ip igmp max-group action test.

```
Switch(config)#interface gi1
Switch(config-if)#ip igmp max-groups action replace
Switch# show ip igmp max-group action
Port ID | Max-groups Action
-----+-----
gi1 : replace gi2 : deny gi3 : deny gi4 : deny gi5 : deny
--More--
```

IP Source Guard

ip source verify

Syntax **ip source verify [mac-and-ip] no ip source verify**

Parameter	mac-and-ip	Verify by mac and ip address boundle
-----------	------------	--------------------------------------

Default	IP Source Guard is disabled on interface. Default is that verifying ip address only
---------	---

Mode	Port Configuration
------	--------------------

Usage Use the **ip source verify** command to enable IP Source Guard function. Default IP Source Guard filter source IP address. The “**mac-and-ip**” filters not only source IP address but also source MAC address.
Use the **no** form of this command to disable.
You can verify settings by the **show ip source interfaces** command.

Example

The example shows how to enable IP Source Guard with source IP address filtering on interface gi1.

```
Switch(config)# interface gi1
switch(config-if)# ip source verify
```

The example shows how to enable IP Source Guard with source IP and MAC address filtering on interface gi2.

```
Switch(config)# interface gi2
switch(config-if)# ip source verify mac-and-ip switch(config-if)# do show ip source interfaces gi1-2 Port | Status | Max Entry | Current Entry
```

```
-----+-----+-----+-----
gi1 | Verify MAC+IP | No Limit | 0 gi2 | disabled | No Limit | 0
```

ip source binding

Syntax

```
ip source binding A:B:C:D:E:F vlan <1-4094> A.B.C.D interface
IF_PORT
no ip source binding A:B:C:D:E:F vlan <1-4094> A.B.C.D interface
IF_PORT
```

Parameter	A:B:C:D:E:F	Specify a MAC address of a binding entry
Default	Default VLAN ID is 1.	Specify a VLAN ID of a binding entry
	A.B.C.D	Specify IP address and MASK of a binding entry.
	IF_PORT	Specify interface of a binding entry.

Mode Global Configuration

Usage Use the **ip source binding** command to create a static IP source binding entry has an IP address, its associated MAC address 、 VLAN ID 、 interface.
Use the **no** form of this command to delete static entry.
You can verify settings by the **show ip source binding** command.

Example The example shows how to add a static IP source binding entry. Switch(config)#
ip source binding 00:11:22:33:44:55 vlan 1 192.168.1.55 interface fa1
 switch(config)# **do show ip source binding**
 Bind Table: Maximun Binding Entry Number 192
 Port | VID | MAC Address | IP | Type | Lease Time
 -----+-----+-----+-----+-----+-----
 fa1 | 1 | 00:11:22:33:44:55 | 192.168.1.55(255.255.255.255) | Static | NA

show ip source interface

Syntax show ip source interfaces IF_PORTS

Parameter IF_PORTS specifies ports to show

Default No default is defined

Mode Privileged EXEC

Usage Use the **show ip source interface** command to show settings of IP Source Guard of interface

Example

The example shows how to show settings of IP Source Guard of interface gi1

```
switch# show ip source interfaces gi1
Port | Status | Max Entry | Current Entry
-----+-----+-----+-----
gi1 | Verify MAC+IP | No Limit | 0
```

show ip source binding

Syntax

show ip source binding [(dynamic|static)]

Parameter

dynamic	Show entries that added by DHCP snooping learn
static	Show entries that added by user

Default

No default is defined

Mode

Privileged EXEC

Usage

Use the **show ip source binding** command to show binding entries of IP Source Guard.

Example

The example shows how to show static binding entries of IP Source Guard.

```
switch# show ip source binding
Bind Table: Maximun Binding Entry Number 192
Port | VID | MAC Address | IP | Type | Lease Time
-----+-----+-----+-----+-----+-----
fa1 | 1 | 00:11:22:33:44:55 | 192.168.1.55(255.255.255.255) | Static | NA
```

Link Aggregation

lag

Syntax

lag <1-8> mode (static | active | passive)
no lag

Parameter <1-8> Specify the LAG id for the interface

static Specify the LAG to be static mode and join the interface into this LAG.

active Specify the LAG to be dynamic mode and join the interface into this LAG with LACP active port.

passive Specify the LAG to be dynamic mode and join the interface into this LAG with LACP passive port.

Default

There is no LAG in default.

Mode Interface Configuration

Usage Link aggregation group function allows you to aggregate multiple physical ports into one logic port to increase bandwidth. This command makes normal port join into the specific LAG logic port with static or dynamic mode. And use “**no lag**” to leave the LAG logic port.

Example

This example shows how to create a dynamic LAG and join fa1-fa3 to this LAG.
 Switch(config)# **interface range fa1-3**
 Switch(config-if)# **lag 1 mode active**

This example shows how to show current LAG status.
 Switch# **show lag**
 Load Balancing: src-dst-mac-ip.

```

Group ID | Type | Ports
-----+-----+-----
1 | LACP | Inactive: fa1-3 2 | ----- |
3 | ----- |
4 | ----- |
5 | ----- |
6 | ----- |
7 | ----- |
8 | ----- |
  
```

lag load-balance

Syntax **lag load-balance (src-dst-mac | src-dst-mac-ip)**
no lag load-balance

Parameter src-dst-mac Specify algorithm to balance traffic by using source and destination MAC address for all packets.

src-dst-mac-ip Specify algorithm to balance traffic by using source and destination IP address for IP packets and using source and destination MAC address for non-IP packets.

Default Default load balance algorithm is src-dst-mac

Mode Global Configuration

Usage Link aggregation group port should transmit packets spread to all ports to balance traffic loading. There are two algorithm supported and this command allow you to select the algorithm.

Example

This example shows how to change load balance algorithm to src-dst-mac-ip.
 Switch(config)# **lag load-balance src-dst-mac-ip**

This example shows how to show current load balance algorithm.

```
Switch# show lag
Load Balancing: src-dst-mac-ip.
```

```
Group ID | Type | Ports
-----+-----+-----
1 | ----- |
2 | ----- |
3 | ----- |
4 | ----- |
5 | ----- |
6 | ----- |
7 | ----- |
8 | ----- |
```

lacp port-priority

Syntax lacp port-priority <1-65535>
no lacp port-priority

Parameter	<1-65535>	Specify port priority value
------------------	-----------	-----------------------------

Default	Default port priority is 1.
----------------	-----------------------------

Mode	Interface Configuration
-------------	-------------------------

Usage LACP port priority is used for two connected DUT to select aggregation ports. Lower port priority value has higher priority. And the port with higher priority will be selected into LAG first.

The only way to show this configuration is using “**show running-config**” command.

Example

This example shows how to configure interface fa1 lacp port priority to 100.

```
Switch(config)# interface fa1
Switch(config-if)# lacp port-priority 100
```

lacp system-priority

Syntax lacp system-priority <1-65535>
no lacp system-priority

Parameter	<1-65535>	Specify system priority value
------------------	-----------	-------------------------------

Default	Default system priority is 32768.
----------------	-----------------------------------

Mode	Global Configuration
-------------	----------------------

Usage LACP system priority is used for two connected DUT to select master switch. Lower system priority value has higher priority. And the DUT with higher priority can decide which ports are able to join the LAG.

Use “**no lacp system-priority**” to restore to the default priority value. The only way to show this configuration is using “**show running-config**” command.

Example	This example shows how to configure lacp system priority to 1000. Switch(config)# lacp system-priority 1000
----------------	---

lacp timeout

Syntax	lacp timeout (long short) no lacp timeout
---------------	--

Parameter	long	Send LACP packet every 30 seconds.
	short	Send LACP packet every 1 second.

Default	Default LACP timeout is long.
----------------	-------------------------------

Mode	Interface Configuration
-------------	-------------------------

Usage LACP need to send LACP packet to partner switch to check the link status. This command configure the interval of sending LACP packets.

The only way to show this configuration is using “**show running-config**” command.

Example	This example shows how to configure interface fa1 lacp timeout to short. Switch(config)# interface fa1 Switch(config-if)# lacp timeout short
----------------	--

show lacp

Syntax	show lacp sys-id
---------------	-------------------------

show lacp [**<1-8>**] **counters**
show lacp [**<1-8>**] (**internal** | **neighbor**) [**detail**]

Parameter	
------------------	--

Default No default values for this command.

Mode Privileged EXEC

Usage Use “**show lacp sys-id**” command to displays the system identifier that is being used by LACP. The system identifier is made up of the LACP system priority and the switch MAC address.

Use “**show lacp counter**” command to display LACP statistic information. Use “**show lacp internal**” command to display local information.

Use “**show lacp neighbor**” command to display remote information.

State of the specific port. These are the allowed values:

---Port is in an unknown state.

bndl—Port is attached to an aggregator and bundled with other ports.

susp—Port is in a suspended state; it is not attached to any aggregator.

hot-sby—Port is in a hot-standby state.

lndiv—Port is incapable of bundling with any other port.

lndep—Port is in an independent state (not bundled but able to switch data traffic. In this case, LACP is not running on the partner port).

down—Port is down.

State variables for the port, encoded as individual bits within a single octet with these meanings:

bit0—LACP_Activity

bit1—LACP_Timeout

bit2—Aggregation

bit3—Synchronization

bit4—Collecting

bit5—Distributing

bit6—Defaulted

bit7—Expired

Example

This example shows how to show LACP statistics.

```
Switch# show lacp counters
LACPDU  LACPDU
Port Sent Recv Pkts Err
```

```
-----
Channel group 1
          fa1      0      0      0
          fa2      0      0      0
```

This example shows how to show LACP local information.

Switch# **show lacp internal**

Flags: S - Device is requesting Slow LACPDUs F - Device is requesting Fast LACPDUs
 A - Device is in Active mode P - Device is in Passive mode

Channel group 1

Port Port

LACP port Admin Oper

Port Flags State Priority Key Key Number State

fa1 SA down 1 0x3e8 0x3e8 0x1 0x45

fa2 SA down 1 0x3e8 0x3e8 0x2 0x45

This example shows how to show LACP remote information.

Switch# **show lacp neighbor**

Flags: S - Device is sending Slow LACPDUs F - Device is sending Fast LACPDUs
 A - Device is in Active mode P - Device is in Passive mode

Channel group 1 neighbors Partner's information:

LACP port Admin Oper

Port Port

LACP port Admin Oper

Port Flags State Priority Key Key Number State

fa1 SA down 1 0x3e8 0x3e8 0x1 0x45

fa2 SA down 1 0x3e8 0x3e8 0x2 0x45

This example shows how to show LACP remote information.

Switch# **show lacp neighbor**

Flags: S - Device is sending Slow LACPDUs F - Device is sending Fast LACPDUs
 A - Device is in Active mode P - Device is in Passive mode

Channel group 1 neighbors Partner's information:

LACP port Admin Oper

Port Port

show lag

```
Port Flags Priority Dev ID Age key Key Number State
fa1 FP 32768 0000.0000.0000 0s 0x3e8
0x3e8 0x1 0x56
fa2 FP 32768 0000.0000.0000 0s 0x3e8
0x3e8 0x2 0x56
```

Syntax **show lag**

Parameter

Default No default values for this command.

Mode Privileged EXEC

Usage Use “**show lag**” command to show current LAG load balance algorithm and members active/inactive status.

Example

This example shows how to show current LAG status.

```
Switch# show lag
Load Balancing: src-dst-mac-ip.
```

```
Group ID | Type | Ports
-----+-----+-----
1 | LACP | Inactive: fa1-3 2 | ----- |
3 | ----- |
4 | ----- |
5 | ----- |
6 | ----- |
7 | ----- |
8 | ----- |
```

LLDP

clear lldp statistics

Syntax clear lldp statistics

Default There is no default configuration for this command

Mode Privileged EXEC

Usage Use “clear lldp statistics” command to clear the LLDP RX/TX statistics.

Example This example shows how to clear LLDP statistics.

Switch# clear lldp statistics

lldp

Syntax lldp
no lldp

Default Default is enabled

Mode Global Configuration

Usage Use “lldp” command to enable LLDP RX/TX ability. The LLDP enable status is displayed by “show lldp” command.

Use the **no** form of this command to disable the LLDP. When LLDP is disabled, the behavior of receiving LLDP PDU would be decided by “lldp lldpdu” command.

Example

The following example sets LLDP enable/disable.

```
Switch (config)# lldp
Switch# show lldp
```

```
State: Enabled Timer: 30 Seconds
Hold multiplier: 4 Reinit delay: 2 Seconds Tx delay: 2 Seconds
LLDP packet handling: Flooding
```

```
Port | State | Optional TLVs | Address
-----+-----+-----+-----
|192.168.1.2
fa2 | RX,TX | |192.168.1.2
fa3 | RX,TX | |192.168.1.2
fa4 | RX,TX | |192.168.1.2
fa5 | RX,TX | |192.168.1.2
```

lldp rx

Syntax **lldp rx**
 no lldp rx

Default Default is enabled

Mode Port Configuration

Usage Use “**lldp rx**” command to enable the LLDP PDU RX ability. The configuration could be shown by “**show lldp**” command.

Use the **no** form of this command to disable the RX ability.

Example

This example sets port gi1 to enable LLDP TX, port gi2 to disable RX but enable TX, port gi3 to enable RX but disable TX, port gi4 to disable RX and TX.

```
Switch(config)# interface gi1
Switch(config-if)# lldp rx
```

```
Switch(config-if)# lldp tx Switch(config)# interface gi2 Switch(config-if)# no lldp rx
Switch(config-if)# lldp tx Switch(config)# interface gi3 Switch(config-if)# lldp rx
Switch(config-if)# no lldp tx Switch(config)# interface gi4 Switch(config-if)# no lldp rx
Switch(config-if)# no lldp tx Switch(config-if)# end
Switch# show lldp interfaces gi1-4
```

```
State: Enabled Timer: 30 Seconds
Hold multiplier: 4 Reinit delay: 2 Seconds Tx delay: 2 Seconds
LLDP packet handling: Bridging
```

lldp tx-interval

Port	State	Optional TLVs	Address
gi1	RX,TX		192.168.1.254
gi2	TX		192.168.1.254
gi3	RX		192.168.1.254
gi4	Disable		192.168.1.254

Syntax `lldp tx-interval <5-32768>`

`no lldp tx-interval`

Parameter	<5-32768>	Specify the LLDP PDU TX interval in unit of second.
-----------	-----------	---

Default	Default TX interval is 30 seconds
---------	-----------------------------------

Mode	Global Configuration
------	----------------------

Usage Use “`lldp tx-interval`” command to configure the LLDP TX interval. It should be noticed that both “`lldp tx-interval`” and “`lldp tx-delay`” affects the LLDP PDU TX time. The larger value of the two configurations decides the TX interval. The configuration could be shown by “`show lldp`” command.

Use the **no** form of this command to restore the interval to default value.

Example	This example sets LLDP TX interval to 10 seconds.
---------	---

```
Switch(config)# lldp tx-interval 10
Switch# show lldp
```

```
State: Disabled Timer: 10 Seconds
Hold multiplier: 4 Reinit delay: 2 Seconds Tx delay: 2 Seconds
LLDP packet handling: Flooding
```

lldp reinit-delay

Syntax `lldp reinit-delay <1-10>`

no `lldp reinit-delay`

Parameter	<code><1-10></code>	Specify the LLDP re-initial delay time in unit of <u>second.</u>
------------------	---------------------------	--

Default	Default reinital delay is 2 seconds
----------------	-------------------------------------

Mode	Global Configuration
-------------	----------------------

Usage Use “`lldp reinit-delay`” to configure the LLDP re-initial delay. This delay avoids LLDP generate too many PDU if the port is up and down frequently. The delay starts to count when the port links down. The port would not generate LLDP PDU until the delay counts to zero. The configuration could be shown by “`show lldp`” command.

Use the **no** form of this command to restore the delay to default value.

Example	This example sets LLDP re-initial delay to 5 seconds.
----------------	---

```
Switch(config)# lldp reinit-delay 5
Switch# show lldp
```

```
State: Disabled Timer: 10 Seconds
Hold multiplier: 4 Reinit delay: 5 Seconds Tx delay: 2 Seconds
LLDP packet handling: Flooding
```

lldp holdtime-multiplier

Syntax `lldp holdtime-multiplier <2-10>`

no `holdtime-multiplier`

Parameter	<code><2-10></code>	Specify the LLDP hold time multiplier.
------------------	---------------------------	--

Default	<code>lldp holdtime-multiplier 4</code>
----------------	---

Mode	Global Configuration
-------------	----------------------

Usage Use “`lldp holdtime-multiplier`” command to configure the LLDP PDU hold

multiplier that decides time-to-live (TTL) value sent in LLDP advertisements: $TTL = (tx\text{-interval} * holdtime\text{-multiplier})$. The configuration could be shown by “**show lldp**” command.

Use the **no** form of this command to restore the multiplier to default value.

Example This example sets LLDP hold time multiplier to 3.

```
Switch(config)# lldp holdtime-multiplier 3
Switch# show lldp

State: Disabled Timer: 10 Seconds
Hold multiplier: 3 Reinit delay: 2 Seconds Tx delay: 2 Seconds
LLDP packet handling: Flooding
```

lldp lldpdu

Syntax **lldp lldpdu (filtering|flooding|bridging)**

Parameter	bridging	When LLDP is globally disabled, LLDP packets are bridging (bridging LLDP PDU to VLAN member ports).
	filtering	When LLDP is globally disabled, LLDP packets are filtered (deleted).
	flooding	When LLDP is globally disabled, LLDP packets are flooded (forwarded to all interfaces).

Default Default LLDP PDU handling behavior when LLDP disabled is flooding

Mode Global Configuration

Usage Use “**lldp lldpdu**” command to configure the LLDP PDU handling behavior when LLDP is globally disabled. It should be noticed that if LLDP is globally enabled and per port LLDP RX status is configured to disabled, the received LLDP PDU would be dropped instead of taking the global disable behavior.

The configuration could be shown by “**show lldp**” command.

Use the **no** form of this command to restore the behavior to default.

Example

This example sets LLDP disable action to bridging.

```
Switch(config)# lldp lldpdu bridging
Switch# show lldp
```

```
State: Enabled Timer: 30 Seconds
Hold multiplier: 4 Reinit delay: 2 Seconds Tx delay: 2 Seconds
LLDP packet handling: Bridging
```

lldp med

Syntax

```
lldp med
no lldp med
```

Default

```
lldp med
```

Mode

```
Port Configuration
```

Usage Use “**lldp med**” to configure the LLDP MED enable status. If LLDP MED is enabled, LLDP MED capability TLV and other selected MED TLV would be attached. The configuration could be shown by “show lldp med” command.

Use the **no** form of this command to disable the LLDP MED status.

Example

This example sets port gi1 to enable LLDP MED, port gi2 to disable LLDP MED.

```
Switch(config)# interface gi1 Switch(config-if)# lldp med
Switch(config)# interface gi2 Switch(config-if)# no lldp med
Switch# show lldp interfaces gi1-2 med
```

```
Port | Capabilities | Network Policy | Location | Inventory
-----+-----+-----+-----+-----
--
gi1 | Yes | Yes | No |
No
gi2 | No | Yes | No |
No
```

Ildp med fast-start-repeat-count

Syntax	lldp med fast-start-repeat-count <1-10> no lldp med fast-start-repeat-count
Parameter	<1-10> LLDP PDU fast start TX repeat counts.
Default	Default fast start TX repeat count is 3
Mode	Global Configuration

Usage Use “**lldp med fast-start-repeat-count**” command to configure the LLDP PDU fast start TX repeat count. When port links up, it will send LLDP PDU immediately to notify link partner. The number of LLDP PDU sends when it links up depends on fast-start-repeat-count configuration. The LLDP PDU fast-start transmits in interval of one second. The fast start behavior works no matter LLDP MED is enabled or not. The configuration could be shown by “**show lldp med**” command.

Use the **no** form of this command to restore count to default.

Example	This example sets fast start repeat count to 10.
	<pre>Switch(config)# lldp med fast-start-repeat-count 10 Switch# show lldp med Fast Start Repeat Count: 10 lldp med network-policy voice: auto</pre>

Ildp med location

Syntax	lldp med location (coordination civic-address ecs-elin) ADDR no lldp med location (coordination civic-address ecs-elin)
Parameter	<p>coordination Location type to be configured. “ecs-elin” is abbreviation of civic-address ecs-emergency call service – emergency location identifier</p> <p>elin number</p> <p>ADDR Specify the location data. Input format is hexadecimal values without colon (for example: 1234AB). For coordination location type, the length of ADDR is 16 bytes. For civic-address, the length is 6 to 160 bytes. <u>For ecs-elin, the length is 10 to 25 bytes.</u></p>
Default	Default is no location data.
Parameter	<p><1-32> Specify the network policy index</p> <p>voice Specify the network policy application type.</p> <p>voice-signaling</p>
Mode	Port Configuration

Usage Use “**lldp med location**” command to configure the LLDP MED location data. The “coordinate”, “civic-address”, “ecs-elin” locations are independent, so at most three location TLVs could be sent if their data are not empty. The configuration of location could be shown by “**show lldp interface PORT med**” command.

Use the **no** form of this command to clear location data.

Example This example sets location data for interface gi1.

```
Switch(config)# interface gi1
Switch(config-if)# lldp med location coordinate
112233445566778899AABBCCDDEEFF00
Switch(config-if)# lldp med location civic-address 112233445566
Switch(config-if)# lldp med location ecs-elin 112233445566778899AA
Switch# show lldp interfaces gi1 med

Port | Capabilities | Network Policy | Location | Inventory
-----+-----+-----+-----+-----
--
gi1 | Yes | Yes | Yes |
Yes

Port ID: gi1
Network policies: 1, 32 Location:
Coordinates: 112233445566778899AABBCCDDEEFF00
Civic-address: 112233445566
Ecs-elin: 112233445566778899AA
```

lldp med network-policy

Syntax **lldp med network-policy** <1-32> **app** (voice|voice-signaling|guest-voice|guest-voice-signaling|softphone-voice|video-conferencing|streaming-video|video-signaling) **vlan** <1-4094> **vlan-type** (tag|untag) **priority** <0- 7> **dscp** <0-63>

no lldp med network-policy <1-32>

guest-voice- signaling softphone-voice video- conferencing
streaming-video video-signaling

<1-4094> Specify the VLAN ID

	tag	Specify the VLAN tag status
	untag	
	<0-7>	Specify the L2 priority
	<0-63>	Specify the DSCP value
Default	No network policy is defined	

Mode Global Configuration

Usage Use “**lldp med network-policy**” command to configure the LLDP MED network policy table and add a network policy entry that can be bind to ports. If LLDP MED network policy voice auto mode is enabled, “voice” type network policy can not be created since it is in auto mode. The network policy table configuration could be shown by “**show lldp med**” command.

Use the **no** form of this command to remove network policy entry of specific index. A network policy can be removed only when it is not bind to any port.

Example This example create 2 network policies.

```
Switch(config)# lldp med network-policy 1 app voice-signaling vlan 2
vlan-type tag priority 3 dscp 4
Switch(config)# lldp med network-policy 32 app video- conferencing
vlan 5 vlan-type tag priority 1 dscp 63 Switch# show lldp med
```

```
Fast Start Repeat Count: 10
lldp med network-policy voice: auto
```

```
Network policy 1
-----
```

```
Application type: Voice Signaling VLAN ID: 2 tagged
Layer 2 priority: 3
DSCP: 4
```

```
Network policy 32
-----
```

```
Application type: Conferencing VLAN ID: 5 tagged
Layer 2 priority: 1
DSCP: 63
```

lldp med network-policy (Interface)

Syntax **lldp med network-policy (add|remove) <1-32>**

Parameter	add	Add network policy binding for ports.
	remove	Remove network policy binding for ports.
	<1-32>	Specify the network policy index
Default	Default is no network policy binding to port.	

Mode Port Configuration

Usage Use “**lldp med network-policy**” command to bind the network policy to port interface. The binded network policy of one port should be with different types. If network policy TLV is selected over a port, the binded network policies would be attached in LLDP MED PDU. The configuration of network policy binding could be shown by “show lldp med” command.

Example This example binds network policy for interface gi1 and gi2.

```
Switch# show lldp med

Fast Start Repeat Count: 10
lldp med network-policy voice: auto

Network policy 1
-----
Application type: Voice Signaling VLAN ID: 2 tagged
Layer 2 priority: 3
DSCP: 4

Network policy 32
-----
Application type: Conferencing VLAN ID: 5 tagged
Layer 2 priority: 1
DSCP: 63

Switch(config)# interface range gi1,2
Switch(config-if-range)# lldp med network-policy add 1,32
Switch# show lldp interfaces gi1,2 med

Port | Capabilities | Network Policy | Location | Inventory
----- + ----- + ----- + ----- + -----
--
gi1 | Yes | Yes | Yes |
Yes
gi2 | Yes | Yes | Yes |
Yes
```

Port ID: gi1
Network policies: 1, 32

Port ID: gi2
Network policies: 1, 32

lldp med network-policy voice auto

Syntax **lldp med network-policy voice auto**
no lldp med network-policy voice auto

Default lldp med network-policy auto

Mode Global Configuration

Usage Use “**lldp med network-policy voice auto**” command to enable network policy voice auto mode. In voice auto mode, if network-policy TLV is selected, a voice type network policy would be attached to PDU that contents comes from voice VLAN configuration. This works for voice VLAN module to exchange voice VLAN information with link partner. If voice auto mode is enabled, user can not manually create an voice type network policy; if an voice type network policy is created, the voice auto mode can not be enabled. The configuration of network policy auto mode could be shown by “**show lldp med**” command.

Use the **no** form of this command to disable voice auto mode.

Example This example sets network policy auto mode to enable and then disable.

```
Switch (config)# lldp med network-policy auto
Switch# show lldp med

Fast Start Repeat Count: 10
lldp med network-policy voice: auto

Switch (config)# no lldp med network-policy auto
Switch# show lldp med

Fast Start Repeat Count: 10
lldp med network-policy voice: manual
```

lldp med tlv-select

Syntax **lldp med tlv-select** *MEDTLV* [*MEDTLV*] [*MEDTLV*] [*MEDTLV*]
no lldp med tlv-select

Parameter	MEDTLV MED optional TLV. Available optional TLVs are : <u>network-policy, location, poe-pse, inventory.</u>
Default	network-policy TLV

Mode Port Configuration

Usage Use “**lldp med tlv-select**” command to configure the LLDP MED TLV selection. It should be noticed that even no MED TLV is selected, MED capability TLV would be attached if LLDP MED is enable. The configuration could be shown by “show lldp med” command.

Use the **no** form of this command to remove all selected MED TLV over the dedicated ports.

Example

This example sets port gi1-2 to select LLDP MED network policy, location, POE-PSE, inventory TLVs, and it sets port gi3-4 to un-select all LLDP MED TLVs.

```
Switch(config)# interface gi1
Switch(config-if)# lldp med tlv-select network-policy location
inventory
Switch(config)# interface gi2
Switch(config-if)# no lldp med tlv-select
Switch# show lldp interfaces gi1-2 med
```

```
Port | Capabilities | Network Policy | Location | Inventory
-----+-----+-----+-----+-----
--
gi1 | Yes | Yes | Yes |
Yes
gi2 | Yes | No | No |
No
```

lldp tlv-select

Syntax `lldp tlv-select TLV [TLV] [TLV] [TLV] [TLV] [TLV] [TLV] [TLV]`
`no lldp tlv-select`

Parameter	TLV	Specify the selected optional TLV. Available optional TLVs are : sys-name (system name), sys-desc (system description), sys-cap (system capability), mac-phy (802.3 MAC-PHY), lag (802.3 link aggregation), max- frame-size (802.3 max frame size), and management- <u>addr (management address).</u>
-----------	-----	--

Default Default is no selected optional TLV.

Mode Port Configuration

Usage Use “lldp tlv-select” command to attach selected TLV in PDU. The configuration could be shown by “show lldp” command.

Use the **no** form of this command to remove all selected TLV.

Example

This example selects system name, system description, system capability, 802.3 MAC-PHY, 802.3 link aggregation, 802.3 max frame size, and management address TLVs for interface gi1 and gi3.

```
Switch(config)# interface range gi 1,3
Switch(config-if-range)# lldp tlv-select port-desc sys-name sys-
desc sys-cap mac-phy lag max-frame-size management-addr
Switch(config-if-range)# end
Switch# show lldp interfaces gi1,3
```

```
State: Disabled Timer: 10 Seconds
Hold multiplier: 3 Reinit delay: 2 Seconds Tx delay: 2 Seconds
LLDP packet handling: Flooding
```

```
Port | State | Optional TLVs | Address
-----+-----+-----+-----
gi1 | RX,TX | PD, SN, SD, SC | 192.168.1.254
gi3 | RX,TX | PD, SN, SD, SC | 192.168.1.254
```

```
Port ID: gi1
802.3 optional TLVs: 802.3-mac-phy, 802.3-lag, 802.3-max- frame-
size, management-addr
802.1 optional TLVs PVID: Enabled
```

```
Port ID: gi3
802.3 optional TLVs: 802.3-mac-phy, 802.3-lag, 802.3-max- frame-
size, management-addr
802.1 optional TLVs PVID: Enabled
```

lldp tlv-select pvid

Syntax

```
lldp tlv-select pvid (disable|enable)
no lldp tlv-select pvid
```

Parameter

disable	Disable LLDP 802.1 PVID TLV attach state
enable	Enable LLDP 802.1 PVID TLV attach state

Default

Default is enabled

Mode

Port Configuration

Usage Use “**lldp tlv-select pvid**” command to configure the 802.1 PVID TLV attach enable status. The configuration could be shown by “**show lldp**” command. Use the **no** form of this command to restore the pvid to default value.

Example

This example sets port gi1 PVID TLV attaches status to disable and port gi2 to enable.

```
Switch(config)# interface gi1
Switch(config-if)# lldp tlv-select pvid disable
Switch(config-if)# interface gi2
Switch(config-if)# lldp tlv-select pvid enable

Switch# show lldp interfaces gi1,gi2

State: Disabled Timer: 10 Seconds
Hold multiplier: 3 Reinit delay: 2 Seconds Tx delay: 2 Seconds
LLDP packet handling: Flooding

Port | State | Optional TLVs | Address
-----+-----+-----+-----+-----+-----
|192.168.1.254
gi2 | RX,TX | |192.168.1.254

Port ID: gi1
802.3 optional TLVs:
802.1 optional TLVs PVID: Disabled

Port ID: gi2
802.3 optional TLVs:
802.1 optional TLVs
PVID: Enabled
```

lldp tlv-select vlan-name

Syntax `lldp tlv-select vlan-name (add|remove) VLAN-LIST`

Parameter	add VLAN-LIST	Add VLAN list for LLDP 802.1 VLAN-NAME TLV on the specific interface. The configured ports should be member of all the specified VLANs or the VLAN-LIST is not valid.
	remove VLAN-LIST	Remove VLAN list of LLDP 802.1 VLAN-NAME TLV from interface.

Default Default is no VLAN added.

Mode Port Configuration

Usage Use “**lldp tlv-select vlan-name**” command to add or remove VLAN list for 802.1 VLAN-NAME TLV. The configuration could be shown by “**show lldp**” command.

Example This example add VLAN 100 to VLAN-NAME TLV for port gi10.

```
Switch(config)#      vlan      100      Switch(config-vlan)#      exit
Switch(config)# interface gi1
Switch(config-if)#  switchport trunk allowed vlan add all
Switch(config-if)#  lldp tlv-select  vlan-name add 100
Switch(config-if)# end

Switch# show lldp interfaces gi1

State: Enabled Timer: 30 Seconds
Hold multiplier: 4 Reinit delay: 2 Seconds Tx delay: 2 Seconds
LLDP packet handling: Flooding

Port | State | Optional TLVs | Address
-----+-----+-----+-----
|192.168.1.2          | gi1 | RX,TX |

Port ID: gi1
802.3 optional TLVs:
802.1 optional TLVs PVID: Enabled
VLANs: 100
```

lldp tx

Syntax **lldp tx no lldp tx**

Default Default is enabled

Mode Port Configuration

Usage Use “**lldp tx**” command to enable the LLDP PDU TX ability. The configuration could be shown by “**show lldp**” command. Use the **no** form of this command to disable the TX ability.

Example

This example sets port gi1 to enable LLDP TX, port gi2 to disable RX but enable TX, port gi3 to enable RX but disable TX, port gi4 to disable RX and TX.

```
Switch(config)# interface gi1 Switch(config-if)# lldp rx
Switch(config-if)# lldp tx Switch(config)# interface gi2
Switch(config-if)# no lldp rx Switch(config-if)# lldp tx
Switch(config)# interface gi3 Switch(config-if)# lldp rx
Switch(config-if)# no lldp tx Switch(config)# interface gi4
Switch(config-if)# no lldp rx Switch(config-if)# no lldp tx
Switch(config-if)# end
Switch# show lldp interfaces gi1-4
```

```
State: Enabled Timer: 30 Seconds
Hold multiplier: 4 Reinit delay: 2 Seconds Tx delay: 2 Seconds
LLDP packet handling: Bridging
```

```
Port | State | Optional TLVs | Address
-----+-----+-----+-----+-----
|192.168.1.254
gi2 | TX | |192.168.1.254
gi3 | RX | |192.168.1.254
gi4 | Disable | |192.168.1.254
```

lldp tx-delay

Syntax `lldp tx-delay <1-8192>`
`no lldp tx-delay`

Parameter	<code><1-8192></code>	Specify the LLDP tx delay in unit of seconds.
------------------	-----------------------------	---

Default	Default TX delay is 2 seconds
----------------	-------------------------------

Mode	Global Configuration
-------------	----------------------

Usage Use “`lldp tx-delay`” command to configure the delay in seconds between successive LLDP frame transmissions. The delay starts to count in any case LLDP PDU is sent such as by LLDP PDU advertise routine, LLDP PDU content change, port link up, etc. The configuration could be shown by “`show lldp`” command.

Use the **no** form of this command to restore the delay to default value.

Example This example sets LLDP PDU TX delay to 10 seconds.

```
Switch(config)# lldp tx-delay 10
Switch# show lldp
```

```
State: Disabled Timer: 10 Seconds
Hold multiplier: 4 Reinit delay: 2 Seconds Tx delay: 10 Seconds
LLDP packet handling: Flooding
```

show lldp

Syntax `show lldp`
`show lldp interface IF_NMLPORTS`

Parameter `IF_NMLPORTS` Specify the ports to display information

Default This command has no default value.

Mode Privileged EXEC

Usage Use “`show lldp`” and “`show lldp interface`” commands to display LLDP global information including LLDP enable status, LLDP PDU TX interval, hold time multiplier, re-initial delay, TX delay, and LLDP packet handling when LLDP is disabled. The per port information displayed includes port LLDP RX/TX enable status, selected TLV to TX and IP address. The abbreviations in optional TLVs are: port description (PD), system name (SN), system description (SD), and system capability (SC).

Example This example displays lldp information of port gi1 and gi2
Switch# `show lldp interfaces gi1,gi2`

```
State: Disabled Timer: 30 Seconds
Hold multiplier: 4 Reinit delay: 2 Seconds Tx delay: 2 Seconds
LLDP packet handling: Flooding
```

```
Port | State | Optional TLVs | Address
-----+-----+-----+-----
| RX,TX | | 192.168.1.254 | 192.168.1.254 | gi1 | RX,TX | PD, SN, SD, SC | 192.168.1.254 | gi1
```

```
Port ID: gi1
802.3 optional TLVs: 802.3-mac-phy, 802.3-lag, 802.3-max- frame-size, management-addr
802.1 optional TLVs PVID: Enabled
```

```
Port ID: gi2
802.3 optional TLVs:
802.1 optional TLVs
```


PVID: Enabled

show lldp local-device

Syntax	show lldp local-device show lldp interfaces <i>IF_NMLPORTS</i> local-device
Parameter	<i>IF_NMLPORTS</i> Specify the ports to display information
Default	There is no default configuration for this command
Mode	Privileged EXEC
Usage	Use “ show lldp local-device ” command to show the local configuration of LLDP PDU. By the commands, a user can view the contents of LLDP/ LLDP-MED TLVs that would be attached in LLDP PDU.

Example This example displays the local device information.

```
Switch# show lldp local-device

LLDP Local Device Information: Chassis Type : Mac Address Chassis
ID : 00:12:12:12:12:12
System Name : Switch121212 System Description :
System Capabilities Support : Bridge System Capabilities Enable :
Bridge
Management Address : 192.168.1.254 (IPv4)
```

```
Switch121212(config)# show lldp interfaces gil local-device
```

```
Device ID: 00:12:12:12:12:12
Port ID: gil
System Name: Switch121212 Capabilities: Bridge System description:
Port description:
Management address: 192.168.1.254 Time To Live: 120
802.3 MAC/PHY Configur/Status
Auto-negotiation support: Supported Auto-negotiation status: Enabled
Auto-negotiation Advertised Capabilities: 10BASE-T half duplex, 10BASE-T full duplex, 100BASE-
TX half duplex, 100BASE-TX full duplex
Operational MAU type: Other or unknown
802.3 Link Aggregation
Aggregation capability: Capable of being aggregated Aggregation status: Not currently in
aggregation Aggregation port ID: 0
802.3 Maximum Frame Size: 1522
802.1 PVID: 1
LLDP-MED capabilities: Capabilities, Network Policy, Location, Extended PSE, Inventory
LLDP-MED Device type: Network Connectivity LLDP-MED Network policy
Application type: Voice Signaling Flags: Unknown Policy
VLAN ID: 2
```

```

Layer 2 priority: 3
DSCP: 4
LLDP-MED Network policy Application type: Conferencing Flags: Unknown Policy
VLAN ID: 5
Layer 2 priority: 1
DSCP: 63
Hardware revision: 1123
Firmware revision: 2.5.0-beta.32801 Software revision: 2.5.0-beta.32801 Serial number: abc
Manufacturer Name:
Model name: RTL8328-24FE-4GE Asset ID:
LLDP-MED Location
Coordinates: 11:22:33:44:55:66:77:88:99:AA:BB:CC:DD:EE:FF:00
Civic-address: 11:22:33:44:55:66
Ecs-elin: 11:22:33:44:55:66:77:88:99:AA
  
```

show lldp med

Syntax show lldp med

show lldp interfaces *IF_NMLPORTS* med

Parameter	<i>IF_NMLPORTS</i>	Specify the ports to display information
-----------	--------------------	--

Default	There is no default configuration for this command
----------------	--

Mode	Privileged EXEC
-------------	-----------------

Usage	Use “ show lldp med ” command to display the LLDP MED configuration information.
--------------	---

Example	This example display the LLDP MED information.
----------------	--

```

Switch# show lldp med

Fast Start Repeat Count: 10
lldp med network-policy voice: manual

Network policy 1
-----
Application type: Voice Signaling VLAN ID: 2 tagged
Layer 2 priority: 3
DSCP: 4

Network policy 32
-----
Application type: Conferencing VLAN ID: 5 tagged
Layer 2 priority: 1
DSCP: 63

Port | Capabilities | Network Policy | Location | Inventory
----- + ----- + ----- + ----- + -----
--
  
```

```

gi1 | Yes | Yes | Yes |
Yes
gi2 | Yes | Yes | Yes |
Yes
gi3 | Yes | No | No |
No
gi4 | Yes | No | No |
No
gi5 | No | Yes | No |
No
gi6 | No | Yes | No |
No
gi7 | No | Yes | No |
No
gi8 | No | Yes | No |
No
gi9 | Yes | Yes | No |
No
gi10 | Yes | Yes | No |
No
gi11 | Yes | Yes | No |

```

```

No
  gi12 |      Yes      |      Yes      |      No      |
No
  gi13 |      Yes      |      Yes      |      No      |
No
  gi14 |      Yes      |      Yes      |      No      |
No
  gi15 |      Yes      |      Yes      |      No      |
No
  gi16 |      Yes      |      Yes      |      No      |
No
  gi17 |      Yes      |      Yes      |      No      |
No
  gi18 |      Yes      |      Yes      |      No      |
No
  gi19 |      Yes      |      Yes      |      No      |
No
  gi20 |      Yes      |      Yes      |      No      |
No
  gi21 |      Yes      |      Yes      |      No      |
No
  gi22 |      Yes      |      Yes      |      No      |
No
  gi23 |      Yes      |      Yes      |      No      |
No
  gi24 |      Yes      |      Yes      |      No      |
No
  gi25 |      Yes      |      Yes      |      No      |
No
  gi26 |      Yes      |      Yes      |      No      |
No
  gi27 |      Yes      |      Yes      |      No      |
No
  gi28 |      Yes      |      Yes      |      No      |
No

```

Switch# show lldp interfaces gi1 med

```

Port | Capabilities | Network Policy | Location | Inventory
-----+-----+-----+-----+-----

```

```
--
gil | Yes | Yes | Yes |
Yes

Port ID: gil
Network policies: 1, 32 Location:
Coordinates: 112233445566778899AABBCCDDEEFF00
Civic-address: 112233445566 Ecs-elin: 112233445566778899AA
```

Switch121212(config)#

show lldp neighbor

Syntax	show lldp neighbor show lldp interfaces <i>IF_NMLPORTS</i> neighbor
Parameter	<i>IF_NMLPORTS</i> Specify the ports to display information
Default	There is no default configuration for this command
Mode	Privileged EXEC

Usage Use “**show lldp neighbor**” command to display the received neighbor LLDP PDU information. When LLDP PDU is received on LLDP RX enable ports, system would store the PDU information in database until time to live of the PDU counts down to zero.

Example This example displays the neighbor information.

```
Switch# show lldp neighbor

Port | Device ID | Port ID | SysName
| Capabilities | TTL
----+-----+-----+-----
-- +-----+-----
gi3 | 00:12:12:12:12:12 | gi1 |
Switch121212 | Bridge | 111
gi11 | TREEBASE |00:1A:4D:26:EB:E8 |
TREEBASE | Station Only | 33
Switch121212(config)# show lldp interfaces gi3 neighbor Device ID:
00:12:12:12:12:12
Port ID: gi1
System Name: Switch121212 Capabilities: Bridge System description:
Port description:
Management address: 192.168.1.254 Time To Live: 98
802.3 MAC/PHY Configur/Status
Auto-negotiation support: Supported Auto-negotiation status:
Enabled
Auto-negotiation Advertised Capabilities: 10BASE-T half duplex,
10BASE-T full duplex, 100BASE-TX half duplex, 100BASE-TX full
duplex
Operational MAU type: 100BASE-TX full duplex mode
```

```

802.3 Link Aggregation
Aggregation capability: Capable of being aggregated Aggregation
status: Not currently in aggregation Aggregation port ID: 0
802.3 Maximum Frame Size: 1522
802.1 PVID: 1
LLDP-MED capabilities: Capabilities, Network Policy, Location,
Extended PSE, Inventory
LLDP-MED Device type: Network Connectivity LLDP-MED Network policy
Application type: Voice Signaling
  
```

```

Flags: Unknown Policy VLAN ID: 2
Layer 2 priority: 3
DSCP: 4
LLDP-MED Network policy Application type: Conferencing Flags: Unknown Policy
VLAN ID: 5
Layer 2 priority: 1
DSCP: 63
LLDP-MED Power over Ethernet Device Type: Power Sourcing Entity Power Source: Primary Power
Source Power priority: Low
Power value: 13.0 Watts Hardware revision: 1123
Firmware revision: 2.5.0-beta.32801 Software revision: 2.5.0-beta.32801 Serial number: abc
Manufacturer Name:
Model name: RTL8328-24FE-4GE Asset ID:
LLDP-MED Location
Coordinates: 11:22:33:44:55:66:77:88:99:AA:BB:CC:DD:EE:FF:00
Civic-address: 11:22:33:44:55:66
Ecs-elin: 11:22:33:44:55:66:77:88:99:AA
  
```

show lldp statistics

Syntax	show lldp statistics show lldp interfaces <i>IF_NMLPORTS</i> statistics
Parameter	<i>IF_NMLPORTS</i> Specify the ports to display information
Default	There is no default configuration for this command
Mode	Privileged EXEC
Usage	Use “ show lldp statistics ” command to display the LLDP RX/TX statistics.
Example	<p>This example display the LLDP statistics.</p> <pre> Switch# show lldp statistics LLDP Global Statistics: Insertions : 3 Deletions : 0 Drops : 0 Age Outs : 1 TX Frames RX Frames RX </pre>

TLVs		RX Ageouts								
Port	Total	Total	Discarded	Errors	Discarded	Unrecognized	Total			
0	0	0	50	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	1	0	50	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	3377	10129	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	

```
Switch121212(config)# show lldp interfaces gil statistics
```

```
LLDP Port Statistics:
```

```
| TX Frames | RX Frames | RX TLVs | RX Ageouts
Port | Total | Total | Discarded | Errors | Discarded | Unrecognized | Total
-----+-----+-----+-----+-----+-----+-----+-----
gil | 51 | 0 | 0 | 0 | 0 | 0 |
0 | 0
```

show lldp tlv-overloading

Syntax `show lldp interfaces IF_NMLPORTS tlv-overloading`

Parameter `IF_NMLPORTS` Specify the ports to display information

Default There is no default configuration for this command

Mode Privileged EXEC

Usage The LLDP PDU is composed by TLVs and selected number TLVs may compose a large PDU that the system can not handle. The maximum PDU length is to take the smaller number of jumbo frame size minus 30 bytes (30 bytes kept for header) or 1488 bytes.

Use “**show lldp tlv-overloading**” command to display the length of LLDP TLVs and if the TLVs overload the PDU length. The TLVs with status marked “overload” would not be transmitted.

Example This example display the LLDP TLVs overloading status of port gil.

```
Switch# show lldp interfaces gil tlv-overloading
```

```
gil:
```

```
TLVs Group | Bytes | Status
-----+-----+-----
Mandatory | 21 | Transmitted
LLDP-MED Capabilities | 9 | Transmitted
LLDP-MED Location | 53 | Transmitted
LLDP-MED Network Policies | 20 | Transmitted
LLDP-MED POE | 9 | Transmitted
802.3 | 30 | Transmitted
Optional | 38 | Transmitted
LLDP-MED Inventory | 97 | Transmitted
802.1 | 8 | Transmitted
```

```
Total: 285 bytes
```

```
Left: 1203 bytes
```

Example The following example shows the global logging configuration.

```
Switch# show logging Logging service is enabled
TARGET | STATUS | Server (PORT) | FACILITY | LOG LEVEL
-----+-----+-----+-----+-----
buffered | enabled | |
|emerg, alert, crit, error, warning, notice
console | enabled | |
|emerg, alert, crit, error, warning, notice
```

The following table describes the significant fields shown in the example:

Field	Description
TARGET	The destinations where the logging messages are stored.
STATUS	The status of logging destinations.
Server (PORT)	Server address and port number for the remote logging.
FACILITY	The facility of the log messages.
LOG LEVEL	The severity level of the log messages.

The following example shows the log messages stored in the RAM.

```
Switch# show logging buffered

Log messages in buffered

NO. | Timestamp | Category | Severity | Message
-----+-----+-----+-----+-----
1|Jan 01 2000 08:14:47| AAA| notice| New console connection for user admin, source async
ACCEPTED
2|Jan 01 2000 08:03:12| AAA| notice| New console connection for user admin, source async
ACCEPTED
3|Jan 01 2000 08:01:13| System| notice| System Startup!
4|Jan 01 2000 08:01:13| System| notice| Logging is enabled
```

The following table describes the significant fields shown in the example:

Field	Description
NO	The number of log entry.
Timestamp	Time when the message was generated.
Category	The category of the message.
Severity	The severity level of the messages.

Message	The message content.
---------	----------------------

Logging

clear logging

Syntax clear logging (buffered|file)

Parameter	buffered	Clear the log messages stored in the RAM.
	file	Clear the log messages stored in the Flash.

Default N/A

Mode Privileged EXEC

Usage To clear the log messages from the internal logging buffer and flash, use the command **clear logging** in the Privileged EXEC mode.

Example The following example clear the log messages stored in RAM and Flash.

```
Switch# clear logging buffered
Switch# clear logging file
```

logging

Syntax logging
no logging

Parameter N/A

Default Logging service is enabled.

Mode Global Configuration

Usage To enable logging service on the switch, use the command **logging** in the Global Configuration mode. Otherwise, use the **no** form of the command to disable the logging service on the switch.

The status of global logging server is available from the command **show**

logging in the Privileged EXEC mode. When the logging service is enabled, logging on and off at each destination rule can be individually configured by the command **logging console**, **logging buffered**, **logging file**, and **logging host** in the Global Configuration mode. If the logging service is disabled, no messages will be sent to these destinations.

Example

The following example disables and enables the logging service on the switch.

```
Switch(config)# no logging
Switch(config)# logging
```

logging host

Syntax

logging host (*ip-addr|hostname*) [**facility** *facility*] [**port** *port*] [**severity** *sev*]
no logging host (*ip-addr|hostname*)

Parameter

<i>ipv4-addr</i>	IPv4 address of the remote logging server.
<i>hostname</i>	Hostname of the remote logging server.
facility <i>facility</i>	Specify the facility of the logging messages. It can be on of the following value: local0, local1, local2, local3, local4, local5, local6, and local7. The default value of facility is local7.
port <i>port</i>	Specify the port number of the remote logging server. The valid range is from 0 to 65535, and the default value is 512.
severity <i>sev</i>	Specify the minimum severity of the logging messages. The valid range is from 0 to 7, and the number 0 to 7 represents emerg, alert, critical, error, warning, notice, info, and debug individually. The default value of minimum severity level is 5 (emerg, alert, crit, error, warning, notice).

Default

No remote logging destination is configured.

Mode

Global Configuration

Usage To define the logging server, use the command **logging host** to add the remote logging server in the Global Configuration mode. Otherwise, use the command **no logging host** to remove the remote logging rules.

For the host name configuration, logging service would try translating the host name to IP address directly. Add the logging host would be failed on the failure of host name translating.

Example

The following example adds the remote logging rules by IP and Hostname.

```
Switch(config)# logging host 1.2.3.4
Switch(config)# logging host SYSLOG
```

logging severity

Syntax

logging (**buffered|console|file**) [**severity** *sev*]
no logging (**buffered|console|file**)

Parameter buffered Log messages to RAM.

console Log messages to console buffer.

file Log messages to Flash.

severity sev Specify the minimum severity of the logging messages.

The valid range is from 0 to 7, and the number 0 to 7 represents emerg, alert, critical, error, warning, notice, info, and debug individually. The default minimum severity of the **logging severity** configuration is 5 (emerg, alert, crit, error, warning, notice).

Default Logging to buffered and console is enabled, and the default minimum severity level is 5 (emerg, alert, crit, error, warning, notice).

Mode Global Configuration

Usage To set the minimum severity for the messages that are logged to RAM, console, or Flash, use the command logging severity in the Global Configuration mode. Use the **no** form of the command to remove the mechanism of logging to RAM, console, or Flash individually.

Example The following example sets the minimum severity level of logging to RAM and Flash as debugging.

```
Switch(config)# logging buffered 7
Switch(config)# logging flash 7
```

show logging

Syntax show logging [buffered|file]

Parameter	buffered	Display the log messages stored in the RAM.
	file	Display the log messages stored in the Flash.

Default N/A

Mode Priviledged EXEC

Usage To display the global logging configuration, and the logging messages stored in the RAM and Flash, use the command **show logging** in the Privileged EXEC mode.

Example The following example shows the global logging configuration.

```
Switch# show logging Logging service is enabled
TARGET | STATUS | Server (PORT) | FACILITY | LOG LEVEL
-----+-----+-----+-----+-----+-----+-----+-----
buffered | enabled | |
```

```

|emerg, alert, crit, error, warning, notice
console | enabled | |
|emerg, alert, crit, error, warning, notice

```

The following table describes the significant fields shown in the example:

Field	Description
TARGET	The destinations where the logging messages are stored.
STATUS	The status of logging destinations.
Server (PORT)	Server address and port number for the remote logging.
FACILITY	The facility of the log messages.
LOG LEVEL	The severity level of the log messages.

The following example shows the log messages stored in the RAM.

```
Switch# show logging buffered
```

```
Log messages in buffered
```

```

NO.| Timestamp | Category | Severity | Message
-----+-----+-----+-----+-----
-----
1|Jan 01 2000 08:14:47| AAA| notice| New console connection for user admin, source async
ACCEPTED
2|Jan 01 2000 08:03:12| AAA| notice| New console connection for user admin, source async
ACCEPTED
3|Jan 01 2000 08:01:13| System| notice| System Startup!
4|Jan 01 2000 08:01:13| System| notice| Logging is enabled

```

The following table describes the significant fields shown in the example:

Field	Description
NO	The number of log entry.
Timestamp	Time when the message was generated.
Category	The category of the message.
Severity	The severity level of the messages.
Message	The message content.

MAC Address Table

clear mac address-table

Syntax `clear mac address-table dynamic [interfaces IF_PORTS | vlan vlan-id]`

Parameter interfaces

IF_PORTS

Delete all dynamic addresses learned on the specific interface.

vlan *vlan-id* Delete all source addresses learned on the specific VLAN.

Default N/A

Mode Privileged EXEC

Usage To clear the dynamic (learned) MAC entries from the MAC address table, the specific interface, or the specific VLAN, use the command **clear mac address-table** in the Privileged EXEC mode.

Example The following example clears the learned MAC addresses on the interface gi1.

```
Switch# clear mac address-table dynamic interfaces gi1
```

mac address-table aging-time

Syntax **mac address-table aging-time** *seconds*

Parameter *seconds* The time in seconds that an entry remains in the MAC address table. Its valid range is from 10 to 630 seconds, and the default value is 300 seconds.

Default The default aging time is 300 seconds.

Mode Global Configuration

Usage To set the aging time of the MAC address table, use the command **mac address-table aging-time** in the Global Configuration mode.

Example The following example set the aging time to 500 seconds.

```
Switch(config)# mac address-table aging-time 500
```

mac address-table static

Syntax **mac address-table static** *mac-addr* **vlan** *vlan-id* **interfaces** *IF_PORTS*
mac address-table static *mac-addr* **vlan** *vlan-id* **drop**
no mac address-table static *mac-addr* **vlan** *vlan-id*

Parameter *mac-addr* MAC address.

vlan *vlan-id* Specify the VLAN ID for the interface.

Interface <i>IF_PORTS</i>	Specify the interface ID or a list of interface IDs.
drop	Drop the packets with the specified source or <u>destination unicast MAC address.</u>

Default No static addresses are configured

Mode Global Configuration

Usage To add a static address to the MAC address table, use the command **mac address-table static** in the Global Configuration mode. For the unicast MAC address filtering, use the command **mac address-table static** with parameter **drop** to drop the packets with the specified source or destination unicast MAC address. To delete the static entry from the MAC address table, use the **no** form of the command.

Example The following example adds a static address into MAC address table.

```
Switch# mac address-table static 00:11:22:33:44:55 vlan 1 interfaces fa5
```

The following example adds a rule of unicast address filtering into MAC address table.

```
Switch# mac address-table static 00:11:22:33:44:55 vlan 1 drop
```

show mac address-table

Syntax `show mac address-table [dynamic|static] [interface IF_PORTS] [vlan vlan-id]`
`show mac address-table [mac-addr] [vlan vlan-id]`

Parameter	dynamic	Display only dynamic MAC addresses
	static	Display only static MAC addresses
	Interface <i>IF_PORTS</i>	Display the MAC addresses entries for a specific interface.
	vlan <i>vlan-id</i>	Display the MAC address entries for a specific VLAN.
	<i>mac-addr</i>	Display entries for a specific MAC address

Default N/A

Mode Privileged EXEC

Usage To show the entry in the MAC address table, use the command `show mac address-table` in the Privileged EXEC mode.

Example

The following example displays the entire MAC address table.

```
Switch# show mac address-table
VID | MAC Address | Type | Ports
-----+-----+-----+-----
-
1 | DE:AD:BE:EF:01:02 | Management | CPU 1 | 00:01:02:03:04:05 |
Static | All 100 | 00:11:22:33:44:55 | Static | gi1 1 |
1C:E6:C7:8F:10:02 | Dynamic | fa3
1 | AA:BB:CC:DD:EE:FF | Static | All
1 | DE:AD:BE:EF:01:0C | Dynamic | gi1

Total number of entries: 6 Switch#
```

The following example displays the static MAC address configuration for the interface fa1.

```
Switch# show mac address-table static interfaces fa1
VID | MAC Address | Type | Ports
-----+-----+-----+-----
-
1 | 00:01:02:03:04:05 | Filtering | All
1 | AA:BB:CC:DD:EE:FF | Filtering | All

Total number of entries: 2 Switch#
```

The following example displays address table entries containing the specified MAC address.

```
Switch# show mac address-table 00:11:22:33:44:55 vlan 100
VID | MAC Address | Type | Ports
-----+-----+-----+-----
100 | 00:11:22:33:44:55 | Static | gi1

Total number of entries: 1
```

show mac address-table counters

Syntax `show mac address-table counters`

Parameter N/A

Default N/A

Mode Privileged EXEC

Usage To display the total entries in the MAC address table, use the command **show mac address-table counters** in the Privileged EXEC mode.

Example The following example display numbers of addresses in the address table.

```
Switch# show mac address-table counters
Total number of entries: 5
```

show mac address-table aging-time

Syntax show mac address-table aging-time

Parameter N/A

Default N/A

Mode Privileged EXEC

Usage To show MAC address aging time, use the command **show mac address-table aging-time** in the Privileged EXEC mode.

Example The following example displays aging time for the MAC address table.

```
Switch# show mac address-table aging-time
Mac Address Table aging time: 300 sec
```

MAC VLAN

vlan mac-vlan group (Global)

Syntax vlan mac-vlan group <1- 2147483647> mac-address mask <9-48>
no vlan mac-vlan group mac-address mask <9-48>

<Parameter	<1-2147483647>	Specify the group ID
	Mac-address	Specify the MAC address to be mapped.
	<9-48>	Specify the mask length of MAC address.

Default No MAC Groups are configured.

Mode Global Configuration

Usage Use the “**vlan mac-vlan group**” command to create MAC address group.

Use the **no** form of this command to delete specify group.

Example The following example shows how to create a MAC group with group ID 3.

```
Switch(config)# vlan mac-vlan group 333 22:33:44:55:66:77 mask 48
```

vlan mac-vlan group (Interface)

Syntax **vlan mac-vlan group** <1- 2147483647> **vlan** <1-4094>
no vlan mac-vlan [group <1- 2147483647>]

<Parameter <1-2147483647> Specify the group ID.
 (optional in no form) Delete all mapping group if not specify.

<1-4094> Specify the VLAN ID to give to match packet.

Default No mappings are configured.

Mode Interface Configuration

Usage Use the “**vlan mac-vlan group**” to create mapping of group and VLAN ID of an interface.

Use the **no** form of this command to delete mapping.

Example The following example shows how to mapping group id 333 to VLAN 100 on interface fa1.

```
Switch(config)# Interface fa1
Switch(config-if)# vlan mac-vlan group 333 VLAN 100
```

show vlan mac-vlan groups

Syntax **show vlan mac-vlan groups**

Default N/A

Mode Privileged EXEC

Usage Use the **show vlan mac-vlan groups** command to display mac groups configuration

Example This following example shows how to display mac group.

```
Switch# show vlan mac-vlan groups
Mac Address Mask Group Id
----- 22:33:44:55:66:77 48 222
44:55:66:77:88:99 48 333
88:99:00:aa:bb:cc 40 444
88:99:00:ab:bb:10 48 111
```

show vlan mac-vlan interfaces

Syntax **show vlan mac-vlan [interfaces IF_PORTS]**

Parameter IF_PORTS (Optional) Specify interfaces mac vlan to display.
Display all ports if not specify.

Default N/A

Mode Privileged EXEC

Usage Use the **show vlan mac-vlan interface** command in EXEC mode to display the mac-vlan interfaces setting

Example The following example shows how to display the MAC-Based VLAN interfaces setting

```
Switch# show vlan mac-vlan interfaces fa1
Port fa1 :
Mac based VLANs: Group ID Vlan ID
----- 333 444
444 1
```

Management ACL management access-list

Syntax **management access-list** NAME
 no management access-list NAME

Parameter	NAME	The name of management <u>ACL</u>
------------------	------	--------------------------------------

Default No management ACL is configured.

Mode Global Configuration

Usage Use the **management access-list** command to create a management access list and to enter management access-list configuration mode. The name of ACL must be unique that cannot have same name with other management ACL. Use the no form of this command to delete

Example The following example shows how to add a management ACL with name “test”

```
Switch(config)# management access-list test
```

management access-class

Syntax **management access-class** NAME
 no management access-class

Parameter	NAME	The name of management <u>ACL to be used.</u>
------------------	------	--

Default Default is no management ACL restrictions

Mode Global Configuration

Usage Use the **management access-class** command to activate a management ACL. Use the no form of this command to delete

Example

The following example shows how to add a management ACL with name "test"

```
Switch(config)# management access-list test
```

deny

Syntax [sequence <1-65535>] deny interfaces IF_PORTS service (all|http|https|snmp|ssh|telnet)

[sequence <1-65535>] deny ip A.B.C.D/A.B.C.D interfaces IF_PORTS service (all|http|https|snmp|ssh|telnet)

[sequence <1-65535>] deny ipv6 X:X::X:X/<0-128> interfaces IF_PORTS service (all|http|https|snmp|ssh|telnet)

Parameter	<1-65535>	(Optional) Specify sequence index of ACL entry, the sequence index represent the priority of an entry in ACL. If not specified, the switch assigns a number from 1 in ascending order.
interfaces IF_PORTS		Specify the interface ID or a list of interface IDs.
ip A.B.C.D/A.B.C.D		Specify the source IP address and mask of packet.
ipv6 X:X::X:X/<0-128>		Specify the source IPv6 address and prefix length of packet.
(all http https snmp ssh telnet)		Specify the type of services.
Default	No rules are configured.	

Mode Management Access-List Configuration

Usage Use the deny command to add deny rules that drop those packets hit the rule.

Example

The following example shows how to add a deny rule to drop all types of services packets that source ip is 1.1.1.1 from interface gi1.

```
Switch(config)# management access-list test
Switch(config-macl)# sequence 1 deny ip
1.1.1.1/255.255.255.255 interfaces gi1 service all
```

permit

Syntax

[sequence <1-65535>] permit interfaces IF_PORTS service (all|http|https|snmp|ssh|telnet)

[sequence <1-65535>] permit ip A.B.C.D/A.B.C.D interfaces IF_PORTS service (all|http|https|snmp|ssh|telnet)

[sequence <1-65535>] permit ipv6 X:X::X:X/<0-128> interfaces IF_PORTS service (all|http|https|snmp|ssh|telnet)

Parameter	<1-65535>	(Optional) Specify sequence index of ACL entry, the sequence index represent the priority of an entry in ACL. If not specified, the switch assigns a number from 1 in ascending order.
	interfaces <i>IF_PORTS</i>	Specify the interface ID or a list of interface IDs.
	ip A.B.C.D/A.B.C.D	Specify the source IP address and mask of packet.
	ipv6 X:X::X:X/<0-128>	Specify the source IPv6 address and prefix length of packet.
	(all http https snmp ssh telnet)	Specify the type of services.

Default No rules are configured.

Mode Management Access-List Configuration

Usage Use the permit command to add permit rules that bypass those packets hit the rule.

Example The following example shows how to add a permit rule to bypass http service packets that source ip is 2.2.2.2 from interface gi1.

```
Switch(config)# management access-list test
Switch(config-macl)# sequence 2 permit ip
2.2.2.2/255.255.255.255 interfaces gi1 service http
```

no sequence

Syntax **no sequence** <1-65535>

Parameter	<1-65535>	Specify sequence index of <u>ACL entry to delete.</u>
------------------	-----------	---

Default No rules are configured.

Mode Management Access-List Configuration

Usage Use the **no sequence** command to delete an entry in management ACL.

Example

The following example shows how to delete an entry.

```
Switch(config)# management access-list test
Switch(config-macl)# sequence 10 deny interfaces gi1 service all
Switch(config-macl)# no sequence 10
```

show management access-class

Syntax

show management access-class

Parameter

Default

No default is defined

Mode

Privileged EXEC

Usage Use the **show management access-class** command to show the active management access-list.

Example

The example shows how to show management access-class

```
Switch# show management access-class
Management access-class is enabled, using access-list test
```

show management access-list

Syntax **show management access-list** [NAME]

Parameter

NAME Specify the name of management ACL to displayed

Default

No default is defined

Mode

Privileged EXEC

Usage

Use the **show management access-list** command to show management ACL.

Example

The example shows how to show management access-list

```
Switch#Switch# show management access-list 1 management access-list is
created
test
----
sequence 1 deny ip 1.1.1.1/255.255.255.255 interfaces gi1 service all
! (Note: all other access implicitly denied)
```

Mirror

mirror session destination interface

mirror session <1-4> **destination interface** *IF_NMLPORT* [**allow-ingress**]
no mirror session <1-4> **destination interface** *IF_NMLPORT*
no mirror session (<1-4> | **all**)

<Parameter>	<1-4>	Specify the mirror session to configure
	<i>IF_NMLPORT</i>	Specify the SPAN destination. A destination must be a physical port
	allow-ingress	Enable ingress traffic forwarding.

Default No monitor sessions are configured.

Mode Global Configuration

Usage Use the “**mirror session destination interface**” command to start a destination interface of a port mirror session.

Use the **no** form of this command to stop a destination interface of a port mirroring session.

Use the “**no mirror session**” command to disable all mirror sessions or specific mirror session.

Example The following example shows how to create a local session 1 to monitor both sent and received traffic on source port fa1.

```
Switch(config)# mirror session 1 destination interface fa1
Switch# show mirror session 1 Session 1 Configuration Source RX
Port : fa2-5 Source TX Port : fa2-5 Destination port : fa1 Ingress
State: disabled
```

mirror session source interface

Syntax **mirror session** <1-4> **source interfaces** *IF_PORTS* (**both** | **rx** | **tx**)
no mirror session <1-4> **source interfaces** *IF_PORTS* (**both** | **rx** | **tx**)
no mirror session (<1-4> | **all**)

<Parameter>	<1-4>	Specify the mirror session to configure
	<i>IF_PORTS</i>	Specify the source interface, Valid interfaces include physical ports and port channels.
	both	Mirror tx and rx direction

rx	Mirror rx direction only
tx	Mirror tx direction only

Default No monitor sessions are configured.

Mode Global Configuration

Usage Use the “**mirror session source interface**” command to start a port mirror session.

Use the **no** form of this command to stop a port mirroring session.

Use the “**no mirror session**” command to disable all mirror sessions or specific mirror session.

Example The following example shows how to create a local SPAN session 1 to monitor both sent and received traffic on source port fa1.

```
Switch(config)# mirror session 1 source interface fa2-5 both
Switch(config)# mirror session 1 destination interface fa1
Switch(config)# show mirror session 1
Session 1 Configuration Source RX Port : fa2-5 Source TX Port :
fa2-5 Destination port : fa1 Ingress State: disabled
```

show mirror

Syntax **show mirror [session <1-4>]**

Parameter **<1-4>** Specify the mirror session to display

Default N/A

Mode Privileged EXEC

Usage Use the **show mirror** command to display mirror session configuration

Example

This following example shows how to display mirror session configuration

```
Switch(config)# show mirror Session 1 Configuration Source RX
Port : fa2-5 Source TX Port : fa2-5
Destination port : fa1
```

Ingress State: disabled

Session 2 Configuration Mirrored source : Not Config Destination port : Not Config

Session 3 Configuration Mirrored source : Not Config Destination port : Not Config

Session 4 Configuration Mirrored source : Not Config
Destination port : Not Config

MLD Snooping

ipv6 mld snooping

Syntax ipv6 mld snooping no ipv6 mld snooping

Parameter	None
------------------	------

Default	Default is disabled
----------------	---------------------

Mode	Global Configuration
-------------	----------------------

Usage	Use the ipv6 mld snooping command to enable MLD snooping function. Use the no form of this command to disable. Disable will clear all ipv6 mld snooping dynamic group and dynamic router port, and make the static ipv6 mld group invalid. No more dynamic group and router port by mld message will be learned. You can verify settings by the show ipv6 mld snooping command.
--------------	--

Example	The following example specifies that set ipv6 mld snooping test. Switch(config)# ipv6 mld snooping
----------------	---

ipv6 mld snooping report-suppression

Syntax	ipv6 mld snooping report-suppression
---------------	---

no ipv6 mld snooping report-suppression

Parameter	none
Default	Default is enabled
Mode	Global Configuration
Usage	Use the ipv6 mld snooping report-suppression command to enable MLD snooping report-suppression function. Use the no form of this command to disable. Disable report-suppression will forward all received reports to the vlan router ports. You can verify settings by the show ipv6 mld snooping command.
Example	The following example specifies that disable ipv6 mld snooping report-suppression test. Switch(config)# no ipv6 mld snooping report-suppression

ipv6 mld snooping version

Syntax ipv6 mld snooping version (1|2)

Parameter	(1 2)	Ipv6 mld snooping running version 1 or 2
Default		Default is version 1
Mode		Global Configuration

Usage Use the **ipv6 mld snooping version** command to change MLD support version. Version 2 packet won't be processed if choose version 1.
You can verify settings by the **show ip igmp snooping** command.

Example The following example specifies that set ipv6 mld snooping version 2.
Switch(config)# **ipv6 mld snooping version 2**

ipv6 mld snooping unknown-multicast action

Syntax `ipv6 mld snooping unknown-multicast action (drop | flood | router-port)`
`_no ipv6 mld snooping unknown-multicast action`

Parameter (drop | flood | router-port) Drop, flood in vlan or forward to router port of unknown multicast packet

Default Default is flood.

Mode Global Configuration

Usage When igmp and mld snooping disabled, it can't set action router-port.

When disable igmp snooping & mld snooping, it set unknown multicast action flood. When action is router-port to flood or drop, it will delete the unknown multicast group entry.

Use the **ipv6 mld snooping unknown-multicast action** command to change action.

Use the **no** form of this command to restore to default.

You can verify settings by the **show ipv6 mld snooping** command.

Example The following example specifies that set ipv6 mld unknown multicast action router-port test.
Switch(config)# **ipv6 mld snooping unknown-multicast action router-port**

ipv6 mld snooping vlan

Syntax `ipv6 mld snooping vlan VLAN-LIST`
`no ipv6 mld snooping vlan VLAN-LIST`

Parameter VLAN-LIST specifies VLAN ID list to set

Default Default is disabled for all VLANs

Mode Global Configuration

Usage Disable will clear all ipv6 mld snooping dynamic group and dynamic router port and make all static ip igmp group invalid of this vlan. Will not learn dynamic group and router port by igmp message any more.

Use the **ipv6 mld snooping vlan** command to enable MLD on VLAN. Use the **no** form of this command to disable

You can verify settings by the **show ipv6 mld snooping vlan** command.

Example

The following example specifies that set ipv6 mld snooping vlan test.
Switch(config)# **ipv6 mld snooping vlan 1**

ipv6 mld snooping vlan parameters

Syntax

```

ipv6 mld snooping vlan <VLAN-LIST> last-member-query-count <1-7>
no ipv6 mld snooping vlan <VLAN-LIST> last-member-query-count
ipv6 mld snooping vlan <VLAN-LIST> last-member-query-interval <1- 60>

no ipv6 mld snooping vlan <VLAN-LIST> last-member-query-interval
[no] ipv6 mld snooping vlan <VLAN-LIST> router learn pim-dvmrp
[no] ipv6 mld snooping vlan <VLAN-LIST> fastleave
ipv6 mld snooping vlan <VLAN-LIST> query-interval <30-18000>
no ipv6 mld snooping vlan <VLAN-LIST> query-interval
ipv6 mld snooping vlan <VLAN-LIST> response-time <5-20>
no ipv6 mld snooping vlan <VLAN-LIST> response-time
ipv6 mld snooping vlan <VLAN-LIST> robustness-variable <1-7>
no ipv6 mld snooping vlan <VLAN-LIST> robustness-variable

```

Parameter VLAN-LIST specifies VLAN ID list to set

last-member-query- count <1-7>

last-member-query- interval <1-60>

query-interval <30-18000>

response-time <5-20>

robustness-variable

specifies last member query count to set. Default is 2 specifies last member query interval to set. Default is 1 specifies query interval to set. Default is 125

specifies a response time to set. default is 10

specifies a robustness value to set, default is 2

<1-7>

Default **no ipv6 mld snooping vlan 1-4094 last-member-query-count no ipv6 mld snooping vlan 1-4094 last-member-query-interval ipv6 mld snooping vlan 1-4094 router learn pim-dvmrp no ipv6 mld snooping vlan 1-4094 fastleave no ipv6 mld snooping vlan 1-4094 query-interval no ipv6 mld snooping vlan 1-4094 response-time no ipv6 mld snooping vlan 1-4094 robustness-variable**

Mode Global Configuration

Usage ‘no ipv6 mld snooping vlan 1 (last-member-query-count | last-member-query-interval | query-interval | response-time | robustness-variable)’ will set the vlan parameters to default.

The cli setting will change the ipv6 mld vlan parameters admin settings. The configure can use ‘show ipv6 mld snooping vlan 1’.

Example The following example specifies that set ipv6 mld snooping vlan parameters test.

```
Switch(config)# ipv6 mld snooping vlan 1 fastleave
Switch(config)# ipv6 mld snooping vlan 1 last-member-query-count 5
Switch(config)# ipv6 mld snooping vlan 1 last-member-query-interval 3
Switch(config)# ipv6 mld snooping vlan 1 query-interval 100 Switch(config)#
ipv6 mld snooping vlan 1 response-time 12 Switch(config)# ipv6 mld snooping
vlan 1 robustness-variable 4 Switch# show ipv6 mld snooping vlan 1
MLD Snooping is globally enabled
MLD Snooping VLAN 1 admin : disabled MLD Snooping oper mode : disabled
MLD Snooping robustness: admin 4 oper 2
MLD Snooping query interval: admin 100 sec oper 125 sec MLD Snooping
query max response : admin 12 sec oper 10 sec MLD Snooping last member
query counter: admin 5 oper 2
MLD Snooping last member query interval: admin 3 sec oper 1 sec MLD
Snooping last immediate leave: enabled
MLD Snooping automatic learning of multicast router ports: enabled
```

ipv6 mld snooping vlan fastleave

Syntax **ipv6 mld snooping vlan <VLAN-LIST> fastleave**
_no ipv6 mld snooping vlan <VLAN-LIST> fastleave

Parameter	VLAN-LIST	specifies VLAN ID list to set
-----------	-----------	-------------------------------

Default	Default is disabled
----------------	---------------------

Mode Global Configuration

Usage Use the **ipv6 mld snooping vlan fastleave** command to enable fastleave function. Group will remove port immediately when receive leave packet. Use the **no** form of this command to disable.

You can verify settings by the **show ipv6 mld snooping vlan** command

Example The following example specifies that set ipv6 mld snooping vlan fastleave test.
Switch(config)# **ipv6 mld snooping vlan 1 fastleave**

ipv6 mld snooping vlan last-member-query-count

Syntax **ipv6 mld snooping vlan <VLAN-LIST> last-member-query-count <1-7>**
no ipv6 mld snooping vlan <VLAN-LIST> last-member-query-count

Parameter **VLAN-LIST** specifies VLAN ID list to set
last-member-query-count <1-7> specifies last member query count to set

Default Default is 2

Mode Global Configuration

Usage Use the **ipv6 mld snooping vlan last-member-query-count** command to change how many query packets will send.

Use the **no** form of this command to restore to default.

You can verify settings by the **show ipv6 mld snooping vlan** command

Example The following example specifies that set **ipv6 mld snooping vlan last-member-query-count** test.
Switch(config)# **ipv6 mld snooping vlan 1 last-member-query-count 5**

ipv6 mld snooping vlan last-member-query-interval

Syntax **ipv6 mld snooping vlan <VLAN-LIST> last-member-query-interval <1- 60>**
no ipv6 mld snooping vlan <VLAN-LIST> last-member-query-interval

Parameter **VLAN-LIST** specifies VLAN ID list to set

last-member-query- specifies last member query interval to set
interval <1-60>

Default Default is 1

Mode Global Configuration

Usage Use the **ipv6 mld snooping vlan last-member-query-interval** command to set interval between each query packet.
 Use the **no** form of this command to restore to default

You can verify settings by the **show ipv6 mld snooping vlan** command

Example The following example specifies that set **ipv6 mld snooping vlan last- member- query-interval** test.
 Switch(config)# **ipv6 mld snooping vlan 1 last-member-query-interval 3**

ipv6 mld snooping vlan query-interval

Syntax **ipv6 mld snooping vlan <VLAN-LIST> query-interval <30-18000>**
no ipv6 mld snooping vlan <VLAN-LIST> query-interval

Parameter VLAN-LIST specifies VLAN ID list to set
 query-interval <30- specifies query interval to set
18000>

Default Default is 125

Mode Global Configuration

Usage Use the **ipv6 mld snooping vlan query-interval** command to set interval between each query.
 Use the **no** form of this command to restore to default
 You can verify settings by the **show ipv6 mld snooping vlan** command

Example The following example specifies that set **ipv6 mld snooping vlan query- interval** test.
 Switch(config)# **ipv6 mld snooping vlan 1 query-interval 100**

ipv6 mld snooping vlan response-time

Syntax `ipv6 mld snooping vlan <VLAN-LIST> response-time <5-20>`
`no ipv6 mld snooping vlan <VLAN-LIST> response-time`

Parameter `VLAN-LIST` specifies VLAN ID list to set
`response-time <5-20>` specifies a response time to set

Default Default is 10

Mode Global Configuration

Usage Use the `ipv6 mld snooping vlan response-time` command to set response time.

Use the `no` form of this command to restore to default.

You can verify settings by the `show ipv6 mld snooping vlan` command

Example The following example specifies that set `ipv6 mld snooping vlan response-time` test.
`Switch(config)# ipv6 mld snooping vlan 1 response-time 12`

ipv6 mld snooping vlan robustness-variable

Syntax `ipv6 mld snooping vlan <VLAN-LIST> robustness-variable <1-7>`
`no ipv6 mld snooping vlan <VLAN-LIST> robustness-variable`

Parameter `VLAN-LIST` specifies VLAN ID list to set
`robustness-variable` specifies a robustness value to set
`<1-7>`

Default Default is 2

Mode Global Configuration

Usage Use the `ipv6 mld snooping vlan robustness-variable` command to times to retry.

Use the `no` form of this command to restore to default

You can verify settings by the **show ipv6 mld snooping vlan** command

Example The following example specifies that set ipv6 mld snooping vlan parameters test.
Switch(config)# **ip igmp snooping vlan 1 robustness-variable**

ipv6 mld snooping vlan router

Syntax **ipv6 mld snooping vlan VLAN-LIST router learn pim-dvmrp**
_no ipv6 mld snooping vlan VLAN-LIST router learn pim-dvmrp

Parameter **VLAN-LIST** specifies VLAN ID list to set

Default Default is enabled

Mode Global Configuration

Usage Use the **ipv6 mld snooping vlan router** command to enable learning router port by routing protocol packets such as PIM/PIMv2, DVMRP, MOSPF. Use the **no** form of this command to disable. You can verify settings by the **show ipv6 mld snooping vlan** command

Example The following example specifies that set **ipv6 mld snooping vlan router** test.
Switch(config)# **ipv6 mld snooping vlan 99 router**

ipv6 mld snooping vlan static-port

Syntax **ipv6 mld snooping vlan <VLAN-LIST> static-port IF_PORTS**
_no ipv6 mld snooping vlan <VLAN-LIST> static-port IF_PORTS

Parameter **VLAN-LIST** specifies VLAN ID list to set
IF_PORTS specifies a port list to set or remove

Default No static port by default

Mode Global Configuration

Usage

Use the **ipv6 mld snooping vlan static-port** command to add static forwarding port, all known vlan 1 ipv6 group will add the static ports. Use the **no** form of this command to delete static port.

You can verify settings by the **show ipv6 mld snooping forward-all** command.

Example

The following example specifies that set ipv6 mld snooping static port test.
Switch(config)# **ipv6 mld snooping vlan 1 static -port gi1-2**

ipv6 mld snooping vlan forbidden-router-port

Syntax

ipv6 mld snooping vlan <VLAN-LIST> forbidden-router-port IF_PORTS
no ipv6 mld snooping vlan <VLAN-LIST> forbidden-router-port _IF_PORTS

Parameter

VLAN-LIST	specifies VLAN ID list to set
IF_PORTS	specifies a port list to set or remove

Default

No forbidden router ports by default

Mode

Global Configuration

Usage

Use the **ipv6 mld snooping vlan forbidden-router-port** command to add static forbidden router port. This will also remove port from static router port. The forbidden router port will not forward received query packet

.Use the **no** form of this command to delete forbidden router port.

You can verify settings by the **show ipv6 mld snooping router** command.

Example

The following example specifies that set ipv6 mld snooping forbidden test.
Switch(config)# **ipv6 mld snooping vlan 1 forbidden-router-port gi2**

ipv6 mld snooping vlan forbidden-router-port

Syntax

ipv6 mld snooping vlan <VLAN-LIST> forbidden-router-port IF_PORTS
no ipv6 mld snooping vlan <VLAN-LIST> forbidden-router-port _IF_PORTS

Parameter

VLAN-LIST	specifies VLAN ID list to set
IF_PORTS	specifies a port list to set or remove

Default No forbidden router ports by default

Mode Global Configuration

Usage Use the **ipv6 mld snooping vlan forbidden-router-port** command to add static forbidden router port. This will also remove port from static router port. The forbidden router port will not forward received query packet
 .Use the **no** form of this command to delete forbidden router port.
 You can verify settings by the **show ipv6 mld snooping router** command.

Example The following example specifies that set ipv6 mld snooping forbidden test.
 Switch(config)# **ipv6 mld snooping vlan 1 forbidden-router-port gi2**

ipv6 mld snooping vlan static router port

Syntax **ipv6 mld snooping vlan <VLAN-LIST> static-router-port IF_PORTS**
no ipv6 mld snooping vlan <VLAN-LIST> static-router-port IF_PORTS

Parameter	VLAN-LIST	specifies VLAN ID list to set
	IF_PORTS	specifies a port list to set or remove

Default None static router ports by default

Mode Global Configuration

Usage Use the **ipv6 mld snooping vlan static-router-port** command to add static router port. All query packets will forward to this port.
 Use the **no** form of this command to delete static router port.
 You can verify settings by the **show ipv6 mld snooping router** command..

Example The following example specifies that set ipv6 mld snooping static test.
 Switch(config)# **ipv6 mld snooping vlan 1 static-router-port gi1-2**

ipv6 mld snooping vlan static-group

Syntax **ipv6 mld snooping vlan <VLAN-LIST> static-group [<ipv6-addr>]**
interfaces IF_PORTS
no ipv6 mld snooping vlan <VLAN-LIST> static-group <ipv6-addr>
interfaces IF_PORTS

Parameter	VLAN-LIST	specifies VLAN ID list to set
	Ipv6-addr	specifies multicast group ipv4 address

	IF_PORTS	specifies port list to set or remove
--	----------	--------------------------------------

Default No static group by default

Mode Global Configuration

Usage Use the **ipv6 mld snooping vlan static-group** command to add a static group. The static group will not learn other dynamic ports. If the dynamic group exists, then the static group will overlap the dynamic group. The static group set to valid unless igmp snooping global and vlan enable.

Use the **no** form of this command to delete a port in static group. If remove the last member of static group, the static group will be delete.

You can verify settings by the **show ipv6 mld snooping group** command.

Example The following example specifies that set ipv6 mld snooping static group test.
Switch(config)# **ipv6 mld snooping vlan 1 static-group ff13::1 interfaces gi1-2**

ipv6 mld snooping vlan group

Syntax no ipv6 mld snooping vlan <VLAN-LIST> group <ipv6-addr>

Parameter	VLAN-LIST	specifies VLAN ID list to set
	ipv6-addr	specifies multicast group ipv6 address

Default None

Mode Global Configuration

Usage Use the **no ipv6 mld snooping vlan group** command to delete a group which could be static or dynamic. You can verify settings by the **show ipv6 mld snooping group** command.

Example

The following example specifies that set ip igmp snooping static group test.
Switch(config)# **no ip igmp snooping vlan 1 group ff13::1**

profile range

Syntax

profile range ipv6 <ipv6-addr> [ipv6-addr] action (permit | deny)

<ipv6-addr>	Start ipv6 multicast address
[ipv6-addr]	End ipv6 multicast address
(permit deny)	Permit: allow Multicast address range ip address learning deny: do not allow Multicast address range ip address learning

Default

None

Mode

mld profile configuration mode

Usage

Use the **profile** command to generate MLD profile.
You can verify settings by the **show ipv6 mld profile** command

Example

The following example specifies that set ipv6 mld profile test. Switch(config)#
ipv6 mld profile 1
Switch(config-mld-profile)# **profile range ipv6 ff13::1 ff13::10 action permit**

ipv6 mld profile

Syntax

ipv6 mld profile <1-128>
no ipv6 mld profile <1-128>

Parameter

<1-128> specifies profile ID

Default

No profile exist by default

Mode

Global Configuration

Usage Use the **ipv6 mld profile** command to enter profile configuration Use the **no** form of this command to delete

profile

You can verify settings by the **show ipv6 mld profile** command

Example The following example specifies that set ipv6 mld profile test. Switch(config)#
ipv6 mld profile 1
Switch(config-mld-profile)# **profile range ipv6 ff13::1 ff13::10 action permit**

ipv6 mld filter

Syntax **ipv6 mld filter <1-128>**
no ipv6 mld filter

Parameter <1-128> specifies profile ID

[interfaces Specifies interfaces to display
IF_PORTS]

Default None

Mode Port Configuration

Usage Use the **ipv6 mld filter** command to bind a profile for port. When the port bind a profile. Then the port learning group will update, if the group is not match the profile rule it will remove the port from the group. Static group is excluded.

Use the **no** form of this command to delete profile

You can verify settings by the **show ipv6 mld filter** command

Example The following example specifies that set ipv6 mld filter test.

Switch(config)# **interface gi1**
Switch(config-if)# **ipv6 mld filter 1**

ipv6 mld max-groups

Syntax **ipv6 mld max-groups <0-1024>**
no ipv6 mld max-groups

Parameter <0-1024> specifies profile ID

Default Default is 1024

Mode Port Configuration

Usage Use the **ipv6 mld max-groups** command to limit port learning max group number. When the port has reach limitation, new group will not add this port. Static group is excluded.

Use the **no** form of this command to restore to default
 You can verify settings by the **show ipv6 mld max-groups** command.

Example The following example specifies that set ipv6 mld max-groups test.
 Switch(config)# **interface gil**
 Switch(config-if)# **ipv6 mld max-groups 10**

ip igmp max-groups action

Syntax **ipv6 mld max-groups action (deny | replace)**

Parameter (deny | replace) Deny: current port igmp group arrived max-groups, don't add group.

Replace: current port igmp group arrived max-groups, remove port for rand group, and add port to new group.

Default Default action is deny

Mode Interface mode

Usage Use the **ipv6 mld max-groups action** command to set the action when the numbers of groups reach the limitation.

Use the **no** form of this command to restore to default
 You can verify settings by the **show ipv6 mld max-groups** command.

Example The following example specifies that set action replace test. Switch(config-if)#**ipv6 mld max-groups action replace**

clear ipv6 mld snooping groups

Syntax **clear ipv6 mld snooping groups [(dynamic | static)]**

Parameter **None** Clear ipv6 mld groups include dynamic and static
 (dynamic | static) ipv6 mld group type is dynamic or static

Default None

Mode Privileged EXEC

Usage This command will clear the ipv6 mld groups for dynamic or static or all of type. You can verify settings by the **show ipv6 mld snooping groups** command..

Example The following example specifies that clear ipv6 mld snooping groups test.
Switch# **clear ipv6 mld snooping groups static**

clear ipv6 mld snooping statistics

Syntax clear ipv6 mld snooping statistics

Parameter none

Default None

Mode Privileged EXEC

Usage This command will clear the igmp statistics. You can verify settings by the **show ipv6 mld snooping** command.

Example The following example specifies that clear ipv6 mld snooping statistics test.
Switch# **clear ipv6 mld snooping statistics**

show ipv6 mld snooping groups counters

Syntax show ipv6 mld snooping groups counters

Parameter none

Default None

Mode Privileged EXEC

Usage This command will display the ipv6 mld group counter include static group.

Example The following example specifies that display ipv6 mld snooping group counter test.
 Switch# **show ipv6 mld snooping group counters**
Total ipv6 mld snooping group number: 2

show ipv6 mld snooping groups

Syntax `show ipv6 mld snooping groups [(dynamic | static)]`

Parameter none Show ipv6 mld groups include dynamic and static
 (dynamic | static) Display ipv6 mld group type is dynamic or static

Default display all ipv6 mld groups

Mode Privileged EXEC

Usage This command will display the ipv6 mld groups for dynamic or static or all of type.

Example The following example specifies that show ipv6 mld snooping groups test.
 Switch# **show ipv6 mld snooping groups**
 VLAN | Group IP Address | Type | Life(Sec) | Port
 -----+-----+-----+-----+-----
 1 | ff13::1 | Static | -- | fa1
 1 | ff13::2 | Static | -- | fa2

Total Number of Entry = 2

show ipv6 mld snooping router

Syntax `show ipv6 mld snooping router [(dynamic | forbidden |static)]`

Parameter none Show ipv6 mld router include dynamic and static and forbidden

(dynamic | forbidden | static) Display ipv6 mld router info for different type

Default None

Mode Privileged EXEC

Usage This command will display the ipv6 mld router info.

Example The following example specifies that show ipv6 mld snooping router test. Switch#

show ipv6 mld snooping router

Dynamic Router Table
VID | Port | Expiry Time(Sec)

-----+-----+-----

Total Entry 0

Static Router Table VID | Port Mask

-----+-----

1 | fa5

Total Entry 1

Forbidden Router Table VID | Port Mask

-----+-----

Total Entry 0

show ipv6 mld snooping

Syntax show ipv6 mld snooping

Parameter none

Default None

Mode Privileged EXEC

Usage This command will display ipv6 mld snooping global info.

Example The following example specifies that show ipv6 mld snooping test. Switch# **show ipv6 mld snooping**
MLD Snooping Status

 Snooping : Disabled Report Suppression : Enabled
 Operation Version : v1
 Forward Method : mac Unknown Multicast Action : Flood

 Packet Statistics
 Total RX : 0
 Valid RX : 0
 Invalid RX : 0
 Other RX : 0
 Leave RX : 0
 Report RX : 0
 General Query RX : 0 Specail Group Query RX : 0 Specail Group & Source Query
 RX : 0 Leave TX : 0
 Report TX : 0
 General Query TX : 0 Specail Group Query TX : 0
Specail Group & Source Query TX : 0

show ipv6 mld snooping vlan

Syntax **show ipv6 mld snooping vlan [VLAN-LIST]**

Parameter	none	Show all ipv6 mld snooping vlan info
	[VLAN-LIST]	Show specifies vlan ipv6 mld snooping info

Default Show all ipv6 mld snooping vlan info

Mode Privileged EXEC

Usage This command will display ipv6 mld snooping vlan info.

Example The following example specifies that show ipv6 mld snooping vlan test. Switch#
show ipv6 mld snooping vlan 1
 MLD Snooping is globally disabled
 MLD Snooping VLAN 1 admin : disabled MLD Snooping oper mode : disabled
 MLD Snooping robustness: admin 2 oper 2
 MLD Snooping query interval: admin 125 sec oper 125 sec MLD Snooping query
 max response : admin 10 sec oper 10 sec MLD Snooping last member query
 counter: admin 2 oper 2
 MLD Snooping last member query interval: admin 1 sec oper 1 sec MLD
 Snooping last immediate leave: disabled
MLD Snooping automatic learning of multicast router ports: enabled

show ipv6 mld snooping forward-all

Syntax **show ipv6 mld snooping forward-all [vlan VLAN-LIST]**
Parameter none Show all ipv6 mld snooping vlan forward-all info
[vlan VLAN-LIST] Show specifies vlan of ipv6 mld forward info.

Default Show all vlan ipv6 mld forward all info

Mode Privileged EXEC

Usage This command will display ipv6 mld snooping forward all info.

Example The following example specifies that show ipv6 mld snooping forward-all test.
 Switch# **show ipv6 mld snooping forward-all**
 MLD Snooping VLAN 1
 MLD Snooping static port : None
MLD Snooping forbidden port : None

show ipv6 mld profile

Syntax **show ipv6 mld profile [<1-128>]**
Parameter none Show all ipv6 mld snooping profile info
[<1-128>] Show specifies index profile info

Default Show all ipv6 mld profile info

Mode Privileged EXEC

Usage This command will display ipv6 mld profile info.

Example The following example specifies that show ipv6 mld profile test. Switch# **show ipv6 mld profile**
 IPv6 mld profile index: 1
 IPv6 mld profile action: permit Range low ip: ff13::1
Range high ip: ff13::10

show ipv6 mld filter

Syntax **show ipv6 mld filter [interfaces IF_PORTS]**
Parameter none Show all port filter
 [interfaces IF_PORTS] Show specifies ports filter

Default None

Mode Privileged EXEC

Usage This command will display ipv6 mld port filter info.

Example The following example specifies that show ipv6 mld filter test. Switch# **show ipv6 mld filter**
 Port ID | Profile ID
 -----+-----
 gi1 : 1
 gi2 : None gi3 : None gi4 : None gi5 : None
--More--

show ipv6 mld max-group

Syntax **show ipv6 mld max-group [interfaces IF_PORTS]**
Parameter none Show all port max-group
 [interfaces IF_PORTS] Show specifies ports max-group

Default None

Mode Privileged EXEC

Usage This command will display ipv6 mld port max-group.

Example The following example specifies that show ipv6 mld max-group test.
 Switch(config-if)# **ipv6 mld max-groups 50**
 Switch# **show ipv6 mld max-group**
 Port ID | Max Group
 -----+-----
 gi1 : 50
 gi2 : 256
 gi3 : 256
 gi4 : 256
 gi5 : 256
 --More--

show ipv6 mld port max-group action

Syntax **show ipv6 mld max-group action [interfaces IF_PORTS]**

Parameter **none** Show all port max-group action
 [interfaces IF_PORTS] Show specifies ports max-group action

Default Show all ports ipv6 mld max-group action

Mode Privileged EXEC

Usage This command will display ipv6 mld port max-group action.

Example The following example specifies that show ipv6 mld max-group action test.
 Switch(config-if)# **ipv6 mld max-groups action replace**
 Switch# **show ipv6 mld max-group action**
 Port ID | Max-groups Action
 -----+-----
 gi1 : replace gi2 : deny gi3 : deny gi4 : deny gi5 : deny
 --More--

MVR

mvr

Syntax	mvr no mvr
Parameter	None
Default	Default is disabled
Mode	Global Configuration
Usage	Use the mvr command to enable MVR function. The command will clear all mvr VLAN ID multicast snooping group. Use the no form of this command to disable. Disable will clear all mvr group. You can verify settings by the show mvr command.
Example	The following example specifies that set mvr test. Switch(config)# mvr Switch(config)# no mvr Switch# show mvr MVR Running : Disabled MVR Multicast VLAN : 1 MVR Group Range : None MVR Max Multicast Groups : 128 MVR Current Multicast Groups : 0 MVR Global query response time : 1 sec <u>MVR Mode : compatible</u>

mvr vlan

Syntax **mvr vlan** <VLAN-ID>

Parameter	<VLAN-ID>	The exist static vlan id
Default	Default mvr vlan id is 1	
Mode	Global Configuration	

Usage Use the **mvr vlan** command to modify mvr vlan id when the mvr status is enabled. Change mvr vlan id will delete the old mvr vlan and new mvr vlan group. If there have configure source or receiver port, there will check the source must only in the mvr vlan , and receiver port must not in the mvr vlan member. You can verify settings by the **show mvr** command.

Example The following example specifies that configure mvr vlan 2 test. Switch(config)#
vlan 2
 Switch(config)# **mvr**
The operation will delete groups of VLAN ID is MVR VLAN include static groups. Continue? [yes/no]:y
 Switch(config)# **mvr vlan 2**
The operation will delete the old and new MVR VLAN groups include static MVR groups.Continue? [yes/no]:y

mvr group

Switch# **show mvr**
 MVR Running : Enabled **MVR Multicast VLAN : 2** MVR Group Range : None
 MVR Max Multicast Groups : 128 MVR Current Multicast Groups : 0 MVR Global query response time : 1 sec
 MVR Mode : compatible

mvr group <ip-address> [<1-128>]

< ip-address>	Start MVR IP multicast address
[<1-128>]	Contiguous series of IP addresses.

Default None

Mode Global Configuration

Usage Use the **mvr group** command to configure mvr group address range when mvr is enabled. The command will delete all mvr vlan ipv4 group entry You can verify settings by the **show mvr** command

Example The following example specifies that set mvr group range is 224.1.1.1 ~ 224.1.1.8 test. Switch(config)# **mvr**
 Switch(config)# **mvr group 224.1.1.1 8**
The operation will delete the MVR VLAN groups include static MVR groups.Continue? [yes/no]:y
 Switch# **show mvr**
 MVR Running : Enabled MVR Multicast VLAN : 2
MVR Group Range : 224.1.1.1 ~ 224.1.1.8
 MVR Max Multicast Groups : 128 MVR Current Multicast Groups : 0 MVR Global query response time : 1 sec
MVR Mode : compatible

mvr mode

Syntax **mvr mode (dynamic | compatible)**

Parameter	(dynamic compatible)	dynamic: Allows dynamic MVR membership on
-----------	----------------------	---

source ports
 compatible: does not support IGMP dynamic joins
on source ports.

Default Default is compatible.

Mode Global Configuration

Usage Use the **mvr mode** command to change mvr mode when mvr is enabled. You can verify settings by the **show mvr** command.

Example

The following example specifies that set mvr mode dynamic test.

```
Switch(config)#mvr
Switch(config)#mvr mode dynamic
Switch# show mvr
MVR Running : Enabled MVR Multicast VLAN : 2
MVR Group Range : 224.1.1.1 ~ 224.1.1.8
MVR Max Multicast Groups : 128 MVR Current Multicast Groups : 0 MVR
Global query response time : 1 sec
MVR Mode : dynamic
```

mvr query-time

Syntax **mvr query-time <1-10>**
 no mvr query-time

Parameter <1-10> specifies query response time is 1~10 sec.

Default Default is 1 sec

Mode Global Configuration

Usage Use the **mvr query-time** command to configure when mvr is enabled.
Use the **no** form of this command to set query-time default value. You can verify settings by the **show mvr** command.

Example

The following example specifies that set mvr query-time 10 sec test.

```
Switch(config)# mvr
Switch(config)# mvr query-time 10
Switch# show mvr
```

```
Switch(config)# mvr query-time 10
Switch# show mvr
MVR Running : Enabled MVR Multicast VLAN : 2
MVR Group Range : 224.1.1.1 ~ 224.1.1.8
MVR Max Multicast Groups : 128 MVR Current Multicast Groups : 0
MVR Global query response time : 10 sec
MVR Mode : dynamic
```

mvr port type

Syntax **mvr type (source | receiver)**
 no mvr type

Parameter	(source receiver)	Source: Configure uplink ports that receive and send multicast data as source ports. Subscribers cannot be directly connected to source ports. All source ports on a switch belong to the single multicast VLAN. Receiver: Configure a port as a receiver port if it is a subscriber port and should only receive multicast data. It does not receive data unless it becomes a member of the multicast group, either statically or by using IGMP leave and join messages. Receiver ports cannot belong to the <u>multicast VLAN.</u>
Default	None	
Mode	Port Configuration	

Usage Use the **mvr type** command to configure mvr port type when mvr is enabled.

The source port must only belong to mvr vlan. The receiver port must not belong to mvr vlan, and port mode must be access mode.

Use the **no** form of this command to set mvr type none

You can verify settings by the **show mvr interface** command

Example The following example specifies that set gi1 fa1 is source port , fa2 is receiver port test.
 Switch(config)# **vlan 2** Switch(config-vlan)#**exit** Switch(config)#**mvr**
Switch(config)#**mvr vlan 2**

```
Switch(config)#mvr group 224.1.1.1 8
Switch(config)# interface gi1
Switch(config-if)# switchport trunk allowed vlan 2
Switch(config-if)# mvr type source Switch(config-if)#exit Switch(config)# interface gi2
Switch(config-if)# switchport mode access Switch(config-if)#mvr type receiver Switch# show mvr interface
Port | Type | Immediate Leave
-----+-----+-----
gi1 | Source| Disabled
gi2 | Receiver| Disabled
```

mvr port immediate

Syntax	mvr immediate no mvr immediate
---------------	---

Parameter	None
Default	Default is disabled
Mode	Port Configuration

Usage Use the **mvr immediate** command to configure mvr support immediate leave when mvr is enabled.

Note This command applies to only receiver ports and should only be enabled on receiver ports to which a single receiver device is connected.

Use the **no** form of this command to disable immediate leave. You can verify settings by the **show mvr interface** command

Example The following example specifies that set gi2 immediate enable test. The configure should configure mvr receiver port firstly.(eg. mvr port type) Switch(config)# **interface gi2**
Switch(config-if)#**mvr immediate** Switch(config-if)#**exit** Switch(config)# **exit**
Switch# **show mvr interface**
Port | Type | Immediate Leave
-----+-----+-----
gi1 | Source| Disabled
gi2 | Receiver| **Enabled**

mvr static group

Syntax **mvr vlan <VLAN-ID> group <ip-addr> interfaces IF_PORTS no mvr vlan <VLAN-ID> group <ip-addr> interfaces IF_PORTS**

Parameter	VLAN-ID	specifies MVR VLAN ID for static group
	ip-addr	specifies multicast MVR group address
	IF_PORTS	specifies port list to set or remove

Default None

Mode Global Configuration

Usage Use the **mvr vlan group** command to add a static group or configure static group member ports when mvr is enabled.

This command applies to only receiver ports.

In compatible mode, this command applies to only receiver ports. In dynamic mode, it applies to receiver ports and source ports.

When remove static mvr group all ports, the static group will be delete. Or can use **no ip igmp vlan VLAN-ID group** to delete the mvr static group.

Static group can't learn dynamic port by igmp memesage.

Use the **no** form of this command to delete a port in static group. If remove the last member of static group, the static group will be delete.

You can verify settings by the **show mvr members** command.

Example The following example specifies that set mvr static group test.
 The configure must configure mvr receiver port firstly.(eg. mvr port type)
 Switch(config)# **mvr vlan 2 group 224.1.1.1 interfaces gi2**
 Switch# **show mvr members**
Gourp IP Address | Type | Life(Sec) | Port
 -----+-----+-----+-----
 224.1.1.1 | Static| -- | gi2

Total Number of Entry = 1

clear mvr members

Syntax clear mvr members [dynamic|static]

Parameter	dynamic	specifies MVR dynamic group
	static	specifies MVR static group

Default Clear all of mvr group

Mode Privileged EXEC

Usage This command will clear the mvr groups for selected type.

Example The following example specifies that clear all mvr groups test. Switch# **clear mvr members**

show mvr members

Syntax show mvr members

Parameter	None
------------------	------

Default	None
----------------	------

Mode	Privileged EXEC
-------------	-----------------

Usage	This command will display the mvr groups for all of type.
--------------	---

Example	The following example specifies that show mvr groups test. Switch# show mvr members
----------------	--

show mvr interface

Syntax show mvr interface [IF_PORTS]

Parameter	IF_PORTS	Show specifies port list configuration
------------------	----------	--

Default	None
----------------	------

Mode	Privileged EXEC
-------------	-----------------

Usage	This command will display mvr port type and port immediate status.
--------------	--

Example	The following example specifies that show mvr interface test. Switch# show mvr interface
----------------	---

show mvr

Syntax show mvr

Parameter	None
------------------	------

Default None

Mode Privileged EXEC

Usage This command will display mvr global information.

Example The following example specifies that show mvr test. Switch# **show mvr**
MVR Running : Enabled MVR Multicast VLAN : 100
MVR Group Range : 224.1.1.1 ~ 224.1.1.128
MVR Max Multicast Groups : 128 MVR Current Multicast Groups : 0 MVR
Global query response time : 1 sec
MVR Mode : compatible

Port

back-pressure

Syntax **back-pressure**
no back-pressure

Parameter

Default Default back pressure state is enabled.

Mode Interface Configuration

Usage Use “**back-pressure**” command to make port to enable back pressure feature.

Use **no** form of this command to disable back pressure feature.

The only way to show this configuration is using “**show running-config**” command.

Example

This example shows how to configure port fa1 and fa2 to be protected port.

```
Switch(config)# interface fa1
Switch(config-if)# no back-pressure
```

This example shows how to show current jumbo-frame size Switch# **show running-config interface fa1** interface fa1
no back-pressure

clear interface

Syntax clear interfaces *IF_PORTS* counters

Parameter *IF_PORTS* Specify port to clear counters.

Default No default value for this command.

Mode Privileged EXEC

Usage Use “clear interface” command to clear statistic counters on specific ports.

Example

This example shows how to clear counters on port fa1.

```
Switch(config)# clear interfaces fa1 counters
```

This example shows how to show current counters

```
Switch# show interfaces fa1
Hardware is Fast Ethernet
Auto-duplex, Auto-speed, media type is Copper flow-control is off
0 packets input, 0 bytes, 0 throttles Received 0 broadcasts (0
multicasts)
0 runts, 0 giants, 0 throttles
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
0 multicast, 0 pause input
0 input packets with dribble condition detected
0 packets output, 0 bytes, 0 underrun
0 output errors, 0 collisions, 0 interface resets
0 babbles, 0 late collision, 0 deferred
0 PAUSE output
```


description

Syntax `description WORD<1-32>`
no description

Parameter `WORD<1-32>` Specify port description string.

Default Default port description is empty.

Mode Interface Configuration

Usage Use “**description**” command to give the port a name to identify it easily.

If description includes space character, please use double quoted to wrap it. Use **no** form to restore description to empty string.

Example

```

This example shows how to modify port descriptions.
Switch(config)# interface fa1 Switch(config-if)# description userport
Switch(config-if)# exit
Switch(config)# interface fa2
Switch(config-if)# description "uplink port"
    
```

This example shows how to show current port description on interface fa1 and fa2

```

Switch# show interfaces fa1-2 status
Port Name Status Vlan Duplex Speed
    
```

```

Type
fa1 userport notconnect 1 auto auto
Copper
fa2 uplink port notconnect 1 auto auto
    
```

Duplex

Copper

Syntax `duplex (auto | full | half)`

Parameter

- auto** Specify port duplex to auto negotiation.
- full** Specify port duplex to force full duplex.
- half** Specify port duplex to force half duplex.

Default Default port duplex is auto.

Mode Interface Configuration

Usage Use “**duplex**” command to change port duplex configuration.

Example This example shows how to modify port duplex configuration.

```
Switch(config)# interface fa1 Switch(config-if)# duplex full
Switch(config-if)# exit Switch(config)# interface fa2
Switch(config-if)# duplex half
```

This example shows how to show current speed configuration

```
Switch# show running-config interfaces fa1-2
interface fa1 duplex full
interface fa2 duplex half
```

This example shows how to show current interface link speed

```
Switch# show interfaces fa1-2 status
Port Name Status Vlan Duplex Speed Type
fa1 connected 1 full a-100M Copper
fa2 connected 1 half a-100M Copper
```

eee

Syntax eee
no eee

Parameter

Default Default eee state is disabled.

Mode Interface Configuration

Usage Use “**eee**” command to make port to enable the energy efficient Ethernet feature.

Use **no** form of this command to disable eee.

The only way to show this configuration is using “**show running-config**” command.

Example

This example shows how to configure port fa1 and fa2 to be protected port.

```
Switch(config)# interface fa1
Switch(config-if)# eee
```

This example shows how to show current jumbo-frame size Switch# **show running-config interface fa1** interface fa1
eee

flowcontrol

Syntax

flowcontrol (auto | off | on)
no flowcontrol

Parameter

auto	Automatically enables or disables flow control on the interface.
off	Disable port flow control.
on	Enable port flow control.

Default

Default port flow control is off.

Mode

Interface Configuration

Usage

Use “**flowcontrol**” command to change port flow control configuration.

Use **no** form to restore flow control to default (off) configuration.

Example

This example shows how to modify port duplex configuration.

```
Switch(config)# interface fa1
Switch(config-if)# flowcontrol on
```

This example shows how to show current flow control configuration

```
Switch# show interfaces fa1
Hardware is Fast Ethernet
Full-duplex, Auto-speed, media type is Copper
flow-control is on
0 packets input, 0 bytes, 0 throttles Received 0 broadcasts (0
multicasts)
0 runts, 0 giants, 0 throttles
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
0 multicast, 0 pause input
0 input packets with dribble condition detected
379 packets output, 31981 bytes, 0 underrun
0 output errors, 0 collisions, 0 interface resets
0 babbles, 0 late collision, 0 deferred
0 PAUSE output
```

jumbo-frame

Syntax `jumbo-frame <1518-9216>`

Parameter `<1518-9216>` Specify the maximum frame size.

Default Default maximum frame size is 1522.

Mode Global Configuration

Usage Use “**jumbo-frame**” command to modify maximum frame size.

The only way to show this configuration is using “**show running-config**” command.

Example This example shows how to modify maximum frame size on fa1 to 9216 bytes.

```
Switch(config)# jumbo-frame 9216
```

This example shows how to show current jumbo-frame size

```
Switch# show running-config
jumbo-frame 9216
```

media-type

Syntax `media-type (auto-select | rj45 | sfp)`
`no media-type`

Parameter

<code>auto-select</code>	Select media automatically.
<code>rj45</code>	Select copper media.
<code>sfp</code>	Select fiber media.

Default Default media type is auto.

Mode Interface Configuration

Usage Use “**media-type**” command to change combo port media type.

Use **no** form of this command to restore media type to default.

Example

This example shows how to modify combo port media type to copper.

```
Switch(config)# interface gil
Switch(config-if)# media-type rj45
```

protected

Syntax

protected
no protected

Default

Default protected state is no protected.

Mode

Interface Configuration

Usage Use “**protected**” command to make port to be protected. Protected port is only allowed to communicate with unprotected port. In other words, protected port is not allowed to communicate with another protected port.

Use **no** form to make port unprotected.

Example

This example shows how to configure port fa1 and fa2 to be protected port.

```
Switch(config)# interface range fa1-2
Switch(config-if-range)# protected
```

This example shows how to show current protected port state.

```
Switch# show interfaces fa1-2 protected
Port | Protected State
-----+-----
fa1 | enabled
```

```
fa2 | enabled
```

show interface

Syntax

show interfaces *IF_PORTS*
show interfaces *IF_PORTS* status show
interfaces *IF_PORTS* protected

Parameter

IF_PORTS Specify port to show.

Default

No default value for this command.

Mode

Privileged EXEC

Usage Use “**show interface**” command to show detail port counters, parameters and status.

Use “**show interface status**” command to show brief port status. Use “**show interface protected**” command to show protected status.

Example

This example shows how to show current counters

```
Switch# show interfaces fa1
Hardware is Fast Ethernet
Auto-duplex, Auto-speed, media type is Copper flow-control is off
0 packets input, 0 bytes, 0 throttles Received 0 broadcasts (0
multicasts)
0 runs, 0 giants, 0 throttles
0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
0 multicast, 0 pause input
0 input packets with dribble condition detected
0 packets output, 0 bytes, 0 underrun
0 output errors, 0 collisions, 0 interface resets
0 babbles, 0 late collision, 0 deferred
0 PAUSE output
```

This example shows how to show current protected port state.

```
Switch# show interfaces fa1-2 protected
Port | Protected State
-----+-----
fa1 |enabled fa2 |enabled
```

This example shows how to show current port status

```
Switch# show interfaces fa1-2 status
Port Name Status Vlan Duplex Speed Type
fa1 connected 1 full a-100M Copper
```

speed

Syntax

speed (10 | 100 | 1000)
speed auto [(10 | 100 | 1000 | 10/100)]

speed nonnegtiate
no speed nonnegtiate

Parameter 10 Specify port speed to force 10Mbps/s or auto with 10Mbps/s ability.

100 Specify port speed to force 100Mbps/s or auto with 100Mbps/s ability.

1000 Specify port speed to force 1000Mbps/s or auto with 1000Mbps/s ability.

10/100 Specify port speed to auto with 10Mbps/s and 100Mbps/s

Default

Default port speed is auto with all available abilities.

Mode

Interface Configuration

Usage Use “**speed**” command to change port speed configuration. The speed is only able to configure to the physical maximum speed. For example, in fast Ethernet port, speed 1000 is not available.

You cannot configure the speed on the SFP module ports, but you can configure the speed to not negotiate (nonegotiate) if it is connected to a device that does not support autonegotiation.

Example

This example shows how to modify port speed configuration.

```
Switch(config)# interface fa1 Switch(config-if)# speed 100
Switch(config-if)# exit Switch(config)# interface fa2
Switch(config-if)# speed auto 10/100
```

This example shows how to show current speed configuration

```
Switch# show running-config interfaces fa1-2 interface fa1
speed 100 interface fa2
speed auto 10/100
```

This example shows how to show current interface link speed

```
Switch# show interfaces fa1-2 status
Port Name Status Vlan Duplex Speed Type
```

Port	Name	Status	Vlan	Duplex	Speed	Type
fa1		connected	1	a-full	a-100M	Copper
fa2		connected	1	a-full	a-100M	Copper

shutdown

Syntax

shutdown
no shutdown

Parameter

Default

Default port admin state is no shutdown.

Mode

Interface Configuration

Usage Use “**shutdown**” command to disable port and use “**no shutdown**” to enable port. If port is error disabled by some reason, use “no shutdown” command can also recovery the port manually.

Example

This example shows how to modify port duplex configuration.
 Switch(config)# **interface fa1** Switch(config-if)#
shutdown

This example shows how to show current admin state configuration Switch#
show running-config interfaces fa1 interface fa1
 shutdown

This example shows how to show current link status
 Port Name Status Vlan Duplex Speed Type fa1 **disable** 1 full auto
 Copper

Port Error Disable errdisable recovery cause

Syntax errdisable recovery cause (all|acl|arp-inspection|bpduguard|broadcast-flood|dhcp-rate-limit|psecure-violation|selfloop|unicast-flood|unknown-multicastflood)
 no errdisable recovery cause (all|acl|arp-inspection|bpduguard|broadcast-flood|dhcp-rate-limit|psecure-violation|selfloop|unicast-flood|unknown-multicastflood)

Parameter	all	Enable the auto recovery for port error disabled from all causes.
	acl	Enable the auto recovery for port error disabled from the ACL cause.
	arp-inspection	Enable the auto recovery for port error disabled from the ARP inspection cause.
	bpduguard	Enable the auto recovery for port error disabled from the STP BPDU Guard cause.
	broadcast-flood	Enable the auto recovery for port error disabled from the broadcast flooding cause.
	dhcp-rate-limit	Enable the auto recovery for port error disabled from the DHCP rate limit cause.
	psecure-violation	Enable the auto recovery for port error disabled from the port security cause.
	selfloop	Enable the auto recovery for port error disabled from the STP self-loop cause.
	unicast-flood	Enable the auto recovery for port error disabled from the unicast flooding cause.
	unknown-multicastflood	Enable the auto recovery for port error disabled from the unknown multicast flooding cause.

Default Error disable recovery is disabled for all cause.

Mode Global Configuration

Usage Ports would be disabled because of the invalid actions detected by protocols.

To enable the port error disable recovery from the specific cause, use the command **errdisable recovery cause** in the Global Configuration mode.

Example The following example enables the port error disable recovery for the STP BPDU Guard and self-loop cause.

```
Switch(config)# errdisable recovery cause bpduguard
Switch(config)# errdisable recovery cause selfloop
```

errdisable recovery interval

Syntax **errdisable recovery interval** *seconds*

Parameter	<i>seconds</i>	The time in seconds to recover from a specific error- disable state. The valid range is 0 to 86400 seconds, and the default value is 300 seconds.
------------------	----------------	---

Default The default recovery time is 300 seconds.

Mode Global Configuration

Usage To set the recovery time of the error disabled ports, use the command **errdisable recover interval** in the Global Configuration mode.

Example The following example set the aging time to 500 seconds.

```
Switch(config)# errdisable recovery interval 60
```

show errdisable recovery

Syntax **show errdisable recovery**

Parameter N/A

Default N/A

Mode Privileged EXEC

Usage To show the error disable configuration and the interfaces in the error disabled state, use the command **show errdisable recovery** in the Privileged EXEC mode.

Example The following example shows the error disable configuration, and the interfaces in the error disabled state.

```
Switch# show errdisable recovery ErrDisable Reason | Timer Status
-----+-----
bpduguard | enabled selfloop | enabled
broadcast-flood | disabled unknown-multicast-flood | disabled
unicast-flood | disabled
acl | disabled psecure-violation | disabled dhcp-rate-limit |
disabled arp-inspection | disabled

Timer Interval : 60 seconds
```

Interfaces that will be enabled at the next timeout:

```
Port | Error Disable Reason | Time Left
-----+-----
```

Port Security

port-security (Global)

Syntax port-security

no port-security

Parameter None

Default Default is disabled

Mode Global Configuration

Usage The “**port-security**” command enables the port security functionality globally. Use the **no** form of this command to disable. You can verify settings by the **show port-security** command.

Example

The following example shows how to enable port security switch(config)# **port-security**
 switch# **show port-security**
 port-security is: Enabled

port-security (Interface)

Syntax port-security

no port-security

Parameter

None

Default

Default is disabled

Mode

Port Configuration

Usage The “**port-security**” command enables the port security functionality on this port. Use the **no** form of this command to disable. You can verify settings by the **show port-security interface** command.

Example

The following example shows how to enable port security on interface fa1

```
switch(config)# interface fa1
switch(config-if)# port-security
switch(config)# show port-security interfaces fa1
Port | Security | CurrentAddr | Action
-----+-----+-----+-----
fa1 | Enabled ( 1) | 0 | Discard
```

port-security address-limit

Syntax

port-security address-limit <1-256> **action** (forward|discard|shutdown)
no port-security address-limit

Parameter

<1-256>	The learning-limit number. It specifies how many MAC addresses this port can learn.
forward	Forward this packet whose SMAC is new to system and exceed the learning-limit number.
discard	Discard this packet whose SMAC is new to system and exceed the learning-limit number.
shutdown	Shutdown this port when receives a packet whose SMAC is new to system and exceed the learning limit <u>number.</u>

Default The address-limit default is 1 and action is “drop”.

Mode Port Configuration

Usage Use the “**port-security address-limit**” command to set the learning-limit number and the violation action. Use the **no** form of this command to restore the default settings. You can verify settings by the **show port-security interface** command.

Example The following example shows how to enable port security on port 1 and set the learning limit number to 10.

```
switch(config)# interface fa1
switch(config-if)# port-security address-limit 10 action discard
switch(config-if)# port-security
switch(config)# show port-security interfaces fa1
```

Port	Mode	Security	CurrentAddr	Action
fa1	Dynamic	Enabled (10)	0	Discard

show port-security

Syntax show port-security

Parameter None

Default No default value for this command.

Mode Privileged EXEC

Usage Use “**show port-security**” command to show port-security global information.

Example This example shows how to show port-security configurations.

```
Switch# show port-security
port-security is: Enabled
```

show port-security interface

Syntax `show port-security interface IF_PORTS`

Parameter `IF_PORTS` Select port to show port-security configurations.

Default No default value for this command.

Mode Privileged EXEC

Usage Use “**show port-security interfaces**” command to show port-security information of the specified port.

Example This example shows how to show port-security configurations on interface fa1.

```
Switch# show port-security interfaces fa1
Port | Security | CurrentAddr | Action
-----+-----+-----+-----
fa1 | Enabled ( 10) | 0 | Discard
```

Protocol VLAN

vlan protocol-vlan group (Global)

Syntax `vlan protocol-vlan group <1-8> frame-type (ethernet_ii|llc_other|snap_1042) protocol-value VALUE`
`no vlan protocol-vlan group <1-8>`

Parameter	<code><1-8></code>	Specify protocol vlan group to configure
	<code>(ethernet_ii llc_other snap_1042)</code>	Specify protocol based frame type
	<code>VALUE</code>	Specify protocol value to configure

Default no protocol vlan group are configured

Mode Global Configuration

Usage Use the **vlan protocol-vlan group** Global Configuration mode command to add protocol vlan group with spefied proto type and value.
 Use the **no** form of this command to remove protocol vlan group setting.
 You can verify your setting by entering the **show vlan proto-vlan Privileged EXEC** command

Example The following example show how to configure protocol vlan group:
 Switch(config)# **vlan protocol-vlan group 1 frame-type ethernet_ii protocol-value 0x806**
 Switch(config)# **vlan protocol-vlan group 2 frame-type llc_other protocol-value 0x800**
 Switch# **show vlan protocol-vlan**
 Group ID | Status | Type | value
 -----+-----+-----+-----
 | Enabled | Ethernet | 0x0806
 | Enabled | LLC other | 0x0800
 | Disabled | -- | --
 | Disabled | -- | --
 | Disabled | -- | --
 | Disabled | -- | --
 | Disabled | -- | --
 | Disabled | -- | --

vlan protocol-vlan group (Interface)

Syntax **vlan protocol-vlan group** <1-8> **vlan** <1-4094>
no vlan protocol-vlan group <1-8>

Parameter	<1-8>	Specify protocol vlan group to binding
	<1-4094>	Specifies the Proto VLAN ID to configure.

Default In default all group are not binding to any interface.

Mode Interface configuration

Usage Use the **vlan protocol-vlan binding** Interface Configuration mode command to binding protocol VLAN Group on specified interfaces,
 Use the **no** form of this command to cancel protocol VLAN Group Binding. You can verify your setting by entering the **show vlan protocol-vlan interfaces IF_PORTS Privileged EXEC** command

Example

The following example how to configure Protocol VLAN function on specified interfaces..

```
Switch(config)# interface fa1
Switch(config-if)# vlan protocol-vlan group 1 vlan 2 Switch(config-if)# vlan
protocol-vlan group 2 vlan 3 Switch# show vlan protocol-vlan interfaces fa1
Port fa1 : Group 1
Status : Enabled VLAN ID : 2
Group 2
Status : Enabled VLAN ID : 3
Group 3
Status : Disabled Group 4
Status : Disabled Group 5
Status : Disabled Group 6
Status : Disabled Group 7
Status : Disabled Group 8
Status : Disabled
```

show vlan protocol-vlan

Syntax show vlan protocol-vlan [group <1-8>]

Parameter	<1-8>	Specify protocol vlan group to display
------------------	-------	--

Default	N/A
----------------	-----

Mode	Privileged EXEC
-------------	-----------------

Usage	Use the show vlan proto-vlan command in EXEC mode to display Proto VLAN group configuration
--------------	--

Example

The following example how to display Proto VLAN group configuration Switch#

show vlan protocol-vlan

Group ID | Status | Type | value

```
-----+-----+-----+-----
| Enabled | Ethernet | 0x0806
| Enabled | LLC other | 0x0800
| Disabled | -- | --
| Disabled | -- | --
| Disabled | -- | --
| Disabled | -- | --
| Disabled | -- | --
| Disabled | -- | --
```

show vlan protocol-vlan interfaces

Syntax **show vlan protocol-vlan interfaces IF_PORTS**

Parameter IF_PORTS Specify interfaces protocol vlan to display

Default N/A

Mode Privileged EXEC

Usage Use the **show vlan protocol-vlan interface** command in EXEC mode to display the Protocol VLAN interfaces setting

Example The following example shows how to display the Protocol VLAN interfaces setting

```
Switch# show vlan protocol-vlan interfaces fa1
Port fa1 : Group 1
Status : Enabled VLAN ID : 2
Group 2
Status : Enabled VLAN ID : 3
Group 3
Status : Disabled Group 4
Status : Disabled Group 5
Status : Disabled Group 6
Status : Disabled Group 7
Status : Disabled Group 8
Status : Disabled
```

QoS

qos

Syntax qos
no qos

Default Default qos is disabled.

Mode Global Configuration

Usage Use “**qos**” command to enable quality of service which according to basic trust type to assign queue for packets, and packets with higher priority are able to send first.

Use no form of this command to disable quality of service.

Example

This example shows how to change qos to basic mode.
 Switch(config)# **qos basic**

This example shows how to check current qos mode.
 Switch# **show qos**
 QoS Mode: basic
 Basic trust: cos

qos cos

Syntax

qos cos <0-7>

Parameter

cos <0-7> Specify the CoS value for the interface.

Default

Default CoS value for interface is 0.

Mode

Interface Configuration

Usage Sometimes, there is no qos information in the packets, such as CoS, DSCP, IP Precedence. But we still can give the priority for packets by configuring the interface default cos value. If there is no qos information in the packets, the device will use this default cos value and find the cos-queue map to get the final destination queue.

Use “**qos cos**” command to assign port default cos value.

Example

This example shows how to configure default cos value 7 on interface fa1.
 Switch(config)# **interface GigabitEthernet 1**
 Switch(config-if)# **qos cos 7**
 Switch(config-if)# **end**
 Switch# **show qos interface GigabitEthernet 1**

Port	CoS	Trust State	Remark Cos	Remark DSCP	Remark IP Prec
gil	7	enabled	disabled	disabled	disabled

qos map

Syntax

qos map (cos-queue | dscp-queue | precedence-queue) *SEQUENCE* to <1-8>

qos map (queue-cos | queue-precedence) *SEQUENCE* to <0-7>

qos map queue-dscp *SEQUENCE* to <0-63>

Parameter

cos-queue	Configure or show CoS to queue map
dscp-queue	Configure or show DSCP to queue map
precedence-queue	Configure or show IP Precedence to queue map.
queue-cos	Configure or show queue to CoS map

queue-dscp Configure or show queue to DSCP map

queue-precedence Configure or show queue to IP Precedence map

SEQUENCE	Specify the cos, dscp, precedence or queue with one or multiple values.
<1-8>	Specify the queue id
<0-7>	Specify the cos or precedence values
<0-63>	Specify the dscp values

Default The default values of cos-queue are showing in the following table.

CoS	Queue ID
0	2
1	1
2	3
3	4
4	5
5	6
6	7
7	8

The default values of dscp-queue are showing in the following table.

DSCP	Queue ID
0~7	1
8~15	2
16~23	3
24~31	4
32~39	5
40~47	6
48~55	7
56~63	8

The default values of ip precedence are showing in the following table.

IP Precedence	Queue ID
0	1
1	2
2	3
3	4
4	5
5	6
6	7
7	8

The default values of queue-cos are showing in the following table.

Queue ID	CoS
1	1
2	0
3	2
4	3
5	4
6	5
7	6
8	7

The default values of queue-dscp are showing in the following table.

Queue ID	DSCP
1	0
2	8
3	16
4	24
5	32
6	40
7	48
8	56

The default values of queue-precedence are showing in the following table.

Queue ID	IP Precedence
1	0
2	1
3	2
4	3
5	4
6	5
7	6
8	7

Mode Global Configuration

Usage According to different trust type, packets will be assigned to different queue based on the specific qos map. For example, if the trust type is trust cos, the device will get the cos value in packet and reference the cos-queue mapping to assign the correct queue.

The queue to cos, dscp or precedence maps are used by remarking function. If the port remarking feature is enabled, the remarking function will reference these 3 tables to remark packets.

Example This example shows how to map cos 6 and 7 to queue 1. `Switch(config)# qos map cos-queue 6 7 to 1` `Switch# show qos map cos-queue`

```
CoS to Queue mappings
COS 0 1 2 3 4 5 6 7
-----
Queue 2 1 3 4 5 6 1 1
```

This example shows how to map queue 4 and 5 to cos 7. `Switch(config)# qos map queue-cos 4 5 to 7` `Switch# show qos map queue-cos`

```
Queue to CoS mappings
```

```
Queue 1 2 3 4 5 6 7 8
-----
CoS 1 0 2 7 7 5 6 7
```

qos queue

Syntax

```
qos queue strict-priority-num <0-8>
qos queue weight SEQUENCE
show qos queueing
```

Parameter

strict-priority-num <0-8>	Specify the strict priority queue number
weight SEQUENCE	Specify the non-strict priority queue weight value. The valid queue weight value is from 1 to 127.

Default Default strict priority queue number is 8, it means all queues are strict priority queue.

The default queue weight for each queue is shown in following table.

Queue ID	Queue Weight
1	1
2	2
3	3
4	4
5	5
6	9
7	13
8	15

Mode Global Configuration

Usage

The device support total 8 queues for QoS queueing. It is able to set the queue to be strict priority queue or weighted queue to prevent starvation. The queue with higher id value has higher priority.

First, you need to decide how many strict priority queue you need. The strict priority queue will always occupy the higher priority queue. For example, if you specify the strict priority number to be 2, then the queue 7 and 8 will be the strict priority queues and the others are weighted queues.

After you setup the number of strict priority queue, you need to setup the weight for the weighted queues by using “qos queue weight” command. And the bandwidth will shared by the weight you configured between these weighted queues.

Example

This example shows how to setup device with 3 strict priority queues and give other weighted queues with weight 5, 10, 15, 20, 25.

```
Switch(config)# qos queue strict-priority-num 3 Switch(config)#
qos queue weight 5 10 15 20 25 Switch# show qos queueing
qid-weights Ef - Priority
- 5 dis- N/A
- 10 dis- N/A
- 15 dis- N/A
- 20 dis- N/A
- 25 dis- N/A
- N/A ena- 6
- N/A ena- 7
- N/A ena- 8
```

qos remark

Syntax

qos remark (cos | dscp | precedence)
no qos remark (cos | dscp | precedence)

Parameter

cos	Enable/Disable cos remarking.
dscp	Enable/Disable dscp remarking.
precedence	Enable/Disable precedence remarking.

Default Default CoS remarking is disabled. Default DSCP remarking is disabled.
 Default IP Precedence remarking is disabled.

Mode Interface Configuration

Usage QoS remarking feature allow you to change priority information in packets based on egress queue. For example, you want all packets egress from interface fa1 queue 1 to remark the cos value to be 5 for next tier of device, you can enable the cos remarking feature on fa1 and configure the queue-cos map for queue 1 map to cos 5.

Use “**qos remark**” command to enable remarking feature on specific type. And use “**no qos remark**” command to disable it.

Example

This example shows how to enable remarking features on interface fa1.

```
Switch(config)# interface GigabitEthernet 1 Switch(config-if)# qos
remark cos Switch(config-if)# qos remark dscp Switch(config-if)#
qos remark precedence Switch(config-if)# end
Switch# show qos interface GigabitEthernet 1
Port | CoS | Trust State | Remark Cos | Remark DSCP | Remark IP Prec
-----+-----+-----+-----+-----+-----
gi1 | 0 | enabled | enabled | enabled | enabled |
```

qos trust

Syntax `qos trust (cos | cos-dscp | dscp | precedence)`

Parameter	cos	Specify the device to trust CoS
	cos-dscp	Specify the device to trust DSCP for IP packets, and trust CoS for non-IP packets.
	dscp	Specify the device to trust DSCP
	precedence	Specify the device to trust IP Precedence

Default Default QoS trust type is cos.

Mode Global Configuration

Usage In QoS basic mode, there are 4 trust types for device to judge the appropriate queue of the packets. This command is able to switch between these trust types.

CoS:

IEEE 802.1p defined 3bits priority value in vlan tag. Trust this value in packets and assign queue according to cos-queue map.

DSCP:

IETF RFC2474 defined 6bits priority value in IP packet (highest 6bits in ToS field). Trust this value in packets and assign queue according to dscp-queue map.

IP Precedence:

The highest 3bits priority value in IP packet ToS field. Trust this value in packets and assign queue according to precedence-queue map.

CoS-DSCP:

Trust DSCP for IP packets and assign queue according to dscp-queue map. Trust CoS for non-IP packets and assign queue according to cos-queue map.

Example

This example shows how to change qos basic mode trust types.

```
Switch(config)# qos trust cos Switch(config)# qos trust cos-dscp
Switch(config)# qos trust dscp Switch(config)# qos trust
precedence
```

This example shows how to check current qos trust type.

```
Switch# show qos
QoS Mode: basic
Basic trust: ip-precedence
```

qos trust (Interface)

Syntax `qos trust`
 `no qos trust`

Parameter

Default Default interface qos trust state is enabled.

Mode Interface Configuration

Usage After QoS function is enabled in basic mode, the device also support per interface enable/disable the qos function. If the trust state on interface is enabled, all ingress packets of this interface will remap according to the trust type and the qos maps. Otherwise, all ingress packets will assign to queue 1.

Use “**qos trust**” to enable trust state on interface and use “**no qos trust**” to disable trust state on interface.

Example

```

This example shows how to disable qos trust state on interface fa1.
Switch(config)# interface GigabitEthernet 1 Switch(config-if)# no
qos trust
Switch(config-if)# end
Switch# show qos interface GigabitEthernet 1
Port | CoS | Trust State | Remark Cos | Remark DSCP | Remark IP Prec
-----+-----+-----+-----+-----+-----
gil | 0 | disabled | disabled | disabled | disabled |
  
```

show qos

Syntax `show qos`

Parameter

Default No default value for this command.

Mode Privileged EXEC

Usage Use “**show qos**” command to show qos state and trust type.

Example

This example shows how to check current qos mode.

```
Switch# show qos
QoS Mode: basic
Basic trust: cos
```

show qos interface

Syntax

show qos interface *IF_PORTS*

Parameter

IF_PORTS Select port to show qos configurations.

Default

No default value for this command.

Mode

Privileged EXEC

Usage

Use “**show qos interfaces**” command to show port default cos ,remarking state and remarking type state informations.

Example

This example shows how to show qos configurations on interface fa1.

```
Switch# show qos interface GigabitEthernet 1
Port | CoS | Trust State | Remark Cos | Remark DSCP | Remark IP Prec
-----+-----+-----+-----+-----+-----
gil | 7 | enabled | disabled | disabled | disabled |
```

show qos map

Syntax

show qos map [(**cos-queue** | **dscp-queue** | **precedence-queue** | **queue-cos** | **queue-dscp** | **queue-precedence**)]

Parameter cos-queue Show CoS to queue map.

dscp-queue Show DSCP to queue map. **precedence-queue** Show IP Precedence to queue map. **queue-cos** Show queue to CoS map.

queue-dscp Show queue to DSCP map.

queue-precedence Show queue to IP Precedence map.

Default

No default value for this command.

Mode Privileged EXEC

Usage Use “**show qos map**” command to show all kinds of mapping for qos remapping and remarking features.

Example

This example shows how to show all qos maps.

```
Switch(config)# show qos map

CoS to Queue mappings
COS 0 1 2 3 4 5 6 7
-----
Queue 2 1 3 4 5 6 7 8

DSCP to Queue mappings
d1: d2 0 1 2 3 4 5 6 7 8 9
----- 0: 1 1 1 1 1 1 1 1 2 2
1: 2 2 2 2 2 2 3 3 3 3
2: 3 3 3 3 4 4 4 4 4 4
3: 4 4 5 5 5 5 5 5 5 5
4: 6 6 6 6 6 6 6 6 7 7
5: 7 7 7 7 7 7 8 8 8 8
6: 8 8 8 8

IP Precedence to Queue mappings
IP Precedence 0 1 2 3 4 5 6 7
-----
Queue 1 2 3 4 5 6 7 8

Queue to CoS mappings
Queue 1 2 3 4 5 6 7 8
----- CoS 1 0 2 3 4 5 6 7

Queue to DSCP mappings
Queue 1 2 3 4 5 6 7 8
----- DSCP 0 8 16 24 32 40 48 56

Queue to IP Precedence mappings Queue 1 2 3 4 5 6 7 8
-----
ipprec 0 1 2 3 4 5 6 7
```

show qos queueing

Syntax `show qos queueing`

Parameter

Default No default value for this command.

Mode Privileged EXEC

Usage Use “`show qos queueing`” command to show qos queueing information.

Example	<p>This example shows how to check current qos queueing information.</p> <pre>Switch# show qos queueing qid-weights Ef - Priority - 3 dis- N/A - 5 dis- N/A - N/A ena- 3 - N/A ena- 4 - N/A ena- 5 - N/A ena- 6 - N/A ena- 7 - N/A ena- 8</pre>
----------------	---

Rate Limit

rate limit egress

Syntax	<pre>rate-limit egress <16-1000000> no rate-limit egress</pre>
Parameter	<p><u><16-1000000></u> Specify the committed information rate.</p>
Default	Default rate limit is disabled.
Mode	Interface configuration
Usage	<p>Use the “rate-limit egress” command to configure the egress port shaper. Use the no form of this command to disable the shaper.</p> <p>You can verify your setting by entering the show running-config interfaces command.</p>
Example	<p>The following example show how to configure ingress port rate limit and egress port shaper.</p> <pre>Switch(config)# interfaces gil Switch(config-if)# rate-limit egress 2048 Switch# show running-config interfaces gil interface gil rate-limit egress 2048</pre>

rate limit egress queue

Syntax **rate-limit egress queue** <1-8> <16-1000000>

no rate-limit egress queue <1-8>

Parameter	<1-8>	Specify the egress shaper queue number
	<16-1000000>	Specify the queue rate.

Default Default queue rate limit is disabled.

Mode Interface configuration

Usage Use the “**rate-limit egress queue**” command to configure the egress queue shaper.

Use the **no** form of this command to disable the queue shaper.

You can verify your setting by entering the **show running-config interfaces** command.

Example The following example show how to configure ingress port rate limit and egress port shaper.

```
Switch(config)# interfaces gil
Switch(config-if)# rate-limit egress queue 3 2048 Switch# show
running-config interfaces gil interface gil
rate-limit egress queue 3 2048
```

rate limit ingress

Syntax **rate-limit ingress** <16-1000000>
no rate-limit ingress

Parameter	<16-1000000>	Specify the ingress limit rate
	<1-8>	Specify the egress shaper queue number

Default Rate limiting is disabled.

Mode Interface configuration

Usage Use the “**rate-limit ingress**” command to limit the incoming traffic rate on a port.

Use the **no** form of this command to disable the rate limit.

You can verify your setting by entering the **show running-config interfaces** command

Example

The following example show how to configure ingress port rate limit.

```
Switch(config)# interfaces gil Switch(config-if)# rate-limit ingress 128
Switch# show running-config interfaces gil
interface gil
rate-limit ingress 128
```

RMON

rmon event

Syntax

rmon event <1-65535> [log] [trap COMMUNITY] [description DESCRIPTION] [owner NAME]
no rmon event <1-65535>

Parameter

<1-65535>	Specify event index to create or modify.
[log]	(Optional)Specify to show syslog.
[trap COMMUNITY]	(Optional)Specify SNMP community to show SNMP trap.
[description DESCRIPTION]	(Optional)Specify description of event
[owner NAME]	(Optional)Specify owner of event.

Default

No default is defined.

Mode

Global Configuration

Usage

Use the **rmon event** command to add or modify a RMON event entry. Use the **no** form of this command to delete. You can verify settings by the **show rmon event** command.

Example

The example shows how to add RMON event entry with log and trap action and then modify it action to log only.

```
switch(config)# rmon event 1 log trap public description test owner admin
switch(config)# show rmon event 1
```

Rmon Event Index 1

Rmon Event Type : Log and Trap Rmon Event Community : public Rmon Event Description : test

Rmon Event Last Sent :

Rmon Event Owner : admin

```
switch(config)# rmon event 1 log description test owner admin
```

```
switch(config)# show rmon event 1
```

Rmon Event Index 1

Rmon Event Type : Log Rmon Event Community : public Rmon Event Description : test Rmon Event Last Sent :

Rmon Event Owner : admin

rmon alarm

Syntax **rmon alarm** <1-65535> interface IF_PORT (drop-events|octets|pkts|broadcast-pkts|multicast-pkts|crc-align-errors|undersize-pkts|oversize-pkts|fragments|jabbers|collisions|pkts64octets|pkts65to127octets|pkts128to255octets|pkts256to511octets|pkts512to1023octets|pkts1024to1518octets) <1-2147483647> (absolute|delta) rising <0-2147483647> <0-65535> falling <0-2147483647> <0-65535> startup (rising|rising-falling|falling) [owner NAME]
no rmon alarm <1-65535>

Parameter	Description
<1-65535>	Specify alarm index to create or modify
IF_PORT	Specify the interface to sample
(variable)	Specify a mib object to sample
<1-2147483647>	Specify the time in seconds that the alarm monitors the MIB variable.
(absolute delta)	Specify absolute to compare sample counter absolutely. Specify delta to compare delta counter between samples
<0-2147483647>	Specify a number which the alarm trigger rising event
<0-65535>	Specify event index when the rising threshold exceeds.
<0-2147483647>	Specify a number which the alarm trigger falling event
<0-65535>	Specify event index when the falling threshold exceeds.
(rising rising-falling falling)	Specify only to how rising or falling startup event. Or show either rising or falling startup event.
[owner NAME]	(Optional) Specify owner of alarm.

Default No default is defined.

Mode Global Configuration

Usage Use the **rmon alarm** command to add or modify a RMON alarm entry. Before add alarm entry, at least one event entry must be added. Use the **no** form of this command to delete. You can verify settings by the **show rmon alarm** command.

Example

The example shows how to add RMON alarm entry that sample interface fal packets delta count every 300 seconds. Trigger event index 1 if over than rising threshold 10000, trigger event index 2 if lower than falling threshold.

```
switch(config)# rmon event 1 log
switch(config)# rmon event 2 log
```

```
Switch(config)# rmon alarm 1 interface gi1 pkts 300 delta rising 10000 1
falling 100 1 startup rising-falling owner admin
Rmon Alarm Index 1
Rmon Alarm Sample Interval 300
Rmon Alarm Sample Interface : gi1 Rmon Alarm Sample Variable : Pkts Rmon
Alarm Sample Type : delta
Rmon Alarm Type : Rising or Falling Rmon Alarm Rising Threshold : 10000
Rmon Alarm Rising Event 1
Rmon Alarm Falling Threshold 100
Rmon Alarm Falling Event 1
Rmon Alarm Owner : admin
```

rmon history

Syntax

```
rmon history <1-65535> interface IF_PORT [buckets <1-65535>]
[interval <1-3600>] [owner NAME]
no rmon history <1-65535>
```

Parameter

<1-65535>	Specify history index to create or modify.
IF_PORT	Specify the interface to sample
[bucket <1-65535>]	(Optional) Specify the maximum number of buckets.
[interval <>1-3600]	(Optional) Specify time interval for each sample
[owner NAME]	(Optional)Specify owner of history

Default

No default is defined.

Mode

Global Configuration

Usage Use the **rmon history** command to add or modify a RMON history entry. Use the **no** form of this command to delete. You can verify settings by the **show rmon history** command.

Example

The example shows how to add RMON history entry that monitor interface gi1 every 60 seconds and then modify it to monitor every 30 seconds.

```
switch(config)# rmon history 1 interface gi1 interval 60 owner admin
switch(config)# show rmon history 1
Rmon History Index 1
Rmon Collection Interface: gi1 Rmon History Bucket 50
Rmon history Interval 60
Rmon History Owner : admin
```

```
switch(config)# rmon history 1 interface gi1 interval 30 owner admin
switch(config)# show rmon history 1
Rmon History Index 1
Rmon Collection Interface: gi1 Rmon History Bucket 50
Rmon history Interval 30
Rmon History Owner : admin
```

clear rmon interfaces statistics

Syntax **clear rmon interfaces IF_PORTS statistics**

Parameter **IF_PORTS** specifies ports to clear

Default No default is defined

Mode Privileged EXEC

Usage Use the **clear rmon interfaces statistics** command to clear RMON etherStat statistics those are recorded on interface.
You can verify results by the **show rmon interface statistics** command.

Example

The example shows how to clear RMON etherStat statistics on interface gi1.

```
switch# clear rmon interfaces gi1 statistics
switch# show rmon interfaces gi1 statistics
===== Port gi1 =====
etherStatsDropEvents 0
etherStatsOctets 0
etherStatsPkts 0
etherStatsBroadcastPkts 0
etherStatsMulticastPkts 0
etherStatsCRCAlignErrors 0
etherStatsUnderSizePkts 0
etherStatsOverSizePkts 0
etherStatsFragments 0
etherStatsJabbers 0
etherStatsCollisions 0
etherStatsPkts64Octets 0
etherStatsPkts65to127Octets 0
etherStatsPkts128to255Octets 0
etherStatsPkts256to511Octets 0
etherStatsPkts512to1023Octets 0
etherStatsPkts1024to1518Octets 0
```

show rmon interfaces statistics

Syntax

show rmon interfaces IF_PORTS statistics

Parameter

IF_PORTS specifies ports to show

Default

No default is defined

Mode

Privileged EXEC

Usage

Use the **show rmon interfaces statistics** command to show RMON etherStat statistics of interface.

Example

The example shows how to show RMON etherStat statistics of interface gi1.

```
switch(config)# show rmon interfaces gi1 statistics
===== Port gi1 =====
etherStatsDropEvents 0
etherStatsOctets : 81882
```

```
etherStatsPkts 578
etherStatsBroadcastPkts 10
etherStatsMulticastPkts 0
```

```
etherStatsCRCAlignErrors 0
etherStatsUnderSizePkts 0
etherStatsOverSizePkts 0
etherStatsFragments 0
etherStatsJabbers 0
etherStatsCollisions 0
etherStatsPkts64Octets 355
etherStatsPkts65to127Octets 126
etherStatsPkts128to255Octets 0
etherStatsPkts256to511Octets 42
etherStatsPkts512to1023Octets 55
etherStatsPkts1024to1518Octets 0
```

show rmon event

Syntax **show rmon event (<1-65535> | all)**

Parameter	<1-65535>	specifies event index to show
	all	Show all existed event

Default No default is defined

Mode Privileged EXEC

Usage Use the **show rmon event** command to show existed RMON event entry.

Example The example shows how to show rmon event entry.

```
switch(config)# rmon event 1 log trap public description test owner admin
switch(config)# show rmon event 1
Rmon Event Index 1
Rmon Event Type : Log and Trap Rmon Event Community : public Rmon Event
Description : test
Rmon Event Last Sent :
Rmon Event Owner : admin
```

show rmon event log

Syntax **show rmon event <1-65535> log**

Parameter	<1-65535>	specifies event index to show event log
------------------	------------------------	---

Default No entry and log is exist

Mode Privileged EXEC

Usage Use the **show rmon event log** command to show log triggered by RMON alarm.

Example The example shows how to show rmon event log.

```
switch(config)# show rmon event 1 log
```

```
=====
Index 1
Alarm Index 1
Action : Startup Falling
Time : (32918334) 3 days, 19:26:23.34
Description : fa1.Pkts=0 <= 100
```

show rmon alarm

Syntax show rmon alarm (<1-65535> | all)

Parameter	<1-65535>	specifies alarm index to show
	all	Show all existed alarm

Default No alarm is defined

Mode Privileged EXEC

Usage Use the **show rmon alarm** command to show existed RMON alarm entry.

Example

The example shows how to show rmon alarm entry.

```
Switch(config)# rmon alarm 1 interface gi1 pkts 300 delta rising 10000 1
falling 100 1 startup rising-falling owner admin
Rmon Alarm Index 1
Rmon Alarm Sample Interval 300
Rmon Alarm Sample Interface : gi1 Rmon Alarm Sample Variable : Pkts Rmon
Alarm Sample Type : delta
Rmon Alarm Type : Rising or Falling Rmon Alarm Rising Threshold : 10000
Rmon Alarm Rising Event 1
Rmon Alarm Falling Threshold 100
Rmon Alarm Falling Event 1
Rmon Alarm Owner : admin
```

show rmon history

Syntax `show rmon history (<1-65535> | all)`

Parameter	<1-65535>	specifies history index to show
	all	Show all existed history

Default No history is defined

Mode Privileged EXEC

Usage Use the **show rmon history** command to show existed RMON history entry.

Example

The example shows how to show RMON history entry.

```
switch(config)# rmon history 1 interface gi1 interval 30 owner admin
switch(config)# show rmon history 1
Rmon History Index 1
Rmon Collection Interface: gi1 Rmon History Bucket 50
Rmon history Interval 30
Rmon History Owner : admin
```

show rmon history statistic

Syntax `show rmon history <1-65535> statistic`

Parameter <1-65535> specifies history index to show history statistic

Default No history is defined

Mode Privileged EXEC

Usage Use the **show rmon history statistic** command to show statistics that are recorded by RMON history.

Example The example shows how to show RMON history statistics

```
switch(config)# show rmon history 1 statistics
```

```
=====
Sample Index 2
Interval Start : (32940466) 3 days, 19:30:04.66
DropEvents 0
Octets : 117226
Pkts 763
BroadcastPkts 9
MulticastPkts 0
CRCAAlignErrors 0
UnderSizePkts 0
OverSizePkts 0
Fragments 0
Jabbers 0
Collisions 0
Utilization 1
```

```
=====
Sample Index 1
Interval Start : (32939462) 3 days, 19:29:54.62
DropEvents 0
Octets 220
Pkts 3
BroadcastPkts 1
MulticastPkts 0
CRCAAlignErrors 0
UnderSizePkts 0
OverSizePkts 0
Fragments 0
```

```
Jabbers        : 0
Collisions    : 0
Utilization   : 0
```

28. SNMP

show snmp

Syntax `show snmp`

Parameter N/A

Default N/A

Mode Privileged EXEC

Usage To show the status of Simple Network Management Protocol (SNMP), use the command **show snmp** in the Privileged EXEC mode.

Example The following example shows the SNMP status.

```
Switch# show snmp
SNMP is disabled.
```

show snmp community

Syntax `show snmp community`

Parameter N/A

Default N/A

Mode Privileged EXEC

Usage To show the configuration of snmp communities, use the command **show snmp community** in the Privileged EXEC mode.

Example

The following example shows the SNMP communities configuration.

```
Switch# show snmp community
Community Name Group Name View Access
-----
private all
ro
public all
rw

Total Entries: 2
```

show snmp engineid

Syntax `show snmp engineid`

Parameter N/A

Default N/A

Mode Privileged EXEC

Usage To show the SNMPv3 engine IDs defined on the switch, use the command **show snmp engineid** in the Privileged EXEC mode.

Example

The following example shows the SNMP engineid information.

```
Switch# show snmp engineid
Local SNMPV3 Engine id: 00036d001122

IP address Remote SNMP engineID
-----
192.168.1.11 00036D10000A

Total Entries: 1
```

show snmp group

Example The following example shows the configuration of SNMP notification recipients on the switch.

Syntax

`show snmp group`

Parameter

```
Switch# show snmp host
Server Community Name Notification Version Notification Type
-----
192.168.1.11 private v1 trap
```

Default N/A

Total Entries: 1

Mode Privileged EXEC

Usage To show the SNMP group configuration on the switch, use the command **show snmp group** in the Privileged EXEC mode.

Example The following example shows the SNMP group configuration.

```
Switch# show snmp group
Group Name Model Level ReadView
WriteView Not
-----
private v2c noauth all
all ---
v3 v3 auth all
all all

Total Entries: 2
```

show snmp host

Syntax **show snmp host**

Parameter N/A

Default N/A

Mode Privileged EXEC

Usage To show the SNMP trap notification recipients defined on the switch, use the command **show snmp host** in the Privileged EXEC mode.

show snmp trap

Syntax **show snmp trap**

Parameter N/A

Default N/A

Mode Privileged EXEC

Usage To show the status of SNMP traps on the switch, use the command **show snmp trap** in the Privileged EXEC mode.

Example The following example shows the status of SNMP traps.

```
Switch# show snmp trap
SNMP auth failed trap : Enable SNMP linkUpDown trap : Enable SNMP
cold-start trap : Enable
SNMP warm-start trap : Enable
```

show snmp view

Syntax **show snmp view**

Parameter N/A

Default N/A

Mode Privileged EXEC

Usage To show the SNMP view defined on the switch, use the command **show snmp view** in the Privileged EXEC mode.

Example The following example shows the configuration of SNMP view.

```
Switch# show snmp view
View Name Subtree OID
OID Mask View Type
-----
-----
```

```
all .1
all included
private .1.3.3.1
all included
```

Total Entries: 2

show snmp user

Syntax **show snmp user**

Parameter N/A

Default N/A

Mode Privileged EXEC

Usage To show the SNMP users defined on the switch, use the command **show snmp user** in the Privileged EXEC mode.

Example The following example shows the configuration of SNMP user.

```
Switch# show snmp user Username: v3
Password: *****
Privilege Mode: rw
Access GroupName: v3 Authentication Protocol: md5 Encryption
Protocol: none Access SecLevel: auth

Total Entries: 1
```

snmp

Syntax **snmp**

Parameter N/A

Default SNMP is disabled by default

Mode Global Configuration

Usage To enable the SNMP on the switch, use the command **snmp** in the Global Configuration mode. Otherwise, use the **no** form of the command to disable to SNMP.

Example The following example enables the SNMP.

```
Switch(config)# snmp
```

snmp community

Syntax **snmp community** *community-name* [**view** *view-name*] (**ro**|**rw**)
snmp community *community-name* **group** *group-name*
no snmp community *community-name*

Parameter *community-name* The SNMP community name. Its maximum length is

20 characters.

view *view-name* Specify the SNMP view configured by the command **snmp view** to define the object available to the community.

ro Read only access (default)

rw Writable access

group *group-name* Specify the SNMP group configured by the command **snmp group** to define the object available to the community.

Default No SNMP community is configured

Mode Global Configuration

Usage To define the SNMP community that permit access for SNMP v1 and v2, use the command **snmp community** in the Global Configuration mode.

Example The following example defines the SNMP community named *private* with the default view *all*, and the access right is *read-only*.

```
Switch(config)# snmp community private ro
```

snmp engineid

Syntax **snmp engineid (default|ENGINEID)**

Parameter	default	Default engine ID generated on the basis of the switch MAC address.
	ENGINEID	Specify SNMP engine ID. The engine ID is the 10 to 64 hexadecimal characters, and the hexadecimal number must be divided by 2.

Default The default SNMP engine ID on the switch is based on switch MAC address.

Mode Global Configuration

Usage To define the SNMP engine on the switch, use the command **snmp engineid** in the Global Configuration mode.

Example The following example configure the switch SNMP engine ID

```
Switch(config)# snmp engineid 00036D001122
```

snmp engineid remote

Syntax	snmp engineid remote (<i>ip-addr ipv6-addr</i>) <i>ENGINEID</i> no snmp engineid remote (<i>ip-addr ipv6-addr</i>)						
Parameter	<table border="1"> <tr> <td><i>ENGINEID</i></td> <td>Specify SNMP engine ID. The engine ID is a 10 to 64 hexadecimal characters, and the hexadecimal number must be divided by 2.</td> </tr> <tr> <td><i>ip-addr</i></td> <td>IP address of the remote host</td> </tr> <tr> <td><i>ipv6-addr</i></td> <td>IPv6 address of the remote host</td> </tr> </table>	<i>ENGINEID</i>	Specify SNMP engine ID. The engine ID is a 10 to 64 hexadecimal characters, and the hexadecimal number must be divided by 2.	<i>ip-addr</i>	IP address of the remote host	<i>ipv6-addr</i>	IPv6 address of the remote host
<i>ENGINEID</i>	Specify SNMP engine ID. The engine ID is a 10 to 64 hexadecimal characters, and the hexadecimal number must be divided by 2.						
<i>ip-addr</i>	IP address of the remote host						
<i>ipv6-addr</i>	IPv6 address of the remote host						
Default	N/A						
Mode	Global Configuration						

Usage To define the remote host for SNMP engine, use the command **snmp engineid remote** in the Global Configuration mode; and use the **no** form of the command to delete the remote host from the SNMP engine.

Example The following example adds the remote *192.168.1.11* into SNMP engine

```
Switch(config)# snmp engineid remote 192.168.1.11 00036D10000A
```

snmp group

Syntax **snmp group** *group-name* (**1|2c|3**) (**noauth|auth|priv**) **read-view** *read-view*
write-view *write-view* [**notify-view** *notify-view*]

no snmp group *group-name* security-mode version (**1|2c|3**)

Parameter *group-name* Specify SNMP group name, and the maximum length is 30 characters.

(1|2c|3) Specify the SNMP version.

noauth Specify that no packet authentication is performed.

auth Specify that no packet authentication without entryption is performed. It is applicable only to the SNMPv3 security mode.

priv Specify that no packet authentication with entryption is performed. It is applicable only to the SNMPv3 security mode.

read-view *read-view*

write-view *write-view*

notify-view *notify-view*

Set the view name that enables configuring the agent, and its maximum length is 30 characters.

Set the view name that enables viewing only, and its maximum length is 30 characters.

Sets the view name that sends only traps with contents that is included in SNMP view selected for notification.

The maximum length is 30 characters.

Default No group entry is existed.

Mode Global Configuration

Usage To define the SNMP group, use the command **snmp group** in the Global Configuration mode, and use the **no** form of the command to delete the configuration.

SNMP group configuration is used in the command **snmp use** to map SNMP users to the SNMP group. These users would be automatically mapped to the SNMP views defined in this command.

The security level for SNMP v1 or v2 is always **noauth**.

Example The following example adds SNMPv3 group

```
Switch(config)# snmp group v3 version 3 auth read-view all
write-view all notify-view all
```

snmp host

Syntax **snmp host** (*ip-addr|ipv6-addr|hostmane*) [**traps|informs**] [**version (1|2c)**] *_community-name* [**udp-port udp-port**] [**timeout timeout**] [**retries retries**]

snmp host (*ip-addr|ipv6-addr|hostmane*) [**traps|informs**] **version 3** [**(auth|noauth|priv)**] *community-name* [**udp-port udp-port**] [**timeout timeout**] [**retries retries**]
no snmp host (*ip-addr|ipv6-addr|hostmane*) [**traps|informs**] [**version (1|2c|3)**]

<i>ip-addr</i>	The IP address of recipient.
<i>ipv6-addr</i>	The IPv6 address of recipient.
<i>hostname</i>	The host name of recipient.
traps	Send SNMP traps to the host. It is the default action.
informs	Send SNMP informs to the host.
version (1 2c 3)	Specify the SNMP version.
noauth	Specify that no packet authentication is performed. It is applicable only to the SNMPv3 security mode.
auth	Specify that no packet authentication without encryption is performed. It is applicable only to the SNMPv3 security mode.
priv	Specify that no packet authentication with encryption is performed. It is applicable only to the SNMPv3 security mode.
<i>community-name</i>	The SNMP community sent with the notification.
udp-port <i>udp-port</i>	Specify the UDP port number.
timeout <i>timeout</i>	Specify the SNMP informs timeout.
retries <i>retries</i>	Specify the retry counter of the SNMP informs.

Default No SNMP host is configured.
The default SNMP version for the command is SNMPv1.

Mode Global Configuration

Usage To configure the hosts to receive SNMP notifications, use the command **snmp host** in the Global Configuration mode; and use the **no** form of the command to delete the configuration.

Example The following example adds the recipient *192.168.1.11* for the SNMP traps notification.

```
Switch(config)# snmp host 192.168.1.11 private
```

snmp trap

Syntax `snmp trap (auth|cold-start|linkUpDown|port-security|warm-start)`

no snmp trap `(auth|cold-start|linkUpDown|port-security|warm-start)`

auth	Enable the SNMP authentication failure trap.
cold-start	Enable the SNMP cold start-up failure trap.
linkUpDown	Enable the SNMP link up and down failure trap.
port-security	Enable the SNMP port security trap.
warm-start	Enable the SNMP warm start-up failure trap.

Default All the SNMP traps are enabled.

Mode Global Configuration

Usage To send the SNMP traps, use the command `snmp trap` in the Global Configuration mode; and use the no form of the command to disable the SNMP traps.

Example The following example disables and enables the SNMP link up and down traps individually.

```
Switch(config)# no snmp trap linkUpDown
Switch(config)# snmp trap linkUpDown
```

snmp user

Syntax `snmp user username group-name [auth (md5|sha) AUTHPASSWD] snmp user username group-name auth (md5|sha) AUTHPASSWD priv PRIVPASSWD`

no snmp user `username`

<i>username</i>	Specify the SNMP user name on the host that connects to the SNMP agent. The max character is 30 characters. For the SNMP v1 or v2c, the user name must match the community name by the command snmp host .
<i>group-name</i>	Specify the SNMP group to which the SNMP user belongs. The SNMP group should be SNMPv3 and configured by the command snmp group .
auth (md5)	Specify the HMAC-MD5-96 authentication protocol as the user authentication.
auth (sha)	Specify the HMAC-SHA-96 authentication protocol as the user authentication.
<i>AUTHPASSWD</i>	The password for authentication and the range of length is from 8 to 32 characters.
Priv PRIVPASSWD	The private password for the privacy key, and the range 64 characters.

Default N/A

Mode Global Configuration

Usage To define a SNMP user, use the command `snmp user` in the Global Configuration mode; and use the no form to delete the SNMP user.

Example The following example adds SNMP user `v3` into the group `v3` by the MD5 authentication.

```
Switch(config)# snmp user v3 v3 auth md5 12345678
```

snmp view

Syntax `snmp view view-name subtree oid-tree oid-mask (all|oid-mask) viewtype (included|excluded)`

no snmp view `view-name subtree (all|oid-tree)`

<i>view-name</i>	The SNMP view name. Its maximum length is 30 characters.
subtree <i>oid-tree</i>	Specify the ASN.1 subtree object identifier (OID) to be included or excluded from the SNMP view.
oid-mask (all oid-mask)	Specify the OID family mask. It is used to define a family of view subtrees. For example, OID mask FA.80 is 11111010.10000000. The length of the OID mask must be less than the length of subtree OID.
iewtype (included excluded)	Include or exclude the selected MIBs in the view.

Default N/A

Mode Global Configuration

Usage To configure the SNMP view, use the command **snmp view** in the Global Configuration mode; and use the **no** form of the command to delete the SNMP view.

The default SNMP view cannot be deleted and modified by users. By default, the maximum numbers of SNMP view is limited to 16.

Example The following example defines the SNMP view.

```
Switch(config)# snmp view private subtree 1.3.3.1 oid-mask all
viewtype included
```

Spanning Tree instance (MST)

Syntax `instance instance-id vlan vlan-list`
no instance `instance-id vlan vlan-list`

Parameter *instance-id* The MSTP instance ID from 0 to 15.
vlan *vlan-list* Add the VLAN list to the MSTP instance.

Default All VLANs are mapped to the Common and Internal Spanning Tree (CIST) instance (instance 0).

Mode MST Configuration

Usage To map the VLAN to the Multiple Spanning Tree (MSTP) instances, use the command instance in the MST Configuration mode; and use the no form of the command to restore its default configuration.

All VLANs that are not explicitly configured to an MSTP instance are mapped to the CIST instance (instance 0).

For two or more switches in the same MSTP region, their VLAN mapping, name and revision number configuration, must be the same.

Example The following example maps the vlan 10-20 to the MSTP instance 1, and VLAN 100 to instance 2.

```
Switch(config)# spanning-tree mst configuration Switch(config-mst)#
instance 1 vlan 10-20
Switch(config-mst)# instance 2 vlan 100
```

name (MST)

Syntax **name** *name-str*
no name

Parameter *name-str* The MSTP instance name. Its maximum length is 32 characters.

Default The default MSTP name is the switch MAC address.

Mode MST Configuration

Usage To define the name for MSTP instance, use the command **name** in the MST Configuration mode; and use the **no** form to restore the default name configuration.

Example The following example configures the name of MST instance to *Valkyrie*.

```
Switch(config)# spanning-tree mst configuration
Switch(config-mst)# name Valkyrie
```

revision (MST)

Syntax **revision** *rev*
no revision

Parameter *rev* The MSTP revision number. Its valid range is from 0 to 65535.

Default The default revision number is 0.

Mode MST Configuration

Usage To define the revision for the MSTP configuration, use the command **revision** in the MST Configuration mode; and use the **no** form of the command to restore it default configuration.

Example The following example defines the revision MSTP configuration to 1.

```
Switch(config)# spanning-tree mst configuration
Switch(config-mst)# revision 1
```

show spanning-tree

Syntax **show spanning-tree**

Parameter N/A

Default N/A

Mode Privileged EXEC

Usage To display the spanning tree configuration, use the command **spanning-tree** in the Privileged EXEC mode

Example The following example shows the spanning tree configuration.

```
Switch# show spanning-tree

Spanning tree enabled mode RSTP Default port cost method: short

Root ID Priority 32768
Address 00:11:22:33:44:55
This switch is the root
Hello Time 4 sec Max Age 10 sec Forward Delay
25 sec

Number of topology changes 2 last change occurred 20:34:30 ago
Times: hold 0, topology change 0, notification 0
hello 4, max age 10, forward delay 25

Interfaces
Name State Prio.Nbr Cost Sts Role EdgePort Type
-----
fa23 enabled 128.23 19 Blk Desg No P2P
(RSTP)
```

show spanning-tree interface

Syntax `show spanning-tree interface IF_PORTS [statistic]`

Parameter	interface	An interface ID or the list of interface IDs.
	<i>IF_PORTS</i>	
	statistic	Display the STP statistic for an interface.

Default N/A

Mode Privileged EXEC

Usage To show the STP configuration and statistics for an interface, use the command `show spanning-tree interface` in the Privileged EXEC mode.

Example

The following example shows the STP configuration for the interface fa23.

```
Switch# show spanning-tree interfaces fa23 Port fa23 enabled
State: forwarding Role:
designated
Port id: 128.23 Port cost: 19
Type: P2P (RSTP) Edge Port: No
Designated bridge Priority : 32768 Address: 00:11:22:33:44:55
Designated port id: 128.23 Designated path cost: 0
BPDU Filter: Disabled BPDU guard: Disabled
BPDU: sent 21886, received 0
```

The following example shows the STP statistic for the interface fa23.

```
Switch# show spanning-tree interfaces fa23 statistic STP Port
Statistic
=====

Port : fa23
Configuration BDPUs Received : 0 TCN BDPUs Received : 0
MSTP BDPUs Received : 0 Configuration BDPUs Transmitted : 0 TCN
BDPUs Transmitted : 0
MSTP BDPUs Transmitted : 21917
=====
```

show spanning-tree mst

Syntax `show spanning-tree mst instance-id`

Parameter	<i>instance-id</i>	The MSTP instance ID. Its valid range is from 0 to 15.
------------------	--------------------	--

Default N/A

Mode Privileged EXEC

Usage To show the information for a specific MSTP instance, use the command **show spanning-tree mst** in the Privileged EXEC mode.

Example The following example displays the information for the MSTP instance 0 and 1 individually.

```
Switch# show spanning-tree mst 0

MST Instance Information
=====
Instance Type : CIST (0)
Bridge Identifier : 32768/ 0/00:11:22:33:44:55
-----
                Designated Root Bridge : 32768/ 0/00:11:22:33:44:55
                External Root Path Cost : 0
                Regional Root Bridge : 32768/ 0/00:11:22:33:44:55
                Internal Root Path Cost : 0
                Designated Bridge : 32768/ 0/00:11:22:33:44:55
                Root Port : 0/0
                Max Age : 10
                Forward Delay : 25
                Topology changes : 3
                Last Topology Change : 930
-----
----- VLANs mapped: 1-99,111-4094
=====

Interface Role Sts Cost Prio.Nbr Type
-----
fa23 Desg FWD 19 128.23 P2P (RSTP)

Switch# show spanning-tree mst 1
MST Instance Information
=====
Instance Type : MSTI (1)
Bridge Identifier : 32768/ 0/00:11:22:33:44:55
-----
Regional Root Bridge : 32768/ 0/00:11:22:33:44:55 Internal Root Path Cost : 0
Remaining Hops : 10 Topology changes : 3
Last Topology Change : 933
-----
VLANs mapped: 100-110
=====

Interface Role Sts Cost Prio.Nbr Type
-----
fa23 Desg FWD 19 128.23 P2P (RSTP)
```

show spanning-tree mst configuration

Syntax `show spanning-tree mst configuration`

Parameter N/A

Default N/A

Mode Privileged EXEC

Usage To show the global MST configuration, use the command **show spanning-tree mst configuration** in the Privileged EXEC mode.

Example The following example shows the global MST configuration.

```
Switch# show spanning-tree mst configuration Name [00:11:22:33:44:55]
Revision 0 Instances configured 2

Instance Vlans mapped
----- 0 1-
99,111-4094
1 100-110
-----
```

show spanning-tree mst interface

Syntax `show spanning-tree mst instance-id interface IF_PORTS`

Parameter *instance-id* The MSTP instance ID. Its valid range is from 0 to 15.

interface An interface ID or the list of interface IDs.

IF_PORTS

Default N/A

Mode Privileged EXEC

Usage To show the MSTP instance information on the specific interface, use the command **show spanning-tree mst interface** in the Privileged EXEC mode.

Example

The following example shows the MSTP 0 and 1 information individually on the interface fa23.

```
Switch# show spanning-tree mst 0 interfaces fa23 MST Port
Information
```

```
=====
Instance Type : CIST (0)
-----
```

```
Port Identifier : 128/23 External Path-Cost : 0 /19
Internal Path-Cost : 0 /19
```

```
-----
Designated Root Bridge : 32768/00:11:22:33:44:55 External Root Cost : 0
Regional Root Bridge : 32768/00:11:22:33:44:55 Internal Root Cost : 0
Designated Bridge : 32768/00:11:22:33:44:55 Internal Port Path Cost : 19
Port Role : Designated Port State : Forwarding
-----
```

```
Switch# show spanning-tree mst 1 interfaces fa23 MST Port Information
```

```
=====
Instance Type : MSTI (1)
-----
```

```
Port Identifier : 128/23 Internal Path-Cost : 0 /19
```

```
-----
Regional Root Bridge : 32768/00:11:22:33:44:55 Internal Root Cost : 0
Designated Bridge : 32768/00:11:22:33:44:55 Internal Port Path Cost : 19
Port Role : Designated Port State : Forwarding
-----
```

spanning-tree

Syntax spanning-tree

no spanning-tree

Parameter N/A

Default Spanning-Tree is enabled by default.

Mode Global Configuration

Usage To enable the spanning tree, use the command spanning-tree in the Global Configuration mode; and use the no form of the command to disable the spanning tree on the switch.

Example

The following example disables and enables the spanning tree individually.

```
Switch(config)# no spanning-tree
```

```
Switch(config)# spanning-tree
```

spanning-tree bpdu

Syntax	spanning-tree bpdu (filtering flooding) no spanning-tree bpdu
Parameter	filtering Filter the BPDU when STP is disabled. flooding Flood the BPDU when the STP is disabled.
Default	The default configuration is flooding.
Mode	Global Configuration

Usage To configure the action of Bridge Protocol Data Unit (BPDU) handling when STP is disabled, use the command **spanning-tree bpdu** in the Global Configuration mode. To restore the configuration to the default action, use the **no** form of the command.

Example The following example configures the action of BPDU handling to filter when the STP is disabled.

```
Switch(config)# spanning-tree bpdu filtering
```

spanning-tree bpdu-filter

Syntax **spanning-tree bpdu-filter**
no spanning-tree bpdu-filter

Parameter N/A

Default BPDU filter is disabled.

Mode Interface Configuration

Usage To enable the BPDU filter, use the command **spanning-tree bpdu-filter** in the Interface Configuration mode; and use **no** form of the command to disable the BPDU filter.

Example The following example enables the BPDU filter for interface fa1.

```
Switch(config)# interface fa1
Switch(config-if)# spanning-tree bpdu-filter
```

spanning-tree bpduguard

Syntax `spanning-tree bpduguard`

no `spanning-tree bpduguard`

Parameter N/A

Default BPDU guard is disabled

Mode Interface Configuration

Usage To enable the BPDU filter, use the command **spanning-tree bpduguard** in the Interface Configuration mode; and use **no** form of the command to disable the BPDU filter.

Example The following example enables the BPDU guard for interface gi1.

```
Switch(config)# interface gi1
Switch(config-if)# spanning-tree bpduguard
```

spanning-tree cost

Syntax `spanning-tree cost cost`

no `spanning-tree cost`

Parameter `cost` The port path cost. For the long path cost method, its valid range is from 0 to 200000000; and the valid range is from 0 to 65535 for the short path cost method. The value 0 indicates AUTO, which the port path cost is determined by the port speed and the path cost method.

Default The default port path cost is 0, and it is determined by the port speed and the path cost method (long or short).

Interface	Long	Short
Gigabit Ethernet (1000Mbps)	20000	4
Fast Ethernet (100Mbps)	200000	19
Ethernet (10Mbps)	2000000	100

Mode Interface Configuration

Usage To configure the STP path cost for an interface, use the command **spanning-tree cost** in the Interface Configuration mode; and use the **no** form of the command to restore it to the default configuration.

Example The following example configures port path cost to 30000 for interface fa2.

```
Switch(config)# interface gil
Switch(config-if)# spanning-tree cost 30000
```

spanning-tree forward-time

Syntax `spanning-tree forward-time` *seconds*

no `spanning-tree forward-time`

Parameter	<i>seconds</i>	STP forward delay time. Its valid range is from 4 to 10 seconds.
------------------	----------------	--

Default	The default forward delay time is 15 seconds.
----------------	---

Mode	Global Configuration
-------------	----------------------

Usage To configure the STP bridge forward delay time, which is the amount of time that a port remains in the Listening and Learning states before it enters the Forwarding state, use the command `spanning-tree forward-time` in the Global Configuration mode. To restore it to the default configuration, use the **no** form of the command.

When the forward delay time is configured, the following relationship should be maintained:

$$2 * (\text{forward-time} - 1) \geq \text{Max-Age}$$

Example The following example configures STP forward delay time to 25.

```
Switch(config)# spanning-tree forward-time 25
```

spanning-tree hello-time

Syntax `spanning-tree hello-time` *seconds*

no `spanning-tree hello-time`

Parameter	<i>seconds</i>	STP hello time in second. Its valid range is from 1 to 10 seconds.
------------------	----------------	--

Default	The default STP hello time is 2 seconds.
----------------	--

Mode	Global Configuration
-------------	----------------------

Usage STP hello time is the time interval to broadcast its hello message to other bridges. To configure the STP hello time, use the command `spanning-tree hello-time` in the Global Configuration mode; and use the **no** form of the

command to restore the hello time to default configuration.

When the hello time is configured, the following relationship should be maintained:

$$\text{Max-Age} \geq 2 * (\text{hello-time} + 1)$$

Example The following example configures BPDU hello time to 4.

```
Switch(config)# spanning-tree hello-time 4
```

spanning-tree edge

Syntax `spanning-tree edge`

`no spanning-tree edge`

Parameter N/A

Default The default configuration is disabled.

Mode Interface Configuration

Usage To enable the edge mode for an interface, use the command **spanning-tree edge** in the Interface Configuration mode; and use the **no** form of the command to restore it to the default configuration.

In the edge mode, the interface would be put into the Forwarding state immediately upon link up. If the edge mode is enabled for the interface and there are BPDUs received on the interface, the loop might be occurred in the short time.

Example The following example enables the edge mode for the interface fa1.

```
Switch(config)# interface fa1
```

```
Switch(config-if)# spanning-tree edge
```

spanning-tree link-type

Syntax `spanning-tree link-type (point-to-point|shared)`
`no spanning-tree link-type`

Parameter	point-to-point	Specify the port link type is point to point.
	shared	Specify the port link type is shared.

Default The default configuration link type is **point-to-point** for the ports with full duplex configuration, and **shared** for the ports with half duplex settings.

Mode Interface Configuration

Usage To set the RSTP link-type for an interface, use the command **spanning-tree link** in the Interface Configuration mode. For the default configuration, use the **no** form of the command.

Example The following example configures the link-type to point-to-point for the interface fa1.

```
Switch(config)# interface fa1
Switch(config-if)# spanning-tree link-type point-to-point
```

spanning-tree max-hops

Syntax **spanning-tree max-hops** *counts*

no spanning-tree max-hops

Parameter *counts* Specify the number of hops in an MSTP region before the BPDU is discarded. The valid range is 1 to 40.

Default The default max-hops configuration is 20.

Mode Global Configuration

Usage To specify the number of hops for a BPDU to be forwarded in the MSTP region, use the command **spanning-tree max-hops** in the Global Configuration mode; and restore the setting to default configuration by the **no** form of the command.

Example The following example specifies the max hops for BPDU to 10.

```
Switch(config)# spanning-tree max-hops 10
```

spanning-tree maximum-age

Syntax **spanning-tree maximum-age** *seconds*

no spanning-tree maximum-age

Parameter *seconds* The interval in seconds for a switch to wait the configuration messages, without attempting to redefine its own configuration.

Default The default maximum age is 20 seconds.

Mode Global Configuration

Usage To set the interval in seconds that the switch can wait without receiving the configuration messages, before attempting to redefine its own configuration, use the command **spanning-tree maximum-age** in the Global Configuration mode. For the default configuration, use the **no** form of the commands.

When the maximum age is configured, the following relationship should be maintained:

$$2 * (\text{forward-time} - 1) \geq \text{Max-Age} \geq 2 * (\text{hello-time} + 1)$$

Example The following example configures STP maximum age to 10.

```
Switch(config)# spanning-tree maximum-age 10
```

spanning-tree mcheck

Syntax **spanning-tree mecheck**

Parameter N/A

Default N/A

Mode Interface Configuration

Usage To restart the Spanning Tree Protocol (STP) migration process (re-negotiate forcibly with its neighborhood) on the specific interface, use the command **spanning-tree mcheck** in the Interface Configuration mode

Example The following example restarts the STP negotiation on the interface fa1.

```
Switch(config)# interface fa1
Switch(config-if)# spanning-tree mecheck
```

spanning-tree mode

Syntax **spanning-tree mode (mstp|rstp|stp)**
no spanning-tree force-version

Parameter	Parameter	Description
mstp	Enable the Multiple Spanning Tree (MSTP) operation.	
rstp	Enable the Rapid Spanning Tree (RSTP) operation.	
stp	Enable the Spanning Tree (STP) operation.	

Default The default mode is rstp.

Mode Global Configuration

Usage To specify the spanning tree operation mode, use the command of **spanning-tree mode** in the Global Configuration mode. For the default configuration, use the command **no spanning-tree force-version** in the Global Configuration mode.

When the switch is configured as MSTP mode, it can use STP and RSTP for the backward compatibility with switches working in STP and RSTP mode individually. For the RSTP configuration, the switch can also use STP for the switches working in the STP operation.

Example The following example sets the STP operation to MSTP.

```
Switch(config)# spanning-tree mode mstp
```

spanning-tree mst configuration

Syntax **spanning-tree mst configuration**

Parameter N/A

Default N/A

Mode Global Configuration

Usage To enter the MST configuration mode for the MSTP configuration modification, use the command **spanning-tree mst configuration** in the Global Configuration mode.

Example The following example modifies the MSTP configuration in the MST Configuration mode.

```
Switch(config)# spanning-tree mst configuration Switch(config-mst)#
instance 1 vlan 10-20 Switch(config-mst)# name Valkyrie
Switch(config-mst)# revision 1
```

spanning-tree mst cost

Syntax **spanning-tree mst instance-id cost cost**
no spanning-tree mst instance-id cost cost

Parameter *instance-id* Specify the instance ID. The valid range is from 0 to 15.

cost Specify the path cost for the interfaces on the specific MSTP instance. For the long path cost method, its valid range is from 0 to 200000000; and the valid range is from 0 to 65535 for the short path cost method. The value 0 indicates AUTO, which the port path cost is determined by the port speed and the path cost method.

Default The default port path cost is 0, and it is determined by the port speed and the path cost method (long or short).

Interface	Long	Short
Gigabit Ethernet (1000Mbps)	20000	4
Fast Ethernet (100Mbps)	200000	19
Ethernet (10Mbps)	2000000	100

Mode Interface Configuration

Usage To configure the path cost for MSTP calculations, use the command **spanning-tree mst cost** in the Interface Configuration mode. If the loop occurs, the MSTP considers the path cost when selecting the interface into the Forwarding state. For the default configuration, use the no form of the command.

When configuring the path cost on the CIST (instance 0), it is equal to the

command **spanning-tree cost** in the Interface Configuration mode.

Example The following example configures the path cost of interface fa1 on the instance 1 to 30000

```
Switch(config)# interface gi1
Switch(config-if)# spanning-tree mst 1 cost 30000
```

spanning-tree mst port-priority

Syntax **spanning-tree mst** *instance-id* **port-priority** *priority*
no spanning-tree mst *instance-id* **port-priority**

Parameter *instance-id* Specify the instance ID. The valid range is from 0 to 15.

priority Specify the interface priority on the specific instance.

Default The default port priority on each instance is 128

Mode Interface Configuration

Usage To configure the interface priority on the specific instances, use the command **spanning-tree mst port-priority** in the Interface Configuration mode. For the default configuration, use the **no** form of the command.

The priority value must be the multiple of 16. When the port priority on the CIST (instance 0) is configured, it is

equal to the command **spanning-tree port-priority** in the Interface Configuration mode.

Example The following example sets the port priority of gi1 on the instance 1 to 144; and set the port priority of gi1 on the CIST (instance 0) to 96

```
Switch(config)# interface gi1
Switch(config-if)# spanning-tree mst 1 port-priority 144
Switch(config-if)# spanning-tree mst 0 port-priority 96
```

spanning-tree mst priority

Syntax **spanning-tree mst instance** *instance-id* **priority** *priority*
no spanning-tree mst instance *instance-id* **priority**

Parameter	<i>instance-id</i>	Specify the instance ID. The valid range is from 0 to 15.
	<i>priority</i>	Specify the bridge priority on the specific instance. The

valid range is from 0 to 61440. It ensures the probability that the switch is selected as the root bridge, and the lower values has the higher priority for the switch to be selected as the root bridge.

Default The default priority on each instance is 32768.

Mode Global Configuration

Usage To configure the bridge priority on the specific instance, use the command **spanning-tree mst priority** in the Global Configuration mode. To restore the default configuration, use the **no** form of the command.

The value of bridge priority must be the multiple of 4096. A switch with the lowest priority is the root of the STP topology. For the configuration of bridge priority on the CIST (instance 0), it is equal to the command **spanning-tree priority** in the Global Configuration mode.

Example The following example modifies the bridge priority to 4096 on instance 0 and instance 1 individually.

```
Switch(config)# spanning-tree mst 0 priority 4096
Switch(config)# spanning-tree mst 1 priority 4096
```

spanning-tree pathcost method

Syntax **spanning-tree pathcost method** (long|short)

Parameter	long	The range for the path cost is from 1 to 200000000.
	short	The range for the path cost is from 1 to 65535.

Default The default path cost method is long.

Mode Global Configuration

Usage To set the spanning tree path cost method, use the command **spanning-tree pathcost method** in the Global Configuration mode.

If the short method is specified, the switch calculates the path cost in the range 1 through 65535; Otherwise, it calculates the path cost in the range 1 to 200000000.

Example The following example modifies path cost method to short.

```
Switch(config)# spanning-tree pathcost method short
```

spanning-tree port-priority

Syntax **spanning-tree port-priority** *priority*
no spanning-tree port-priority *priority*

Parameter *priority* Specify the priority for an interface. The valid range is from 0 to 240.

Default The default priority for each interface is 128.

Mode Interface Configuration

Usage To configure the STP priority for an interface, use the command **spanning- tree port-priority** in the Interface Configuration mode. For the default configuration, use the **no** form of the command.

The priority value must be the multiple of 16.

Example The following example modifies the port priority to 96 for the interface gi2 .

```
Switch(config)# interface gi2
Switch(config-if)# spanning-tree port-priority 96
```


spanning-tree priority

Syntax `spanning-tree priority priority`
`no spanning-tree priority`

Parameter	<i>instance-id</i>	Specify the instance ID. The valid range is from 0 to 15.
	<i>priority</i>	Specify the bridge STP priority. The valid range is from 0 to 61440. It ensures the probability that the switch is selected as the root bridge, and the lower values has the higher priority for the switch to be selected as the root

bridge of the STP topology.

Default The default priority for the switch 32768.

Mode Global Configuration

Usage To configure the bridge priority, use the command **spanning-tree mst priority** in the Global Configuration mode. To restore the default configuration, use the **no** form of the command.

The value of bridge priority must be the multiple of 4096. A switch with the lowest priority is the root of the STP topology. When switches with the same priority configuration in the environment, the switch with lowest MAC address would be selected as the root bridge.

Example The following example modifies the bridge priority to 4096.

```
Switch(config)# spanning-tree priority 4096
```

spanning-tree tx-hold-count

Syntax `spanning-tree tx-hold-count count`
`no spanning-tree tx-hold-count`

Parameter *count* Specify the tx-hold-count used to limit the maximum numbers of packets transmission per second. The valid range is from 1 to 10.

Default The default value is 6.

Mode Global Configuration

Usage To limit the maximum numbers of packets transmission per second, use the command **spanning-tree tx-hold-count** in the Global Configuration mode. For the default configuration, use the **no** form of the command.

Example The following example sets the tx-hold-count to 4.

```
Switch(config)# spanning-tree tx-hold-count 4
```

Storm Control

show storm-control

Syntax `show storm-control`

show storm-control interface *IF_PORTS*

Parameter	<i>IF_PORTS</i>	Specify port to show.
Default	No default value for this command	
Mode	Privileged EXEC	

Usage Use “**show storm-control**” command to show all storm control related configurations including global configuration and per port configurations.

Use “**show storm-control interface**” command to show selected port storm control configurations.

Example This example shows how to show storm control global configuration.

```
Switch# show storm-control
Storm control preamble and IFG: Excluded Storm control unit: pps
.....
```

This example shows how to show current storm control configuration on interface gi1

```
Switch# show storm-control interfaces gi1
Port | State | Broadcast | Unkown-Multicast | Unknown-Unicast | Action
| | pps | pps | pps
|
-----+-----+-----+-----+-----+-----+-----|-----
---
fa1 enable 200 Off( 10000) Off( 10000)
Shutdown
```

storm-control

Syntax **storm-control**
 no storm-control

storm-control (broadcast | unknown-unicast | unknown-multicast) no storm-control (broadcast | unknown-unicast | unknown-multicast)

Parameter broadcast Select broadcast storm control type

unknown-unicast Select unknown unicast storm control type

unknown-multicast Select unknown multicast storm control type

Default Default storm control is disabled.
 Default broadcast storm control is disabled.

Default unknown multicast storm control is disabled Default unknown unicast storm control is disabled

Mode Interface Configuration

Usage Storm control function is able to enable/disable on each single port. Use the “**storm control**” command to enable storm control feature on the selected ports. And use “**no storm control**” command to disable storm control feature. Not only port is able to enable/disable on the port. Each storm control type is also able to enable/disable on each single port.

Use the “**storm-control (broadcast|unknown-unicast|unknown-multicast)**” command to enable the storm control type you need and use no form to disable it.

Example This example shows how to enable storm control on interface gi1.

```
Switch(config)# interface gi1
Switch(config-if)# storm-control
```

This example shows how to enable broadcast storm control and configure broadcast storm control rate to 200.

```
Switch(config)# interface gi1
Switch(config-if)# storm-control broadcast
```

This example shows how to show current storm control configuration on interface gi1

```
Switch# show storm-control interfaces gi1
Port | State | Broadcast | Unkown-Multicast | Unknown-Unicast | Action
| | pps | pps | pps
|
-----+-----+-----+-----+-----+-----|-----
---
gi1 enable 200 Off( 10000) Off( 10000)
Shutdown
```

storm-control action

Syntax `storm-control action (drop | shutdown)`
`no storm-control action`

Parameter drop Storm control rate calculates by octet-based
shutdown

Default Default storm control action is drop.

Mode Interface Configuration

Usage Use “**storm-control action**” command to set the action when the received storm control packets exceed the maximum rate on an interface. Use **no** form to restore to default action.

Example This example shows how to configure storm control action to shutdown port on interface g1l.

```
Switch(config)# interface g1l
Switch(config-if)# storm-control action shutdown
```

This example shows how to show storm control action on interface g1l.

```
Switch# show storm-control interfaces g1l
Port | State | Broadcast | Unkown-Multicast | Unknown-Unicast | Action
| | pps | pps | pps
|
-----+-----+-----+-----+-----+-----+-----
---
g1l disable Off( 10000) Off( 10000) Off( 10000)
Shutdown
```

storm-control ifg

Syntax `storm-control ifg (include | exclude)`

Parameter include Include preamble & IFG (20 bytes) when count ingress storm control rate.

exclude Exclude preamble & IFG (20 bytes) when count ingress storm control rate

Default Default storm control inter frame gap is excluded.

Mode Global Configuration

Usage Storm control mechanism will try to calculate ingress packets is exceed configured rate or not and do corresponding action.

Use **storm-control ifg** command to include/exclude the preamble and inter frame gap into the calculating.

Example

This example shows how to configure storm inter frame gap to include.
 Switch(config)# **storm-control ifg include**

This example shows how to show storm control global configuration.
 Switch# **show storm-control**
 Storm control preamble and IFG: Included

Storm control unit: pps

storm-control level

Syntax **storm-control (broadcast | unknown-unicast | unknown-multicast) level**
<1-1000000>
no storm-control (broadcast | unknown-unicast | unknown-multicast)
level

Parameter broadcast Select broadcast storm control type

unknown-unicast Select unknown unicast storm control type

unknown- multicast

Select unknown multicast storm control type

level <1-1000000> Specify the storm control rate for selected type.

For bps, range is 16-1000000

For pps, range is 1-262143

Default

Default broadcast storm control rate is 10000.

Default unknown multicast storm control rate is 10000. Default unknown unicast storm control rate is 10000.

Mode

Interface Configuration

Usage Each control type is allowed to have different storm control rate.

Use “**storm-control (broadcast|unknown-unicast|unknown-multicast) level**” command to configure it

Use no form to restore to default rate.

Example

This example shows how to enable broadcast storm control and configure broadcast storm control rate to 200.

```
Switch(config)# interface gi1
Switch(config-if)# storm-control broadcast
Switch(config-if)# storm-control broadcast level 200
```

This example shows how to show current storm control configuration on interface gi1

```
Switch# show storm-control interfaces gi1
Port | State | Broadcast | Unkown-Multicast | Unknown-Unicast | Action
| | pps | pps | pps
|
-----+-----+-----+-----+-----+-----|-----
---
gil enable 200 Off( 10000) Off( 10000)
Shutdown
```

storm-control unit

Syntax `storm-control unit (bps | pps)`

Parameter	bps	Storm control rate calculates by octet-based
	pps	Storm control rate calculates by packet-based

Default Default storm control unit is bps.

Mode Global Configuration

Usage Storm control mechanism will try to calculate ingress packets is exceed configured rate or not and do corresponding action.

Use **storm-control unit** command to change the unit of calculating method.

Example

This example shows how to configure storm control rate unit as pps.

```
Switch(config)# storm-control unit pps
```

This example shows how to show storm control global configuration.

```
Switch# show storm-control
Storm control preamble and IFG: Excluded Storm control unit: pps
.....
```

System File

boot system

Syntax `boot system (image0 | image1)`

Parameter	image0	image1
	Boot from flash image partition 0	Boot from flash image partition 1

Default Default boot image is image0.

Mode Global Configuration

Usage Dual image allow user to have a backup image in the flash partition. Use “**boot system**” command to select the active firmware image. And another firmware image will become a backup one.

Example This example shows how to select image1 as active image.

```
Switch(config)# boot system image1
Select "image1" Success
```

This example shows how to show active image partition.

```
Switch# show flash
File Name File Size Modified
-----
startup-config 1191 2000-01-01 00:00:23
backup-config 1607 2000-01-01 08:36:23
rsa1 974 2000-01-01 00:00:18
rsa2 1675 2000-01-01 00:00:18
dsa2 668 2000-01-01 00:00:18
ssl_cert 993 2000-01-01 00:00:18
image0 (backup) 4372401 2012-09-24 01:57:29
image1 (active) 5555970 2012-06-12 12:17:46
```

copy

Syntax `copy (flash:// | tftp://) (flash:// | tftp://)`
`copy tftp:// (backup-config | running-config | startup-config) copy`
`(backup-config | running-config | startup-config) tftp://`

`copy (backup-config | startup-config) running-config copy`
`(backup-config | running-config) startup-config copy (running-`
`config | startup-config) backup-config`

Parameter	flash://	Specify the file stored in flash to operation. Available files are: flash://startup-config flash://backup-config flash://rsa1 flash://rsa2 flash://dsa2 flash://image0 flash://image1 flash://ram.log flash://flash.log
------------------	-----------------	--

tftp://	Specify remote tftp server and remote file name. The format is “ tftp://192.168.1.111/remote_file_name ”
----------------	---

running-config	Running configuration file
-----------------------	----------------------------

startup-config	Startup configuration file
-----------------------	----------------------------

backup-config	Backup configuration file
----------------------	---------------------------

Default	No default value for this command.
----------------	------------------------------------

Mode	Privileged EXEC
-------------	-----------------

Usage	There are many types of files in system. These files are very important for administrator to manage the switch. The most common file operation is copy. By using these copy commands, we can upgrade, backup following type of files.
--------------	---

Firmware Image

Configuration Files

Syslog Files

Language Files

Security Certificate

Example	This example shows how to copy running configuration to startup configuration. Switch# copy running-config startupst-config
----------------	---

This example shows how to backup running configuration to remote tftp server 192.168.111 with file name test1.cfg.

```
Switch# copy running-config tftp://192.168.1.111/test1.cfg
Uploading file...Please Wait... Uploading Done
```

This example shows how to upgrade startup configuration from remote tftp server 192.168.1.111 with file name test2.cfg.

```
Switch# copy tftp://192.168.1.111/test2.cfg startup-config
Downloading file...Please Wait... Downloading Done
Upgrade config success. Do you want to reboot now? (y/n)n
```

This example shows how to backup security file dsa2 to remote tftp server 192.168.1.111 with file name dsa2.

```
Switch# copy flash://dsa2 tftp://192.168.1.111/dsa2
Uploading file...Please Wait... Uploading Done
```


delete

Syntax `delete (startup-config | backup-config | flash://)`

`delete system (image0 | image1)`

Parameter	flash://	Specify the configuration file stored in flash to delete. Available files are: flash://startup-config flash://backup-config
	startup-config	Delete startup configuration file
	backup-config	Delete backup configuration file
	image0	Delete flash image0.
	image1	Delete flash image1.

Default No default value for this command.

Mode Privileged EXEC

Usage Use “**delete**” command to delete configuration files or use “**delete system**” command to delete firmware image stored in flash.

The “**delete startup-config**” command is using to restore factory default and it is equal to command “**restore-defaults**”.

Example

This example shows how to delete backup configuration file.
Switch# **delete backup-config**

This example shows how to delete backup firmware image from flash.
Switch# **delete system image1**

This example shows how to show file status in flash.

```
Switch# show flash
File Name File Size Modified
-----
startup-config 1191 2000-01-01 00:00:23
backup-config 1607 2000-01-01 08:36:23
rsa1 974 2000-01-01 00:00:18
rsa2 1675 2000-01-01 00:00:18
dsa2 668 2000-01-01 00:00:18
ssl_cert 993 2000-01-01 00:00:18
image0 (active) 4372401 2012-09-24 01:57:29
image1 (backup) 0
```

restore-defaults

Syntax `restore-defaults [interfaces IF_PORTS]`

Parameter `interfaces` Specify port to restore its' running config
`IF_PORTS`

Default No default value for this command.

Mode Privileged EXEC

Usage Use “**restore-defaults**” command to restore factory default of all system. The command is equal to “**delete startup-config**”,

Example This example shows how to restore factory defaults.
 Switch# **restore-defaults**
 Restore Default Success. Do you want to reboot now? (y/n)n

save

Syntax `save`

Parameter

Default No default value for this command.

Mode Privileged EXEC

Usage Use “**save**” command to save running configuration to startup configuration file. This command is equal to “**copy running-config startup-config**”.

Example

This example shows how to save running configuration to startup configuration.

```
Switch# save
Success
```

This example shows how to show startup configuration

```
Switch# show startup-config
! System Description: RTK RTL8328-24FE-4GE Switch
! System Version: v2.5.0-beta.32811
! System Name: SwitchEF0102
! System Up Time: 0 days, 4 hours, 31 mins, 43 secs
!
!
!
!
username "" privilege user secret "dnXencJRwflV6" username "admin"
secret "FzjrGO6vfbERY"
voice-vlan vpt 0
voice-vlan dscp 0
.....
```

show bootvar

Syntax

show bootvar

Parameter

Default

No default value for this command.

Mode

Privileged EXEC

Usage

Use “**show bootvar**” command to show image information in both flash partitions. It also shows current active image and active image on next booting.

Example

This example shows how to show dual image information

```
Switch# show bootvar
Image  Version Date Status File Name
-----
0 3.0.5 2014-09-22 16:53:53 Active v3.0.5.bix
1 3.1.0 2014-10-09 18:32:26 Not active* v3.1.0.bix
```

show config

Syntax

show (running-config | startup-config | backup-config)

show running-config interfaces IF_PORTS

Parameter		
	running-config	Show running configuration on terminal
	startup-config	Show startup configuration on terminal
	backup-config	Show backup configuration on terminal
	<i>IF_PORTS</i>	Specify port to show its' ruuning config

Default No default value for this command.

Mode Privileged EXEC

Usage Our configuration file is text based. Therefore, we can show the configuration on terminal and read it by this command.
 Use “**show config**” command to show configuration files stored in system. Use “**show config interfaces**” command to show specific port configurations.

Example

This example shows how to show startup configuration

```
Switch# show startup-config
! System Description: RTK RTL8328-24FE-4GE Switch
! System Version: v2.5.0-beta.32811
! System Name: SwitchEF0102
! System Up Time: 0 days, 4 hours, 31 mins, 43 secs
!
!
!
username "" privilege user secret "dnXencJRwflV6" username
"admin" secret "FzjrGO6vfbERY"
voice-vlan vpt 0
voice-vlan dscp 0
.....
```

This example shows how to show running configuration

```
Switch# show running-config
! System Description: RTK RTL8328-24FE-4GE Switch
! System Version: v2.5.0-beta.32811
! System Name: SwitchEF0102
! System Up Time: 0 days, 5 hours, 23 mins, 42 secs
!
!
!
username "" privilege user secret "dnXencJRwflV6" username
"admin" secret "FzjrGO6vfbERY"
voice-vlan vpt 0
voice-vlan dscp 0
.....
```

This example shows how to display running configuration on specific port.

```
Switch# show running-config interfaces gil
interface gil
  rate-limit ingress 128
```

show flash

Syntax **show flash**

Parameter

Default No default value for this command.

Mode Privileged EXEC

Usage Use “**show flash**” command to show all files’ status which stored in flash.

Example

This example shows how to show all files status stored in flash.

```
Switch# show flash
File Name File Size Modified
-----
startup-config 1191 2000-01-01 00:00:23
backup-config 1607 2000-01-01 08:36:23
rsa1 974 2000-01-01 00:00:18
rsa2 1675 2000-01-01 00:00:18
dsa2 668 2000-01-01 00:00:18
ssl_cert 993 2000-01-01 00:00:18
image0 (active) 4372401 2012-09-24 01:57:29
image1 (backup) 0
```

Surveillance VLAN

surveillance-vlan (Global)

Syntax

```
surveillance-vlan
no surveillance -vlan
```

Parameter

Default Surveillance VLAN is disabled

Mode

Global Configuration

Usage Use the **surveillance vlan** global configuration command to enable the functional Surveillance VLAN on the device.

Use the **no** form of this command to disable Surveillance VLAN function. You can verify your setting by entering the **show surveillance vlan Privileged EXEC** command.

Example

The following example shows how to enable Surveillance VLAN.

```
Switch(config)# surveillance -vlan
Switch# show surveillance -vlan
Administrate Surveillance VLAN state : disabled Surveillance VLAN ID : none
(disable) Surveillance VLAN Aging : 1440 minutes Surveillance VLAN CoS 6
Surveillance VLAN 1p Remark: disabled
```

surveillance-vlan (Interface)

Syntax surveillance-vlan

no surveillance-vlan

Parameter

N/A

Default

Disable by default.

Mode Interface Configuration

Usage Use the **surveillance vlan** Interface configuration command to enable OUI surveillance VLAN configuration on an interface
 Use the **no** form of this command to disable Surveillance VLAN on an interfaces
 You can verify your setting by entering the **show surveillance vlan Privileged EXEC** command

Example The following example how to enable Surveillance VLAN function in oui mode on an interface
 Switch(config)#**interface range fa1-3**
 Switch(config-if)#**surveillance-vlan**
 Switch# **show surveillance-vlan interfaces fa1-3** Surveillance VLAN Aging :
 1440 minutes Surveillance VLAN CoS 7
 Surveillance VLAN 1p Remark: enabled

```
OUI table
OUI MAC | Description
-----+-----
00:01:02 | Test
```

```
Port | State | Port Mode | Cos Mode
-----+-----+-----+-----
fa1 | Disabled | Auto | Src fa2 | Disabled | Auto | Src
fa3 | Disabled | Auto | Src
```

surveillance-vlan vlan

Syntax **surveillance-vlan vlan** <1-4094>
no surveillance-vlan vlan

Parameter	<1-4094>	Specify the Surveillance VLAN ID
------------------	----------	----------------------------------

Default The default Surveillance VLAN ID is None.

Mode Global Configuration

Usage Use the **surveillance vlan id** global configuration command to configure the VLAN identifier of the surveillance VLAN statically.

Use the **no** form of this command to restore surveillance VLAN id to default. You can verify your setting by entering the **show surveillance vlan Privileged EXEC** command

Example The following example shows how to set Surveillance VLAN id. The VLAN id must be created first.

```
Switch(config)# surveillance-vlan vlan 128
Switch# show surveillance-vlan
Administrate Surveillance VLAN state : enabled Surveillance VLAN ID 128
Surveillance VLAN Aging : 1440 minutes Surveillance VLAN CoS 6
Surveillance VLAN 1p Remark: disabled
```

surveillance-vlan oui-table

Syntax **surveillance-vlan oui-table** A:B:C [DESCRIPTION]
no surveillance-vlan oui-table [A:B:C]

Parameter	A:B:C	Specify OUI Mac address to add or remove
	DESCRIPTION	Specify description of the specified MAC address to the <u>surveillance VLAN OUI table</u>

Default Default has no pre-defined OUI.

Mode Global Configuration

Usage Use the **surveillance vlan oui-table** global configuration command to add OUI mac address to OUI Table
 Use the **no** form of this command to remove all or specified OUI mac address..
 You can verify your setting by entering the **show surveillance vlan Privileged EXEC** command

Example This following example shows how to add OUI Mac. Switch(config)# **surveillance-vlan oui-table 00:01:02 "Test"** Switch# **show surveillance-vlan interfaces fa1-3** Surveillance VLAN Aging : 1440 minutes
Surveillance VLAN CoS : 6

Surveillance VLAN 1p Remark: disabled

```
OUI table
OUI MAC | Description
-----+-----
00:01:02 | Test
```


Port | State | Port Mode | Cos Mode

-----+-----+-----+-----
 fa1 | Disabled | Auto | Src fa2 | Disabled | Auto | Src
fa3 | Disabled | Auto | Src

surveillance-vlan cos (Global)

Syntax **surveillance-vlan cos** <0-7> [remark]
no surveillance-vlan cos

Parameter <0-7> Specify the surveillance VLAN Class of Service value in telephone OUI mode

remark Specify that the L2 user priority is remarked with the CoS value

Default The default cos value is 6, remark is disabled.

Mode Global Configuration

Usage Use the **surveillance vlan cos** global configurations command to configure the surveillance VLAN cos value and 1p remark function.
 Use the “**no**” form to restore to default mode.
 You can verify your setting by entering the **show surveillance vlan Privileged EXEC** command

Example The following example show how to set cos value and enable 1p remark function

```
Switch(config)# surveillance-vlan cos 7 remark
Switch# show surveillance-vlan
Administrate Surveillance VLAN state : disabled Surveillance VLAN ID 128
Surveillance VLAN Aging : 1440 minutes Surveillance VLAN CoS 7
Surveillance VLAN 1p Remark: enabled
```

surveillance-vlan cos (Interface)

Syntax **surveillance-vlan cos** (src | all)
no surveillance-vlan cos

Parameter src Specify QoS attributes are applied to packets with OUIs in the source MAC address.

All Specify QoS attributes are applied to packets that are classified to the Surveillance VLAN.

Default The default all port in Src mode.

Mode Interface configuration

Usage Use the **surveillance-vlan cos mode** Interface configuration command to configure OUI surveillance VLAN cos mode configuration on an interface. Use the “no” form to restore to default mode.

You can verify your setting by entering the **show surveillance-vlan interfaces Privileged EXEC** command

Example The following example how to configure surveillance packet QoS attributes on an interface

```
Switch(config)#interface range fa1-3 Switch(config-if)#surveillance-vlan cos all
Switch# show surveillance-vlan interfaces fa1-3 Surveillance VLAN Aging : 1440
minutes Surveillance VLAN CoS 7
Surveillance VLAN 1p Remark: enabled
```

```
OOUI table
OUI MAC | Description
-----+-----
00:01:02 | Test
```

```
Port | State | Port Mode | Cos Mode
-----+-----+-----+-----
fa1 | Disabled | Auto | All fa2 | Disabled | Auto | All
fa3 | Disabled | Auto | All
```

surveillance-vlan mode

Syntax **surveillance-vlan mode (auto|manual) no surveillance-vlan mode**

Parameter	auto	Specifies that the port is identified as a candidate to join
-----------	------	--

the surveillance VLAN. When a packet with a source OUI MAC address that identifies the remote equipment as surveillance equipment is seen on the port, the port joins the surveillance VLAN as a tagged port.

manual	Specifies that the port is manually assigned to the <u>surveillance VLAN</u> .
---------------	--

Default The default is auto mode.

Mode Interface Configuration

Usage Use the ~~surveillance-vlan mode~~ global configuration command to configure the surveillance VLAN mode for interface.
 Use the “no” form to restore to default mode.
 You can verify your setting by entering the **show surveillance-vlan interfaces** Privileged EXEC command.

Example The following example shows how to configure surveillance mode to manual
 Switch(config)#**interface range fa1-3**
 Switch(config-if)#**surveillance-vlan mode manual** Switch# **show surveillance-vlan interfaces fa1-3** Surveillance VLAN Aging : 1440 minutes Surveillance VLAN CoS 7
 Surveillance VLAN 1p Remark: enabled

OUI table
 OUI MAC | Description
 -----+-----
 00:01:02 | Test

Port | State | Port Mode | Cos Mode
 -----+-----+-----+-----
 fa1 | Disabled | Manual | Src fa2 | Disabled | Manual | Src fa3 | Disabled | Manual | Src

surveillance-vlan aging-time

Syntax **surveillance-vlan aing-time** <30-65536>
no surveillance-vlan aing-time

Parameter	<30-65536>	Specify the Surveillance VLAN aging timeout interval <u>in minutes</u>
------------------	------------	---

Default The default aging-timeout value is 1440 minutes

Mode Global Configuration

Usage Use the **surveillance vlan aging-time** global configuration command to configure the surveillance VLAN aging timeout.
 Use the “**no**” form to restore to default time.
 You can verify your setting by entering the **show surveillance vlan Privileged EXEC** command

Example The following example shows how to set aging time. Switch(config)# **surveillance-vlan aging-time 720** Switch# **show surveillance-vlan**
 Administrate Surveillance VLAN state : disabled Surveillance VLAN ID 1
 Surveillance VLAN Aging : 720 minutes Surveillance VLAN CoS 5
 Surveillance VLAN 1p Remark: enabled

show surveillance-vlan

Syntax show surveillance-vlan

show surveillance-vlan interfaces [IF_PORTS]

Parameter	IF_PORTS	Specifies interfaces to display surveillance VLAN settings in OUI mode
------------------	----------	--

Default	N/A
----------------	-----

Mode	Privileged EXEC
-------------	-----------------

Usage Use the **show surveillance vlan** command in EXEC mode to display the surveillance VLAN status for all interfaces or for a specific interface if the surveillance VLAN type is OUI

Example

The following example show how to display surveillance vlan OUI mode settings

```
Switch# show surveillance-vlan
Administrate Surveillance VLAN state : disabled Surveillance VLAN ID : none
(disable) Surveillance VLAN Aging : 720 minutes Surveillance VLAN CoS 6
Surveillance VLAN 1p Remark: disabled
Switch# show surveillance-vlan interfaces fa1-4 Surveillance VLAN Aging : 720
minutes Surveillance VLAN CoS 5
Surveillance VLAN 1p Remark: enabled
```

```
OOUI table
OUI MAC | Description
-----+-----
00:01:02 | Test
```

```
Port | State | Port Mode | Cos Mode
-----+-----+-----+-----
fa1 | Disabled | Auto | Src fa2 | Disabled | Auto | Src
fa3 | Disabled | Auto | Src
```

Time clock set

Syntax **clock set HH:MM:SS (jan|feb|mar|apr|may|jun|jul|aug|sep|oct|nov|dec)**
<1-31> <2000-2035>

Parameter HH:MM:SS (jan|feb|mar|apr
|may|jun|jul|aug| sep|oct|nov|dec)
<1-31> <2000-

Specify static time of year, month, day, hour, minute, second

2035>

Default No default is defined.
The clock set to 2000/01/01 08:00:00 by default at startup.

Mode Privileged EXEC

Usage Use the **clock set** command to set static time. The static time won't save to configuration file. You can verify your setting by entering the **show clock Privileged EXEC** command.

Example The example shows how to set static time of switch.

```
switch# clock set 11:03:00 sep 21 2012
11:03:00 DFL(UTC+8) Sep 21 2012
```

```
switch# show clock
11:03:21 DFL(UTC+8) Sep 21 2012
No time source
```

clock timezone

Syntax **clock timezone ACRONYM HOUR-OFFSET [minutes <0-59>]**

Parameter	ACRONYM	Specify acronym name of time zone
	HOUR-OFFSET	Specify hour offset of time zone
	Minutes <1-59>	Specify minute offset of time zone

Default Default time zone is UTC+8.

Mode Global Configuration

Usage Use the **clock timezone** command to set timezone setting. Use the **no** form of this command to restore to default setting. You can verify your setting by entering the **show clock detail Privileged EXEC** command.

Example

The example shows how to set time zone of switch and then restore to default time zone.

```
switch(config)# clock timezone test +5 switch(config)# show clock detail 10:13:27
test(UTC+5) Sep 21 2012
No time source
```

Time zone: Acronym is test Offset is UTC+5

```
switch(config)# no clock timezone
switch(config)# show clock detail
```

```
13:14:50 DFL(UTC+8) Sep 21 2012
No time source
```

Time zone: Acronym is DFL Offset is UTC+8

clock source

Syntax clock source (local|sntp)

Parameter	local	Specify to use static time
	sntp	Specify to use sntp time

Default Default is using local time.

Mode Global Configuration

Usage Use the **clock source** command to set the source of time.

Use the no form of this command to restore to default setting.

You can verify your setting by entering the **show clock detail Privileged EXEC** command.

```
(sun|mon|tue|wed|thu|fri|sat)
(jan|feb|mar|apr|may|jun|jul|aug|sep|oct|nov|dec) HH:MM (<1-5>|first|last) (sun|mon|tue|wed|thu|fri|sat)
(jan|feb|mar|apr|may|jun|jul|aug|sep|oct|nov|dec) HH:MM [<1-1440>]
no clock summer-time
```

Example

The example shows how to set clock source of switch.

```
switch(config)# clock source sntp switch(config)# show clock detail 08:32:12
test(UTC+5) Sep 21 2012
Time source is sntp
```

Time zone: Acronym is DFL Offset is UTC+8

clock summer-time

Syntax	clock	summer-time	ACRONYM	date
	(jan feb mar apr may jun jul aug sep oct nov dec) <1-31>	<2000-2037>	HH:MM (jan feb mar apr may jun jul aug sep oct nov dec) <1-31>	<2000-2037> HH:MM [<1-1440>]
	clock summer-time ACRONYM recurring (usa eu) [<1-1440>] clock summer-time ACRONYM recurring (<1-5> first last)			

Parameter	ACRONYM	Specify acronym name of time zone
	(jan feb mar apr may jun jul aug sep oct nov dec) <1-31> <2000-2037> HH:MM	Specify non-recurring daylight saving time duration.
	(jan feb mar apr may jun jul aug sep oct nov dec) <1-31> <2000-2037> HH:MM	Specify adjust offset of daylight saving time
	usa	Using daylight saving time in the United States that starts on the second Sunday of March and ends on the first Sunday of November
	eu	Using daylight saving time in the Europe that starts on the last Sunday in March and ending on the last Sunday in October

(<1-5>|first|last) (sun|mon|Specify ecurring daylight saving time duration.
 tue|wed|thu|fri|sat) (jan
 |feb|mar|apr|may|jun|
 jul|aug|sep|oct|nov|dec)
 HH:MM (<1-5>|first|last)
 (sun|mon|tue|wed|thu|fri|sat)
 (jan|feb|mar|apr|may|
 jun|jul|aug|sep|oct|nov|dec)
HH:MM

Default No default daylight saving time is defined.

Mode Global Configuration

Usage Use the **clock summer-time** command to set daylight saving time for system time. The “usa” or “eu” means that use the global daylight saving policy which defined by international organization. In both the “date”and “recurring”, the first part of the command specifies when summer time begins, and the second part specifies when it ends. All times are relative to the local time zone. The “recurring” means that adjust time every year within the month.
 Use the no form of this command to default setting.
 You can verify your setting by entering the **show clock detail Privileged EXEC** command.

Example The example shows how to set clock summer time of switch. You can verify settings by the following show show clock command.

```
switch(config)# clock summer-time test recurring usa
switch(config)# show clock detail
08:32:12 test(UTC+5) Sep 21 2012
No time source
```

Time zone: Acronym is DFL Offset is UTC+8

Summertime: Acronym is test Recurring every year. Begins at 2 0 3 2:0
 Ends at 1 0 11 2:0
Offset is 60 minutes.

show clock

Syntax `show clock [detail]`

Parameter `detail` Show more detail information of clock

Default No default is defined

Mode Privileged EXEC

Usage Use the **show clock** command to show clock of switch. The “**detail**” means that show more information of clock such as time zone and daylight saving time.

Example The example shows how to show clock of switch and detail information.

```
Switch334455(config)# clock source sntp Switch334455(config)# clock summer-time DLS
recurring usa Switch334455(config)# sntp host 192.168.1.100 Switch334455(config)#
show clock
14:34:43 DLS(UTC+9) Sep 25 2012
Time source is sntp
```

```
Switch334455(config)# show clock detail
14:35:39 DLS(UTC+9) Sep 25 2012
```

Time source is sntp

Time zone: Acronym is DFL Offset is UTC+8

Summertime: Acronym is DLS Recurring every year. Begins at 2 0 3 2:0
Ends at 1 0 11 2:0 Offset is 60 minutes.

sntp

Syntax `sntp host HOSTNAME [port <1-65535>]`
`no sntp`

Parameter `HOSTNAME` Specify ip address or hostname of sntp server
`sntp` Specify server port of sntp server

Default No default SNTP server defined. Default server port is 123 when server created.

Mode Global Configuration

Usage Use the `sntp` command to set remote SNTP server. Use the `no` form of this command to default setting. You can verify your setting by entering the **show sntp Privileged EXEC** command.

Example The example shows how to set remote SNTP server of switch. `switch(config)# clock source sntp`
`switch(config)# sntp host 192.168.1.100`
`switch(config)# show sntp`
 SNTP is Enabled
 SNTP Server address: 192.168.1.100 SNTP Server port: 123

show sntp

Syntax `show sntp`

Parameter None

Default No default is defined

Mode Privileged EXEC

Usage Use the `show sntp` command to remote SNTP server information.

Example The example shows how to show remote SNTP server.

Switch334455(config)# `show sntp`
 SNTP is Enabled
 SNTP Server address: 192.168.1.100 SNTP Server port: 123

UDLD

errdisable recovery cause udd

Syntax `errdisable recovery cause udd`
`no errdisable recovery cause udd`

Parameter N/A

Default Error disable auto recovery is disabled by default.

Mode Global EXEC

Usage Use the **errdisable recovery cause udd** to enable auto recovery of UniDirectional Link Detection (UDLD). Use the “no” to disable it.

Example The example shows how to enable auto recovery of UniDirectional Link Detection (UDLD).

```
switch(config)# errdisable recovery cause udd
switch# show errdisable recovery
ErrDisable Reason Timer Status
-----+-----
bpduguard | disabled
```

udld | enabled
...

udld

Syntax **udld**
no udd

Parameter N/A

Default UDLD is disabled by default.

Mode Interface Configuration

Usage Use the **udld** command to enable UniDirectional Link Detection (UDLD) normal mode of interface. Use the no form of this command to restore to default setting. You can verify your setting by entering the **show udd interface Privileged EXEC** command.

Example The example shows how to enable UniDirectional Link Detection (UDLD) normal mode in interface gi1.

```
switch(config)# interface gi1
switch(config-if)# udld
switch# show udld interfaces gi1
Port enable administrative configuration setting: Enabled Port enable operational
state: Enabled
Current bidirectional state: Bidirectional
Current operational state: Advertisement - SINGLE NEIGHBOR DETECTED
```

udld aggressive

Syntax `udld aggressive no udld aggressive`

Parameter	<u>N/A</u>
-----------	------------

Default UDLD aggressive mode is disabled by default.

Mode Interface Configuration

Usage Use the **udld aggressive** command to enable UniDirectional Link Detection (UDLD) aggressive mode of interface.

Use the no form of this command to restore to default setting.

You can verify your setting by entering the **show udld interface Privileged EXEC** command.

Example The example shows how to enable udld aggressive mode in interface gi1.

```
switch(config)# interface gi1
switch(config-if)# udld
switch# show udld interfaces gi1
Port enable administrative configuration setting: Enabled / in aggressive mode
Port enable operational state: Enabled / in aggressive mode
Current bidirectional state: Bidirectional
Current operational state: Advertisement - SINGLE NEIGHBOR DETECTED
```

udld message time

Syntax `udld message time message-time-interval`

Parameter `message-time-interval` Specify the interval for sending message.

Default Default interval is 15 seconds.

Mode Global Configuration

Usage Use the **udld message time** to set interval of UniDirectional Link Detection (UDLD) sent message.

Example The example shows how to set interval of UniDirectional Link Detection (UDLD) message.

```
switch(config)# udld message time 30
```

udld reset

Syntax `udld reset`

Parameter N/A

Default No default is defined

Mode Privileged EXEC

Usage Use the **udld reset** command to reset all interfaces disabled by the UniDirectional Link Detection (UDLD) and permit traffic to begin passing through them again.

If the interface configuration is still enabled for UDLD, these ports begin to run UDLD again and are disabled for the same reason if the problem has not been corrected.

Example The example shows how to reset all interfaces disabled by UDLD

```
Switch# udld reset
1 ports shutdown by UDLD were reset.
```

show uddl

Syntax show uddl

show uddl interfaces *IF_NMLPORTS*

Parameter	<i>IF_NMLPORTS</i>	Specify the normal interfaces to display uddl <u>information</u>
Default	No default is defined	
Mode	Privileged EXEC	

Usage Use the **show uddl** command to to display UniDirectional Link Detection (UDLD) administrative and operational status for all ports or the specified port.

Example The example shows how to show UniDirectional Link Detection (UDLD) settings and operational status of interface gi1.

```
Switch334455(config)# show uddl interfaces gi1
```

```
Interface gi1
```

```
---
```

```
Port enable administrative configuration setting: Enabled / in aggressive mode Port enable operational state: Enabled / in aggressive mode
```

```
Current bidirectional state: Bidirectional
```

```
Current operational state: Advertisement - SINGLE NEIGHBOR DETECTED
```

```
Message interval: 15 Time out interval: 5
```

```
Entry 1
```

```
---
```

```
Expiration time: 20
```

```
Current neighbor state: Bidirectional Device ID : COM4
```

```
Device name: com4 Port ID: gi3 Message interval: 7 Time out interval: 5
```

```
Neighbor echo 1 device: COM3 Neighbor echo 1 port: gi1
```

VLAN

vlan

Syntax vlan

no vlan

Default	VLAN 1 created by default
----------------	---------------------------

Mode Global Configuration

Usage Use the **vlan** global configuration command to create VLAN. Use the **no** form of this command to remove exist VLAN.

You can verify your setting by entering the **show vlan Privileged EXEC** command.

Example The following example creates and removes a VLAN entry (100).

```
Switch# configure
Switch (config)# vlan 100
Switch# show vlan
```

Name (vlan)

VID	VLAN Name	Untagged Ports	Tagged Ports	Type
1	default	fa1-48,gi1-4,lag1-8	---	Default 100 VLAN0100 --- --- Static

Syntax **name NAME**

Parameter **NAME** Specify the name of the VLAN (Max. 32 chars).

Default Default name of new vlan is VLANxxxx. Xxxx is 4-digit vlan number.

Mode VLAN Configuration

Usage Use the **name** vlan configuration command to set name of vlan
You can verify your setting by entering the **show vlan Privileged EXEC** command.

Example This example sets the VLAN name of VLAN 100 to be `VLAN- one-hundred`.

```
SwitchEF0101(config)# vlan 100
SwitchEF0101(config-vlan)# name VLAN-one-hundred Switch# show vlan
VID | VLAN Name | Untagged Ports | Tagged Ports | Type
-----+-----+-----+-----+-----
1 | default | fa1-48,gi1-4,lag1-8 | --- | Default 100 | VLAN-one-hundred | --- | --- | Static
```


switchport mode

Syntax `switchport mode (access | hybrid | trunk [uplink] | tunnel)`

Parameter	access	Specify the VLAN mode to Access port.
	hybrid	Specify the VLAN mode to Hybrid port.
	trunk	Specify the VLAN mode to Trunk port.
	uplink	Specify the Uplink property on this Trunk port.
	tunnel	Specify the VLAN mode to Dot1Q Tunnel port.

Default Default is trunk mode of all interfaces

Mode Port Configuration

Usage The VLAN mode is used to configure the port for different port role.

Access port: Accepts only untagged frames and join an untagged VLAN. **Hybrid port:** Support all functions as defined in IEEE 802.1Q specification. **Trunk port:** An untagged member of one VLAN at most, and is a tagged member of zero or more VLANs. If it is an uplink port, it can recognize double tagging on this port.

Tunnel port: Port-based Q-in-Q mode.

Use the **switch mode** port configuration command to set mode of interface You can verify your setting by entering the **show interfaces switchport Privileged EXEC** command.

Example This example sets VLAN mode to Access port.

```
SwitchEF0101(config)# interface fa12 SwitchEF0101(config-if)#
switchport mode access SwitchEF0101# show interfaces switchport fa12
Port : fa12
Port Mode : Access Ingress Filtering : enabled
Acceptable Frame Type : untagged-only Ingress UnTagged VLAN
( NATIVE ) : 1 Trunking VLANs Enabled:
```

```
Port is member in:
Vlan Name Egress rule
```

```
-----
1 default Untagged
```

```
Forbidden VLANs: Vlan Name
-----
```

```
SwitchEF0101#
```

switchport hybrid pvid

Syntax `switchport hybrid pvid <1-4094>`

Parameter `<1-4094>` Specify the port-based VLAN ID on the Hybrid port.

Default Default pvid is 1.

Mode Port Configuration

Usage Use the **switch hybrid pvid** port configuration command to set pvid of interface.
You can verify your setting by entering the **show interfaces switchport Privileged EXEC** command.

Example This example sets PVID to 100.

```
SwitchEF0101(config)# interface fa10 SwitchEF0101(config-if)# switchport
mode hybrid SwitchEF0101(config-if)# switchport hybrid pvid 100
SwitchEF0101# show interfaces switchport fa10
Port : fa10
Port Mode : Hybrid Ingress Filtering : enabled
Acceptable Frame Type : all
Ingress UnTagged VLAN ( NATIVE ) : 100 Trunking VLANs Enabled:

Port is member in:
Vlan Name Egress rule
-----
1 default Untagged

Forbidden VLANs:
Vlan Name

SwitchEF0101#
```

switchport hybrid ingress-filtering

Syntax `switchport hybrid ingress-filtering no switchport hybrid ingress-filtering`

Default Default is enabled

Mode Port Configuration

Usage Use the **switchport hybrid ingress-filtering** port configuration command to enable vlan ingress filter.
Use the **no** form of this command to disable.

You can verify your setting by entering the **s show interfaces switchport Privileged EXEC** command.

Example This example sets ingress-filtering to disable.

```
SwitchEF0101(config)# interface fa10 SwitchEF0101(config-if)# switchport
mode hybrid
SwitchEF0101(config-if)#no switchport hybrid ingress-filtering SwitchEF0101#
show interfaces switchport fa10
Port : fa10
Port Mode : Hybrid Ingress Filtering : disabled
Acceptable Frame Type : all
Ingress UnTagged VLAN ( NATIVE ) : 100 Trunking VLANs Enabled:

Port is member in:
Vlan Name Egress rule
-----
1 default Untagged

Forbidden VLANs:
Vlan Name

SwitchEF0101#
```

switchport hybrid acceptable-frame-type

Syntax **switchport hybrid acceptable-frame-type (all | tagged-only | untagged- only)**

Parameter	all	Specify to accept all frames.
	tagged-only	Specify to only accept tagged frames.
	untagged-only	Specify to only accept untagged frames.

Default Default is accept all frames

Mode Port Configuration

Usage Use the **switchport hybrid accept-frame-type** port configuration command to choose which type of frame can be accepted.

You can verify your setting by entering the **s show interfaces switchport Privileged EXEC** command

Example This example sets acceptable-frame-type to tagged-only. SwitchEF0101(config)# interface fa10 SwitchEF0101(config-if)# switchport mode hybrid SwitchEF0101(config-if)# switchport hybrid acceptable-frame-type tagged- only SwitchEF0101# show interfaces switchport fa10 Port : fa10 Port Mode : Nybrid Ingress Filtering : disabled Acceptable Frame Type : tagged-only Ingress UnTagged VLAN (NATIVE) : 100 Trunking VLANs Enabled:

Port is member in:
Vlan Name Egress rule

1 default Untagged

Forbidden VLANs:
Vlan Name

SwitchEF0101#

switchport hybrid allowed vlan

Syntax **switchport hybrid allowed vlan add VLAN-LIST [(tagged|untagged)]**
switchport hybrid allowed vlan remove VLAN-LIST

Parameter **VLAN-LIST** Specifies the VLAN list to be added or remove.
(tagged | untagged) Specifies the member type is tagged or untagged.

Default Only vlan 1 is untagged member by default. Default is tagged member when added.

Mode Port Configuration

Usage Use the **switchport hybrid allow vlan add** port configuration command to allow vlan on interface.
 Use the **switchport hybrid allow vlan remove** port configuration command to remove vlan on interface.
 You can verify your setting by entering the **show interfaces switchport Privileged EXEC** command.

Example This example sets port fa10 VLAN to join the VLAN 100 as tagged member.

```

SwitchEF0101(config)# interface fa10
SwitchEF0101(config-if)# switchport hybrid allowed vlan add 100-105
SwitchEF0101(config-if)# switchport hybrid allowed vlan remove 105
SwitchEF0101# show interfaces switchport fa10
Port : fa10
Port Mode : Hybrid Ingress Filtering : disabled
Acceptable Frame Type : tagged-only Ingress UnTagged VLAN ( NATIVE ) :
100 Trunking VLANs Enabled:

Port is member in:
Vlan Name Egress rule
-----
1 default Untagged
VLAN-one-hundred Tagged
VLAN0101 Tagged
VLAN0102 Tagged
VLAN0103 Tagged
VLAN0104 Tagged

Forbidden VLANs:
Vlan Name
-----

SwitchEF0101#
  
```

switchport access vlan

Syntax **switchport access vlan <1-4094>** **No switchport access vlan**

Parameter	<1-4094>	Specifies the access VLAN ID.
------------------	----------	-------------------------------

Default	Default is vlan 1
----------------	-------------------

Mode	Port Configuration
-------------	--------------------

Usage Use the **switchport access vlan** port configuration command to set native vlan on interface. The vlan will be pvid on interface as well.
 Use the **no** form of this command to restore to default vlan
 You can verify your setting by entering the **s show interfaces switchport Privileged EXEC** command.

Example This example sets Access port fa10 native VLAN ID to 100.

```
SwitchEF0101(config)# interface fa10 SwitchEF0101(config-if)# switchport
mode access SwitchEF0101(config-if)# switchport access vlan 100
SwitchEF0101# show interfaces switchport fa10
Port : fa10
Port Mode : Access Ingress Filtering : enabled
Acceptable Frame Type : untagged-only Ingress UnTagged VLAN ( NATIVE ) :
100 Trunking VLANs Enabled:

Port is member in:
Vlan Name Egress rule
-----
100 VLAN-one-hundred Untagged

Forbidden VLANs:
Vlan Name
-----
```

switchport tunnel vlan

Syntax **switchport tunnel vlan <1-4094> no switchport tunnel vlan**

Parameter <1-4094> Specifies the tunnel VLAN ID.

Default Default is vlan 1

Mode Port Configuration

Usage Use the **switchport tunnel vlan** port configuration command to set dot1q tunnel vlan on interface. The vlan will be pvid on interface as well.

Use the **no** form of this command to remove vlan on interface. The tunnel vlan id will set to reserve vlan 4095.

You can verify your setting by entering the **s show interfaces switchport Privileged EXEC** command.

Example This example sets Tunnel port fa10 native VLAN to 100.

```
SwitchEF0101(config)# interface fa10
SwitchEF0101(config-if)# switchport mode tunnel
SwitchEF0101(config-if)# switchport tunnel vlan 100
```

```
SwitchEF0101# show interfaces switchport fa10 Port : fa10
Port Mode : Tunnel Ingress Filtering : enabled
Acceptable Frame Type : all
Ingress UnTagged VLAN ( NATIVE ) : 100 Trunking VLANs Enabled:
```

```
Port is member in:
Vlan Name Egress rule
```

```
-----
100 VLAN-one-hundred Untagged
```

```
Forbidden VLANs:
Vlan Name
```

switchport trunk native vlan

Syntax `switchport trunk native vlan <1-4094>` `no switchport trunk native vlan`

Parameter `<1-4094>` Specifies the native VLAN ID.

Default Default is vlan 1

Mode Port Configuration

Usage Use the **switchport trunk native vlan** port configuration command to set native vlan on interface.
Use the **no** form of this command to restore to default vlan.
You can verify your setting by entering the **s show interfaces switchport Privileged EXEC** command.

Example

This example sets Trunk port fa10 native VLAN to 100.

```
SwitchEF0101(config)# interface fa10 SwitchEF0101(config-if)# switchport
mode trunk SwitchEF0101(config-if)# switchport trunk native vlan 100
SwitchEF0101# show interfaces switchport fa10
Port : fa10
Port Mode : Trunk Ingress Filtering : enabled
Acceptable Frame Type : all
```

Ingress UnTagged VLAN (NATIVE) : 100 Trunking VLANs Enabled:

Port is member in:
Vlan Name Egress rule

100 VLAN-one-hundred Untagged

Forbidden VLANs:
Vlan Name

switchport trunk allowed vlan

Syntax **switchport trunk allowed vlan (add | remove) (VLAN-LIST | all)**

Parameter (add | remove) Specify the action to add or remove the allowed VLAN list.

(VLAN-LIST | all) Specify the VLAN list or all VLANs to be added or removed.

Mode Port Configuration

Usage Use the **switchport trunk allow vlan add** port configuration command to allow vlan on interface.
Use the **switchport trunk allow vlan remove** port configuration command to remove vlan on interface.
You can verify your setting by entering the **s show interfaces switchport Privileged EXEC** command.

Example

This example sets Trunk port fa10 to add the allowed VLAN 100.

```
SwitchEF0101(config)# interface fa10
SwitchEF0101(config-if)# switchport trunk allowed vlan add 100
SwitchEF0101# show interfaces switchport fa10
Port : fa10
Port Mode : Trunk Ingress Filtering : enabled
Acceptable Frame Type : all
Ingress UnTagged VLAN ( NATIVE ) : 1 Trunking VLANs Enabled: 100
```

```
Port is member in:
Vlan Name Egress rule
```

```
-----
1 default Untagged
```

100 VLAN-one-hundred Tagged

Forbidden VLANs:

Vlan Name

switchport default-vlan tagged

Syntax switchport default-vlan tagged

no switchport default-vlan tagged

Parameter

None

Default

Default is untagged

Mode

Port Configuration

Usage Use the **switchport default vlan tagged** port configuration command to become default vlan tagged member. Use the **no switchport default vlan tagged** port configuration command to restore to default. You can verify your setting by entering the **show interfaces switchport Privileged EXEC** command

Example

This example sets Trunk port fa10 membership with the default VLAN to tag.

```
SwitchEF0101(config)# interface fa10 SwitchEF0101(config-if)# switchport default-
vlan tagged SwitchEF0101# show interfaces switchport fa10
```

Port : fa10

Port Mode : Hybrid Ingress Filtering : enabled

Acceptable Frame Type : all

Ingress UnTagged VLAN (NATIVE) : 1 Trunking VLANs Enabled:

Port is member in:

Vlan Name Egress rule

1 default Tagged

Forbidden VLANs:

Vlan Name

switchport forbidden default-vlan

Syntax `switchport forbidden default-vlan no switchport forbidden default-vlan`

Parameter

None

Default

Default is allowed

Mode

Port Configuration

Usage

Use the **switchport forbidden default-vlan** port configuration command to forbid default-vlan on interface.

Use the **no switchport forbidden default-vlan** port configuration command to restore to default

You can verify your setting by entering the **s show interfaces switchport Privileged EXEC** command

Example

This example sets the membership of the default VLAN with port fa10 to forbidden.

```
SwitchEF0101(config)# interface fa10 SwitchEF0101(config-if)# switchport
forbidden default-vlan SwitchEF0101# show interfaces switchport fa10
Port : fa10
Port Mode : Trunk Ingress Filtering : enabled
Acceptable Frame Type : all
Ingress UnTagged VLAN ( NATIVE ) : 4095 Trunking VLANs Enabled:
```

```
Port is member in:
Vlan Name Egress rule
-----
```

```
Forbidden VLANs:
Vlan Name
-----
1 default
```

switchport forbidden vlan

Syntax `switchport forbidden vlan (add | remove) VLAN-LIST`

Parameter	(add remove)	Add or remove forbidden membership.
	VLAN-LIST	Specify the VLAN list.

Default No vlan is forbidden by default

Mode Port Configuration

Usage Use the **switchport forbidden vlan add** port configuration command to forbid vlan on interface.
 Use the **switchport forbidden vlan remove** port configuration command to accpet vlan on interface.
 You can verify your setting by entering the **s show interfaces switchport Privileged EXEC** command

Example This example sets the membership of the VLAN 100 with port fa10 to forbidden.

```
SwitchEF0101(config)# interface fa10
SwitchEF0101(config-if)# switchport forbidden vlan add 100
SwitchEF0101# show interfaces switchport fa10
Port : fa10
Port Mode : Trunk Ingress Filtering : enabled
Acceptable Frame Type : all
Ingress UnTagged VLAN ( NATIVE ) : 1 Trunking VLANs Enabled: 100
```

Port is member in:
Vlan Name Egress rule

1 default Untagged

Forbidden VLANs:
Vlan Name

100 VLAN-one-hundred

switchport vlan tpid

Syntax `switchport vlan tpid (0x8100|0x88a8|0x9100|0x9200)`

Parameter (0x8100|0x88a8|0x9100|0x9200) Select TPID to set.

Default Default TPID is 0x8100

Mode Port Configuration

Usage Use the **switchport vlan tpid** port configuration command to set TPID on interface.

You can verify your setting by entering the **show running-config Privileged EXEC** command

Example This example sets the TPID to 0x9100 on interface fa10.

```
SwitchEF0101(config)# interface fa10
SwitchEF0101(config-if)# switchport
vlan tpid 0x9100
```

management-vlan

Syntax `management-vlan vlan <1-4094> no management-vlan`

Parameter `<1-4094>` Specify the VLAN ID of management-vlan.

Default Default management vlan is 1.

Mode Global Configuration

Usage Use the **management vlan** Global Configuration mode command to set management vlan id. Vlan id must be created first.

Use the **no** form of this command to restore to default setting.

You can verify your setting by entering the **show management-vlan Privileged EXEC** command

Example The following example specifies that management vlan 2 is created

```
Switch(config)#vlan 2
Switch(config)# management-vlan vlan 2
```

The following example specifies that management-vlan is restored to be default VLAN.

```
Switch(config)# no management-vlan
```

show vlan

Syntax `show vlan [(VLAN-LIST|dynamic|static)]`

Parameter `(VLAN-LIST|dynamic|static)` Specify vlan id to show information or show all static or dynamic vlan entries.

Default Nones

Mode Privileged EXEC

Usage Display information about vlan entry

Example The following example specifies that show vlan

```
Switch# show vlan
VID | VLAN Name | Untagged Port | Tagged Port | Type
-----+-----+-----+-----+-----
1 | default | fa1-8,fa10-48,lag1-8 | --- | Default 100 | VLAN-one-hundred | --- | --- | Static 101 |
VLAN0101 | --- | --- | Static
102 | VLAN0102 | --- | --- | Static
```

show vlan interface membership

Syntax show vlan VLAN-LIST interfaces IF_PORTS membership

Parameter		
<VLAN-List>		Specify vlan to show
IF_PORTS		Specify interface is to show

Default Nones

Mode Privileged EXEC

Usage Display information about vlan membership on interfaces.

Example The following example specifies that show vlan interface membership Switch#
show vlan 100 interfaces fa10 membership

```
VLAN ID : 100
VLAN Type : Static
```

```
-----+-----
Port | Membership
-----+-----
fa10 | Excluded
-----+-----
```

show interface switchport

Syntax show interface switchport interfaces IF_PORTS

Parameter	IF_PORTS	
		Specify interfaces protocol vlan to display

Default None

Mode Privileged EXEC

Usage Display information about default vlan

Example

The following example specifies that show interface switchport.

```
SwitchEF0101(config)# interface fa10
SwitchEF0101(config-if)# switchport trunk allowed vlan add 100
SwitchEF0101# show interfaces switchport fa10
Port : fa10
Port Mode : Trunk Ingress Filtering : enabled
Acceptable Frame Type : all
Ingress UnTagged VLAN ( NATIVE ) : 1 Trunking VLANs Enabled: 100
```

```
Port is member in:
Vlan Name Egress rule
-----
1 default Untagged
100 VLAN-one-hundred Tagged
```

```
Forbidden VLANs:
Vlan Name
```

show management-vlan

Syntax show management-vlan

Parameter None

Default Nones

Mode Privileged EXEC

Usage Display information about management vlan

Example

The following example specifies that show management vlan Switch(config)#
show management-vlan
Management VLAN-ID : default(1)

Voice VLAN

voice-vlan (Global)

Syntax	voice-vlan no voice-vlan
---------------	---

Parameter	
------------------	--

Default Voice VLAN is disabled

Mode	Global Configuration
-------------	----------------------

Usage Use the **voice vlan** global configuration command to enable the functional Voice VLAN on the device. Use the **no** form of this command to disable voice vlan function. You can verify your setting by entering the **show voice vlan Privileged EXEC** command.

Example	The following example shows how to enable voice vlan. Switch(config)# voice-vlan Switch# show voice-vlan Administrate Voice VLAN state : disabled Voice VLAN ID : none (disable) Voice VLAN Aging : 1440 minutes Voice VLAN CoS 6 <u>Voice VLAN 1p Remark: disabled</u>
----------------	--

voice-vlan (Interface)

Syntax	voice-vlan no voice-vlan
---------------	---

Parameter	<u>N/A</u>
------------------	------------

Default	The default all port admin-staus is disabled.
----------------	---

Mode	Interface Configuration
-------------	-------------------------

Usage	Use the voice vlan Interface configuration command to enable OUI voice VLAN configuration on an interface Use the no form of this command to disable voice vlan on an interfaces You can verify your setting by entering the show voice vlan Privileged EXEC command
--------------	--

Example

The following example shows how to enable voice VLAN function in oui mode on an interface

```
Switch(config)#interface range fa1-3
```

```
Switch(config-if)#voice-vlan
```

```
Switch# show voice-vlan interfaces fa1-8 Voice VLAN Aging : 1440 minutes
```

```
Voice VLAN CoS 7
```

```
Voice VLAN 1p Remark: enabled
```

OUI table

OUI MAC | Description

```
-----+----- 00:E0:BB | 3COM
```

```
00:03:6B | Cisco 00:E0:75 | Veritel 00:D0:1E | Pingtel 00:01:E3 | Siemens
```

```
00:60:B9 | NEC/Philips 00:0F:E2 | H3C
```

```
00:09:6E | Avaya
```

Port | State | Port Mode | Cos Mode

```
-----+-----+-----+-----
```

```
fa1 | Disabled | Auto | Src fa2 | Disabled | Auto | Src fa3 | Disabled | Auto | Src
```

```
fa4 | Disabled | Auto | Src
```

```
fa5 | Disabled | Auto | Src
```

```
fa6 | Disabled | Auto | Src
```

```
fa7 | Disabled | Auto | Src
```

```
fa8 | Disabled | Auto | Src
```

voice-vlan vlan

Syntax `voice-vlan vlan <1-4094>`

`no voice-vlan vlan`

Parameter

<1-4094>

Specify the voice VLAN ID

Default

The default Voice VLAN ID is None.

Mode

Global Configuration

Usage Use the `voice vlan id` global configuration command to configure the VLAN identifier of the voice VLAN

statically.

Use the **no** form of this command to restore voice vlan id to default. You can verify your setting by entering the **show voice vlan Privileged EXEC** command

Example The following example shows how to set Voice vlan id. The vlan id must be created first.

```
Switch(config)# voice-vlan vlan 128
Switch# show voice-vlan
Administrate Voice VLAN state : enabled Voice VLAN ID 128
Voice VLAN Aging : 1440 minutes Voice VLAN CoS 6
Voice VLAN 1p Remark: disabled
```

voice-vlan oui-table

Syntax	voice-vlan oui-table A:B:C [DESCRIPTION] no voice-vlan oui-table [A:B:C]
Parameter	A:B:C Specify OUI Mac address to add or remove DESCRIPTION Specify description of the specified MAC address to the <u>voice VLAN OUI table</u>
Default	The system default has 8 oui addresses.
Mode	Global Configuration
Usage	Use the voice vlan oui-table global configuration command to add oui mac address to OUI Table Use the no form of this command to remove all or specified oui mac address.. You can verify your setting by entering the show voice vlan Privileged EXEC command

Example This following example shows how to add OUI Mac. Switch(config)# **voice-vlan oui-table 00:01:02 "Test"** Switch# **show voice-vlan interfaces all**

```
Voice VLAN Aging : 1440 minutes Voice VLAN CoS 6
Voice VLAN 1p Remark: disabled
```

```
OUI table
OUI MAC | Description
-----+----- 00:E0:BB | 3COM
00:03:6B | Cisco 00:E0:75 | Veritel 00:D0:1E | Pingtel 00:01:E3 | Siemens
00:60:B9 | NEC/Philips 00:0F:E2 | H3C
00:09:6E | Avaya
00:01:02 | Test
```

Port | State | Port Mode | Cos Mode

```
-----+-----+-----+-----
fa1 | Disabled | Auto | Src fa2 | Disabled | Auto | Src fa3 | Disabled | Auto | Src
.....
```

voice-vlan cos (Global)

Syntax **voice-vlan cos** <0-7> [remark]
no voice-vlan cos

Parameter <0-7> Specify the voice VLAN Class of Service value in telephone oui mode

remark Specify that the L2 user priority is remarked with the CoS value

Default The default cos value is 6, remark is disabled.

Mode Global Configuration

Usage Use the **voice vlan cos** global configuration command to configure the voice VLAN cos value and 1p remark function
 Use the “**no**” form to restore to default mode.
 You can verify your setting by entering the **show voice vlan Privileged EXEC** command

Example The following example show how to set cos value and enable 1p remark function

```
Switch(config)# voice-vlan cos 7 remark
Switch# show voice-vlan
Administrate Voice VLAN state : disabled Voice VLAN ID 128
Voice VLAN Aging : 1440 minutes Voice VLAN CoS 7
Voice VLAN 1p Remark: enabled
```

voice-vlan cos (Interface)

Syntax **voice-vlan cos (src | all)**
no voice-vlan cos

Parameter src Specify QoS attributes are applied to packets with OUIs in the source MAC address.

All Specify QoS attributes are applied to packets that are classified to the Voice VLAN.

Default The default all port in Src mode.

Mode Interface configuration

Usage Use the **voice vlan cos** Interface configuration command to configure OUI voice VLAN cos mode configuration on an interface

Use the “no” form to restore to default mode.

You can verify your setting by entering the **show voice-vlan interfaces Privileged EXEC** command

Example The following example how to configure voice packet QoS attributes on an interface
 Switch(config)#**interface range fa1-3**
 Switch(config-if)#**voice-vlan cos all**

Switch# **show voice-vlan interfaces fa1-8**

Voice VLAN Aging : 1440 minutes Voice VLAN CoS 7

Voice VLAN 1p Remark: enabled

OUI table

OUI MAC | Description

-----+----- 00:E0:BB | 3COM

00:03:6B | Cisco 00:E0:75 | Veritel 00:D0:1E | Pingtel 00:01:E3 | Siemens 00:60:B9 | NEC/Philips 00:0F:E2 | H3C

00:09:6E | Avaya

Port | State | Port Mode | Cos Mode

-----+-----+-----+-----

fa1 | Disabled | Auto | All fa2 | Disabled | Auto | All fa3 | Disabled | Auto | All fa4 | Disabled | Auto | Src fa5 | Disabled
 | Auto | Src fa6 | Disabled | Auto | Src fa7 | Disabled | Auto | Src

fa8 | Disabled | Auto | Src

voice-vlan mode

Syntax **voice-vlan mode (auto|manual)**
no voice-vlan mode

Parameter **auto** Specifies that the port is identified as a candidate to join the voice VLAN. When a packet with a source OUI MAC address that identifies the remote equipment as voice equipment is seen on the port, the port joins the voice VLAN as a tagged port.

manual Specifies that the port is manually assigned to the voice VLAN.

Default The default is auto mode.

Mode Interface Configuration

Usage Use the **voice-vlan mode** global configuration command to configure the voice VLAN mode for interface.
 Use the “**no**” form to restore to default mode.
 You can verify your setting by entering the **show voice-vlan interfaces Privileged EXEC** command.

Example The following example shows how to configure voice mode to manual

```
Switch(config)#interface range fa1-3
Switch(config-if)#voice-vlan mode manual Switch# show voice-vlan interfaces
fa1-8 Voice VLAN Aging : 1440 minutes
Voice VLAN CoS 7
Voice VLAN 1p Remark: enabled
```

OUI table
 OUI MAC | Description
 -----+----- 00:E0:BB | 3COM
 00:03:6B | Cisco 00:E0:75 | Veritel 00:D0:1E | Pingtel 00:01:E3 | Siemens 00:60:B9
 | NEC/Philips 00:0F:E2 | H3C
 00:09:6E | Avaya

Port | State | Port Mode | Cos Mode
 -----+-----+-----+-----
 fa1 | Disabled | Manual | Src fa2 | Disabled | Manual | Src fa3 | Disabled | Manual | Src
 fa4 | Disabled | Auto | Src fa5 | Disabled | Auto | Src fa6 | Disabled | Auto | Src fa7 |
 Disabled | Auto | Src
 fa8 | Disabled | Auto | Src

voice-vlan aging-time

Syntax voice-vlan aing-time <30-65536>
no voice-vlan aing-time

Parameter	<30-65536>	Specify the voice VLAN aging timeout interval in <u>minutes</u>
------------------	------------	---

Default The default aging-timeout value is 1440 minutes

Mode Global Configuration

Usage Use the **voice vlan aging-time** global configuration command to configure the voice VLAN aging timeout.
 Use the “**no**” form to restore to default time.
 You can verify your setting by entering the **show voice vlan Privileged EXEC** command

Example The following example shows how to set aging time. Switch(config)# **voice-vlan aging-time 720**
 Switch# **show voice-vlan**
 Administrate Voice VLAN state : disabled Voice VLAN ID 1
 Voice VLAN Aging : 720 minutes Voice VLAN CoS 5
Voice VLAN 1p Remark: enabled

show voice-vlan

Syntax show voice-vlan

show voice-vlan interfaces [IF_PORTS]

Parameter	IF_PORTS	Specifies interfaces to display voice VLAN settings in <u>oui mode</u>
------------------	----------	--

Default	N/A
----------------	-----

Mode	Privileged EXEC
-------------	-----------------

Usage Use the **show voice vlan** command in EXEC mode to display the voice VLAN status for all interfaces or for a specific interface if the voice VLAN type is OUI

Example The following example show how to display voice vlan oui mode settings Switch#
 show voice-vlan

```
Administrate Voice VLAN state : disabled
Voice VLAN ID : none (disable) Voice VLAN Aging : 720 minutes Voice VLAN CoS 6
Voice VLAN 1p Remark: disabled
Switch# show voice-vlan interfaces fa1-4 Voice VLAN Aging : 720 minutes Voice VLAN CoS 5
Voice VLAN 1p Remark: enabled
```

OUI table

OUI MAC | Description

-----+----- 00:E0:BB | 3COM

00:03:6B | Cisco 00:E0:75 | Veritel 00:D0:1E | Pingtel 00:01:E3 | Siemens 00:60:B9 | NEC/Philips 00:0F:E2 | H3C 00:09:6E | Avaya

Port | State | Port Mode | Cos Mode

-----+-----+-----+-----

fa1 | Disabled | Auto | Src fa2 | Disabled | Auto | Src fa3 | Disabled | Auto | Src
fa4 | Disabled | Auto | Src

Static Routing

IPv4 Interface

Syntax	interface vlan ip address ipaddr mask no interface vlan no ip address	
Parameter	<i>ipaddr</i>	Specify IPv4 address for switch
	<i>mask</i>	Specify net mask address for switch

Default The vlan interface and ip address are not configured by default.

Mode Global configuration and vlan interface configuration.

Usage Use the **interface vlan** global configuration command to config ip interface on the device.
Use the **ip address** command in vlan interface mode to configure the device's ip address.
Use the **no ip address** command to delete the configured ip address.
Use the **no interface vlan** command to delete ip interface on the device.
You can verify your setting by entering the **show ip interface vlan** Privileged EXEC command.

Example The following example shows how to config ip interface.
Switch(config)# **interface vlan 2**
Switch(config-if)# **ip address 192.168.3.1 255.255.255.0**
Switch# **show ip interface vlan 2**

```
IP Address I/F I/F Status admin/oper Type Status
-----
```

192.168.3.1/24 VLAN 2 UP/DOWN Static Valid

IPv4 Routes

Syntax `ip route dest-ipaddr mask router-ipaddr`

no ip route `dest-ipaddr mask router-ipaddr`

Parameter	<i>dest-ipaddr</i>	Destination ip address prefix
	<i>mask</i>	Destination ip address prefix mask
	<i>router-ipaddr</i>	Forwarding router's ip address

Default Static route is not configured by default.

Mode Global Configuration mode.

Usage Use the **ip route** command in global mode to configure a static route rule.
Use the **no ip route** command to delete a static routing rule.
You can verify your setting by entering the **show ip route** Privileged EXEC command

Example The following example shows how to configure a static route.

```
Switch(config)# vlan 2
Switch(config)# interface GigabitEthernet 4
Switch(config-if)# switchport trunk allowed vlan add 2
Switch(config)# interface vlan 2
Switch(config-if)# ip address 192.168.3.1 255.255.255.0
Switch(config)# ip route 1.1.1.1 255.0.0.0 192.168.3.11
Switch# show ip route
Codes: > - best, C - connected, S - static

S> 1.0.0.0/8 [1/1] via 192.168.3.11, VLAN 2
C> 192.168.0.0/24 is directly connected, MGMT VLAN
C> 192.168.3.0/24 is directly connected, VLAN 2
```

IPv4 ARP

Syntax `arp ip-addr mac-addr vlan vlanid`

no arp `ip-addr mac-addr vlan vlanid`

Parameter	<i>ip-addr</i>	IP address of ARP entry
	<i>mac-addr</i>	MAC address of ARP entry
	<i>vlanid</i>	Vlan ID of this arp entry

Default The device contains ARP entries of the vlan interface.

Mode Global Configuration mode.

Usage Use the **arp** command to add a static arp entry.
 Use the **no arp** command to delete a static arp entry.
 You can verify your setting by entering the **show arp** Privileged EXEC command

Example The following example shows how to configure and view a static arp entry.

```
Switch(config)# arp 192.168.3.22 00:00:11:11:11:11 vlan 2
Switch# show arp
VLAN Interface IP address HW address Status
-----
vlan 1 192.168.0.112 00:D0:00:00:00:01 Dynamic
vlan 2 192.168.3.22 00:00:11:11:11:11 Static
```

IPv6 Interface

Syntax **interface vlan** *vlanid*
ipv6 enable
no interface vlan *vlanid*
no ipv6 enable

Parameter *vlanid* Vlan id for vlan interface

Default The vlan interface are not configured by default.Ipv6 is disabled.

Mode Global configuration and vlan interface configuration.

Usage Use the **interface vlan** global configuration command to config ip interface on the device.
 Use the **ipv6 enable** command in vlan interface mode to enable ipv6 function.
 Use the **no ipv6 enable** command to disable ipv6 function.
 Use the **no interface vlan** command to delete ip interface on the device.
 You can verify your setting by entering the **show ipv6 interface vlan** Privileged EXEC command.

Example The following example shows how to config ip interface.

```
Switch(config)# interface vlan 2
Switch(config-if)# ipv6 enable
Switch# show ipv6 interface vlan 2
```

```
VLAN 2 is up/up
IPv6 is enabled, link-local address is fe80::2e0:4cff:fe00:0
IPv6 Forwarding is enabled
No global unicast address is configured
```

Joined group address(es):
 ff02::1:ff00:0
 ff02::1
 ff01::1
 ND DAD is enabled, number of DAD attempts: 1
 Stateless autoconfiguration is enabled

IPv6 Address

Syntax	ipv6 address <i>ipv6-addr</i> no ipv6 address
Parameter	<i>ipv6-addr</i> Manually configured ipv6 address

Default The vlan interface are not configured by default.Ipv6 is disabled.

Mode Global configuration and vlan interface configuration.

Usage Use the **ipv6 address** command in vlan interface mode to config a manual ipv6 address.
 Use the **no ipv6 address** command in vlan interface mode to delete all manual ipv6 addresses on this vlan interface.
 You can verify your setting by entering the **show ipv6 interface vlan** Privileged EXEC command.

Example The following example shows how to config ip interface.

```

Switch(config)# interface vlan 2
Switch(config-if)# ipv6 address 2001:01::01:01/64
Switch# show ipv6 interface vlan 2
VLAN 2 is up/up
IPv6 is enabled, link-local address is fe80::2e0:4cff:fe00:0
IPv6 Forwarding is enabled
Global unicast address(es):
IPv6 Global Address Type
2001:1::1:1/64 Manual
Joined group address(es):
ff02::1:ff01:1
ff02::1:ff00:0
ff02::1
ff01::1
ND DAD is enabled, number of DAD attempts: 1
Stateless autoconfiguration is enabled Stateless autoconfiguration is enabled
  
```

IPv6 Routes

Syntax	ipv6 route <i>ipv6-addr/length route-ipv6-addr</i> no ipv6 address <i>ipv6-addr/length</i>
---------------	---

Parameter	<i>ipv6-addr/length</i>	Destination ipv6 prefix and length
	<i>route-ipv6-addr</i>	Forwarding router's ipv6 address

Default The ipv6 routing entry is not configured by default.

Mode Global configuration and vlan interface configuration.

Usage Use the **ipv6 route** command to configure a static ipv6 routing entry.
 Use the **no ipv6 address** command to delete a static ipv6 routing entry.
 You can verify your setting by entering the **show ipv6 route static** Privileged EXEC command.

Example The following example shows how to configure an ipv6 routing entry.

```
Switch(config)# ipv6 route 2002:01::01:01/96 2001:01::01:02
Switch# show ipv6 route static
Codes: A - active, I - inactive

I 2002:1::/96 [1/1] via 2001:1::1:2, inactive
```

IPv6 Neighbors

Syntax	ipv6 neighbor <i>ipv6-addr</i> vlan <i>vlanid</i> <i>macaddr</i>	
	no ipv6 neighbor	
Parameter	<i>ipv6-addr</i>	Neighbor ipv6 address
	<i>vlanid</i>	Vlan interface number
	<i>macaddr</i>	MAC address of ipv6 neighbor entry

Default No ipv6 neighbor address by default.

Mode Global configuration.

Usage Use the **ipv6 neighbor** command to configure a static ipv6 neighbor entry.
 Use the **no ipv6 neighbor** command to delete ipv6 neighbor entry.
 You can verify your setting by entering the **show ipv6 neighbors** Privileged EXEC command.

Example The following example shows how to configure an ipv6 neighbor entry.

```
Switch(config)# ipv6 neighbor 2001:01::01:11 vlan 2 00:00:00:11:11:12
Switch# show ipv6 neighbors
VLAN Interface IPv6 address HW address Status Router State
-----
-----
vlan 2 2001:1::1:11 00:00:00:11:11:12 Static No

Total number of entries: 1
```

<i>hours</i>	Port poe power supply hours
--------------	-----------------------------

Default All ports open POE function all day by default.
(Poe-enabled device)

Mode interface configuration.

Usage Use the **poe schedule** command in interface mode to set port poe power supply time.
Use the **no poe schedule** command in interface mode to clear port poe power supply time..
You can check the port poe work time setting view through the web.

Example The following example shows how to config poe schedule.
Switch(config)# **interface GigabitEthernet 1**
Switch(config-if)# **poe schedule week mon hour 1**

Note: The configured time has a deviation of about 0~10 minutes.

40.ERPS

Erps (global)

Syntax	erps no erps
---------------	-----------------

Parameter	no
------------------	----

Default disable

Mode global configuration.

Usage Run the "erps" command to enable global ERPS.

Example Enable ERPS
Switch(config)# erps

Erps instance (Global)

Syntax	erps instance <1-15> no erps instance <1-15>
---------------	---

Parameter	<1-15>instance id range
------------------	-------------------------

Default no

Mode global configuration.

Usage Run the erps instance command to create an ERPS instance.

Example Set ERPS instance to 0
Switch(config)# erps instance 0

Control-vlan

Syntax control-vlan <1-4094>
no control-vlan

Parameter <1-4094>vlan id range

Default default vlan id 1

Mode ERPS configuration mode.

Usage Run the control-vlan command to set up an ERPS instance to control a VLAN.

Example Example Set the control VLAN to 2
Switch(config-erps-inst)# control-vlan 2

wtr-timer

Syntax wtr-timer <1-12>
no wtr-timer

Parameter <1-12> wtr timer value is from 1 to 12 minutes

Default default 5 minutes

Mode erps configuration mode.

Usage Run the wtr-timer command to set the WTR time in the ERPS.

Example Set the WTR time of the ERPS to 6 minutes
Switch(config-erps-inst)# wtr-timer 6

guard-timer

Syntax **guard-timer <100-2000>**
 no guard-timer

Parameter <100-2000>ms

Default default guard timer is 500ms

Mode erps configuration mode.

Usage Run the guard-timer command to set the guard time in the ERPS.

Example Set erps ring guard-timer 100ms
 Switch(config-erps-inst)# **guard-timer 100**

work-mode

Syntax **work-mode non_revertive**
 work-mode revertive

Parameter no

Default Default Revertive Indicates the reversible mode

Mode erps configuration mode.

Usage Run the "work-mode revertive" command to set the working mode in ERPS..

Example Set ERPS working mode to the reversible mode
 Switch(config-erps-inst)# work-mode revertive

ring<ID>

Syntax **ring <1-239>**

Parameter <1-239>ring id is from 1 to 239

Default The default ring ID is 1

Mode erps configuration mode.

Usage Run the "ring <1-239>" command to set the ring ID of the ERPS.

Example Example Set the ring ID to 2
Switch(config-erps-inst)# **ring 2**

ring-level

Syntax ring-level <0-1>

Parameter <0-1>0 is the primary ring and 1 is the subring

Default 0 is the primary ring

Mode erps configuration mode.

Usage Run the "ring-level <0-1>" command to set the primary ring to 0 and the subring to 1 in the ERPS

Example Set the ERPS ring to subring
Switch(config-erps-inst)# **ring-level 1**

port

Syntax port0 IF_PORTS (owner|neighbour|next-neighbour)

Port1 IF_PORTS (owner|neighbour|next-neighbour)

Parameter IF_PORTS port number

Default port 1

Mode erps configuration mode.

Usage Use the command "port0 IF_PORTS (owner | neighbour | next - neighbour)" set the erps central to the owner, neighbour, next - neighbour.

Example Set port 2 as the owner node
Switch(config-erps-inst)# **port0 GigabitEthernet2 owner**

mel

Syntax **mel <0-7>**

Parameter **<0-7>** mel value is form 0 to 7

Default mel is 0

Mode erps configuration mode.

Usage Use the command "MEL <0-7>" to set the instance level in ERPS.

Example Example Set the instance mel to 2
 Switch(config-erps-inst)# **mel 2**

Ring enable

Syntax **ring enable**

ring disable

Parameter **no**

Default disable

Mode erps configuration mode.

Usage Use the command "ring (enable | disable)" set the erps central is enabled.

Example Set ring enable
 Switch(config-erps-inst)# **ring enable**

protected-instance

Syntax **protected-instance <0-15>**

Parameter **<0-15>** mstp instance id is form 0 to 15

Default no

Mode erps configuration mode.

Usage

Using the command 'protected-instance' Sets the loop protection instance

Example Set ring protected-instance is 1
Switch(config-erps-inst)# **protected-instance 1**

Show erps instance

Syntax **show erps instance all**
show erps instance <0-15>

Parameter <0-15>instance id form 0 to 15

Default no

Mode global configuration.

Usage display erps information

Example Display erps information
Switch# **show erps instance all**
Erps instance : 1
Erps ring status :disable
Erps mel :1
Erps control vlan : 1
Erps WTR time : 5 min
Erps guard time : 500 ms
Erps work-mode :revertive
Erps ring ID :1
Erps ring-level :0
Erps protected-instance :0
Erps port0 portId:GE1, port role :rpl, port status:forwarding
Erps port1 portId:GE1, port role :rpl, port status:forwarding
Erps ring node state :init

41.OSPF

Ospf (global)

Syntax **ospf**
no ospf

Parameter no

Default disable

Mode global configuration.

Usage Run the `ospf` command to enable and enter OSPF process 1.

Example

```

Ebable OSPF
Switch(config)# ospf
Switch(config-ospf-1)#
Example Query OSPF process information.
Switch# show ospf
FOUND.000 aaaaa.txt cccc.txt
System Volume Information bbbb.txt
Switch#
  OSPF Process 1, Router ID: 1.1.1.1
  Supports only single TOS (TOS0) routes
  This implementation conforms to RFC2328
  RFC1583Compatibility flag is disabled
  OpaqueCapability flag is disabled
  Initial SPF scheduling delay 0 millise(c)s
  Minimum hold time between consecutive SPF(s) 50 millise(c)s
  Maximum hold time between consecutive SPF(s) 5000 millise(c)s
  Hold time multiplier is currently 2
  SPF algorithm last executed 5m44s ago
  SPF timer is inactive
  LSA minimum interval 0 msec(s)
  LSA minimum arrival 0 msec(s)
  Write Multiplier set to 0
  Refresh timer 10 sec(s)
  This router is an ABR, ABR type is: Alternative Cisco
  Number of external LSA 0. Checksum Sum 0x00000000
  Number of opaque AS LSA 0. Checksum Sum 0x00000000
  Number of areas attached to this router: 2
  Area ID: 0.0.0.0 (Backbone)
  Number of interfaces in this area: Total: 3, Active: 1
  Number of fully adjacent neighbors in this area: 0
  Area has no authentication
  SPF algorithm executed 2 times
  Number of LSA 2
  Number of router LSA 1. Checksum Sum 0x0000ce04

  Number of summary LSA 1. Checksum Sum 0x0000914a
  Number of ASBR summary LSA 0. Checksum Sum 0x00000000
  Number of NSSA LSA 0. Checksum Sum 0x00000000
  Number of opaque link LSA 0. Checksum Sum 0x00000000
  Number of opaque area LSA 0. Checksum Sum 0x00000000

  Area ID: 0.0.0.1
  Shortcutting mode: Default, S-bit consensus: ok
  Number of interfaces in this area: Total: 1, Active: 1
  Number of fully adjacent neighbors in this area: 0
  Area has no authentication
  Number of full virtual adjacencies going through this area: 0
  SPF algorithm executed 1 times
  Number of LSA 2
  Number of router LSA 1. Checksum Sum 0x000017b3
  Number of network LSA 0. Checksum Sum 0x00000000
  
```

Number of summary LSA 1. Checksum Sum 0x0000e9f9
 Number of ASBR summary LSA 0. Checksum Sum 0x00000000
 Number of NSSA LSA 0. Checksum Sum 0x00000000
 Number of opaque link LSA 0. Checksum Sum 0x00000000
 Number of opaque area LSA 0. Checksum Sum 0x00000000

router-id

Syntax `router-id A.B.C.D`

`no router-id`

Parameter `A.B.C.D ipv4 address`

Default no

Mode ospf configuration mode.

Usage Run the "router-id 1.1.1.1" command to set the router ID of OSPF process 1 to 1.1.1.1.

Example Switch(config)# `ospf`
 Switch(config-ospf-1)#`router-id 1.1.1.1`

timers throttle spf

Syntax `timers throllle spf <0-60000> <0-60000> <0-60000>`

`no timers throllle spf`

Parameter `<1-4094>vlan id`

Default delay time 0, hlod time 50, max hold time 5000

Mode ospf configuration mode.

Usage Run the timers throllle SPF 10 100 10000 command to configure the timer for SPF calculation of OSPF process 1.

Delay time <0-60000>
 Delay time between receiving topology change and SPF calculation
 Hold time <0-60000>
 Hold time between two discontinuous SPF calculations
 Max hold time <0-60000>
 Maximum hold time

Example Switch(config)# **ospf**
Switch(config-ospf-1)#**timers throttle spf 10 100 10000**

refresh timer

Syntax refresh timers <10-1800>

no refresh timers

Parameter <10-1800> timer is 10 to 1800 second

Default default 10 second

Mode ospf configuration mode.

Usage

Run the refresh timers 100 command to set the refresh time 100 of OSPF process 1.

Refresh time <0-60000>

Interval for refreshing routes

Example Switch(config)# **ospf**
Switch(config-ospf-1)#**refresh timers 100**

auto-cost reference-bandwidth

Syntax auto-cost reference-bandwidth <1-4294967>

no auto-cost reference-bandwidth

Parameter <1-4294967>Reference bandwidth in megabits per second. The value ranges from 1 to 4294967

Default bandwidth 100000

Mode ospf configuration mode.

Usage Run the "auto-cost reference-bandwidth" command to configure the reference bandwidth of OSPF process 1.

Example Set the reference bandwidth of OSPF process 1 to 1000000 (1000M).
Switch(config)# **ospf**
Switch(config-ospf-1)#**auto-cost reference-bandwidth 1000000**

default-metric

Syntax **default-metric <0-16777214>**

no default-metric

Parameter **<0-16777214>** Set the default metric for importing routes. ranges from 0 to 16777214

Default Default metric 20

Mode ospf configuration mode.

Usage Run the "default-metric" command to configure the reference bandwidth of OSPF process 1.

Example When OSPF process 1 imports routes, the default metric is 30
 Switch(config)# **ospf**
 Switch(config-ospf-1)#**default-metric 30**

passive-interface vlan-interface

Syntax **passive-interface vlan-interface <1-4094>**
no passive-interface vlan-interface

Parameter **<1-4094>**,Vlan interface. The value ranges from 1 to 4094

Default no

Mode ospf configuration mode.

Usage Run the "passive-interface vlan-interface" command to configure the mode of OSPF process 1 on a specific interface and use it with the passive interface default command.

Example Configure VLAN interface 1 of OSPF process 1 not to send Hello packets
 Switch(config)# **ospf**
 Switch(config-ospf-1)# **passive-interface vlan-interface 1**

passive-interface default

Syntax **passive-interface default**
no passive-interface default

Parameter **no**

Default The default passive interface mode is disabled by default

Mode ospf configuration mode.

Usage Run the "passive interface default" command to configure the default interface mode of OSPF process 1.

Example Configure the default interface of OSPF process 1 to the passive mode
 Switch(config)# **ospf**
 Switch(config-ospf-1)# **passive-interface default**

area

Syntax **area (A.B.C.D|<0-4294967295>)**

no area (A.B.C.D|<0-4294967295>)

Parameter A.B.C.D area identifier in the format of an IP address

The value is a decimal integer ranging from 0 to 4294967295. The system processes the value as an IP address.

Default no

Mode ospf configuration mode.

Usage Run the "area" command to configure the area of OSPF process 1 and enter the area mode

Example Configure area 0 of OSPF process 1 and enter the area mode
 Switch(config)# **ospf**
 Switch(config-ospf-1)# **area 0**
 Switch(config-ospf-1-area-0.0.0.0)#

network

Syntax **network A.B.C.D/M**
no network A.B.C.D/M

Parameter A.B.C.D/M Network address and mask

Default By default, the interface does not belong to any area and the OSPF function is disabled.

Mode Area Configuration Mode

Usage Run the "network A.B.C.D/M" command to enable OSPF on each network interface of the device in the OSPF area to which it belongs.

Example Specify the IP address of the interface 10.1.1.0/24. Run OSPF in area 0.
 Switch(config)# **ospf**
 Switch(config-ospf-1)# **area 0**
 Switch(config-ospf-1-area-0.0.0.0)# **network 10.1.1.0/24**

default-cost

Syntax **default-cost <0-16777215>**
no default-cost

Parameter Cost range <0-16777215>

Default default cost is 1

Mode Area Configuration Mode

Usage Run the "default-cost <0-16777215>" command to set the default cost of the imported default route in the stub/NSSA area. This command applies only to the ABR routers connected to the stub area or NSSA area.

Example The default cost for area 1 is 10.
 Switch(config)# **ospf**
 Switch(config-ospf-1)# **area 1**
 Switch(config-ospf-1-area-0.0.0.1)#**default-cost 10**

authentication

Syntax **authentication [message-digest]**
no authentication

Parameter message-digest MD5 authentication mode: This parameter is optional. If this parameter is not selected, the simple authentication mode is adopted (the password is in plain text).

Default disable

Mode Area Configuration Mode

Usage Use the "authentication" command to configure the authentication mode for OSPF packets in an OSPF area.

Example Configure OSPF area 0 to use MD5 authentication
 Switch(config)# **ospf**
 Switch(config-ospf-1)# **area 0**
 Switch(config-ospf-1-area-0.0.0.0)#**authentication message-digest**

ospf authentication

Syntax	ospf authentication [(null message-digest)] no ospf authentication
Parameter	message-digest MD5 authentication mode: This parameter is optional. If this parameter is not selected, the simple authentication mode is adopted (the password is in plain text). Null Null indicates no authentication

Default The authentication function is disabled by default

Mode Layer 3 interface configuration mode

Usage Run the ospf authentication command to configure the interface to authenticate OSPF packets and the authentication mode.

Using the ospf authentication null and no ospf authentication commands, you can cancel the configured authentication mode on an interface.

Example Configure plaintext authentication for VLANIF1
Switch(config)# **interface vlan 1**
Switch(config-if-vlan1)# **ospf authentication**

ospf authentication-key

Syntax	ospf authentication-key WORD<1-64> no ospf authentication-key
Parameter	Word <1-64>-Plaintext authentication password

Default By default, no authentication password is configured

Mode Layer 3 interface configuration mode

Usage Run the ospf authentication-key command to configure the plaintext password for the interface to authenticate OSPF packets.

Example Configure plaintext authentication for VLANIF1
Switch(config)# **interface vlan 1**
Switch(config-if-vlan1)# **ospf authentication-key 123456**

ospf authentication-digest-key

Syntax	ospf authentication-digest-key <1-255> md5 WORD<1-64> no ospf authentication-digest-key <1-255>
Parameter	<1-255> Key value for MD5 encryption authentication

Word MD5 authentication password

Default By default, MD5 authentication is not configured

Mode Layer 3 interface configuration mode

Usage Run the `ospf authentication-digest-key` command to configure the MD5 key value and password for the interface to authenticate OSPF packets.

Example Configure the MD5 key and password for VLANIF1
 Switch(config)# **interface vlan 1**
 Switch(config-if-vlan1)# **ospf authentication-digest -key 1 md5 password**

ospf cost

Syntax `ospf cost <1-65535>`
`no ospf cost`

Parameter `<1-65535>` The path cost ranges from 1 to 65535

Default The default path cost is 10.

Mode Layer 3 interface configuration mode

Usage Run the "ospf cost" command to set the cost for running OSPF on the interface.

Example Set the path cost of VLANIF1 to 20
 Switch(config)# **interface vlan 1**
 Switch(config-if-vlan1)# **ospf cost 20**

ospf priority

Syntax `ospf priority <0-255>`
`no ospf priority`

Parameter DR priority of the interface. The value ranges from 0 to 255

Default
 The DR priority of the default interface is 1

Mode Layer 3 interface configuration mode

Usage Run the "ospf priority" command to set the cost of running OSPF on the interface.
 The DR priority of an interface determines the qualification of the interface in DR/BDR election. A larger value indicates a higher priority. Those with higher priority are considered first when there is a conflict over voting rights. If the priority of a device is 0, it is not elected as DR or BDR.

Example Set the priority of VLANIF1 to 10
 Switch(config)# **interface vlan 1**
 Switch(config-if-vlan1)# **ospf priority 10**

ospf hello-interval

Syntax **ospf hello-interval <1-65535>**
no ospf hello-interval

Parameter **<1-65535> Interval for the interface to send Hello packets. The value ranges from 1 to 65535 seconds**

Default The default interval for the interface to send Hello packets is 10 seconds

Mode Layer 3 interface configuration mode

Usage Run the ospf hello-interval command to set the interval for sending Hello packets on the interface.

Example The interval for the interface to send Hello packets was set to 30 seconds
 Switch(config)# **interface vlan 1**
 Switch(config-if-vlan1)# **ospf hello-interval 30**

ospf dead-interval

Syntax **ospf dead-interval <1-65535>**
no ospf dead-interval

Parameter **<1-65535> The value ranges from 1 to 65535 seconds**

Default By default, the failure time of OSPF neighbors on P2P and Broadcast interfaces is 40 seconds. The OSPF neighbor failure time of P2MP and NBMA interfaces is 120 seconds.

Mode Layer 3 interface configuration mode.

Usage Run the ospf dead-interval command to set the dead interval of the OSPF neighbor on the interface

Example The OSPF neighbor failure interval of the interface was set to 60 seconds
 Switch(config)# **interface vlan 1**
 Switch(config-if-vlan1)# **ospf dead-interval 60**

ospf retransmit-interval

Syntax **ospf retransmit-interval <1-65535>**
no ospf retransmit-interval

Parameter <1-65535>Interval for retransmitting LSA on an interface. The value ranges from 1 to 65535 seconds

Default By default, the interval for retransmitting LSA on the interface is 5 seconds.

Mode Layer 3 interface configuration mode.

Usage Run the ospf retransmit-interval command to set the interval for the OSPF neighbor to expire on the interface.

Example The interval for retransmitting LSA on the interface was set to 10 seconds
 Switch(config)# **interface vlan 1**
 Switch(config-if-vlan1)# **ospf retransmit-interval 10**

ospf transmit-delay

Syntax ospf transmit-delay <1-65535>
 no ospf transmit-delay

Parameter <1-65535> Delay for transmitting LSA on an interface. The value ranges from 1 to 65535 seconds

Default By default, the delay for transmitting LSA on the interface is 1 second

Mode Layer 3 interface configuration mode.

Usage Run the ospf transmit-delay command to set the time for the OSPF neighbor to become invalid on the interface

Example The delay for transmitting LSA on the interface was set to 2 seconds.
 Procedure
 Switch(config)# **interface vlan 1**
 Switch(config-if-vlan1)# **ospf transmit-delay 2**

ospf network

Syntax ospf network (broadcast|non-broadcast|point-to-multipoint|point-to-point)
 no ospf network

Parameter Broadcast interface The OSPF network type is broadcast
 Non-broadcast interface The OSPF network type is NBMA
 Point-to-multipoint interface The OSPF network type is point-to-multipoint
 Point-to-point interface The OSPF network type is point-to-point

Default The default network type of the interface is broadcast.

Mode Layer 3 interface configuration mode.

Usage Run the `ospf transmit-delay` command to set the OSPF network type of the interface.

Example The OSPF network type of the interface is set to point-to-point
 Switch(config)# **interface vlan 1**
 Switch(config-if-vlan1)# **ospf point-to-point**

ospf mtu-ignore

Syntax	ospf mtu-ignore no ospf mtu-ignore
---------------	---

Parameter	no
------------------	-----------

Default The MTU needs to be checked by default.

Mode Layer 3 interface configuration mode.

Usage
 Run the "ospf mtu-ignore" command to configure the interface not to check the MTU size during DD exchange

Example The MTU size is not checked when the interface performs DD switching
 Switch(config)# **interface vlan 1**
 Switch(config-if-vlan1)# **ospf mtu-ignore**

42.RIP

rip (Global)

Syntax	rip no rip
---------------	-----------------------------

Parameter	no
------------------	-----------

Default disable

Mode global configuration.

Usage Run the "rip" command to enable and enter the RIP process.

Example Enable ERPS
 Switch(config)# **rip**
 Switch(config-rip)#

network

Syntax **network A.B.C.D/M**
no network A.B.C.D/M

Parameter A.B.C.D/M IPv4 Address Source and destination IPv4 address and mask

Default no

Mode rip configuration mode.

Usage Run the "rip" command to enable and enter the RIP process.

Example used to enable RIP on an interface on a specified network segment
 Switch(config)# **rip**
 Switch(config-rip)#**network 192.168.2.10/24**

route

Syntax **route A.B.C.D/M**
no route A.B.C.D/M

Parameter A.B.C.D/M IPv4 Address Source and destination IPv4 address and mask

Default no

Mode rip configuration mode.

Usage Run the "route" command to Configuring RIP Routes

Example Configuring RIP Routes
 Switch(config)# **rip**
 Switch(config-rip)#**route 192.168.10.2/24**

version

Syntax **version (1|2)**

Parameter Specify the RIP version RIPv1 or RIPv2

Default default RIPv1

Mode rip configuration mode.

Usage Specify the RIP version RIPv1 or RIPv2

Example Config RIP version is RIPv2
 Switch(config)# rip
 Switch(config-rip)#version 2

distance

Syntax distance <1-255>
 no distance

Parameter <1-255> Effectively manage distance range 1-255

Default The default is 120

Mode rip configuration mode.

Usage Effectively manage distance range

Example Specify RIP Specifies a management distance of 100
 Switch(config)# rip
 Switch(config-rip)#distance 100

distance

Syntax distance <1-255> A.B.C.D/M
 no distance <1-255> A.B.C.D/M

Parameter A.B.C.D/M IPv4 Address Source and destination IPv4 address and mask
 <1-255> Effectively manage distance range 1-255

Default no

Mode rip configuration mode.

Usage Specify RIP Specifies a network address for the management distance

Example Config specify a management distance 100 network address for the specified RIP
 Switch(config)# rip
 Switch(config-rip)#distance 100 192.168.10.12/24

distribute-list

Syntax **distribute-list WORD<1-32> (in|out) interface vlan <1-4094>**
no distribute-list WORD<1-32> (in|out) interface vlan <1-4094>

Parameter WORD < 1-32 > 32 characters
 In | out configuration into the direction or the direction
 <1-4094> Vlan ID

Default no

Mode rip configuration mode.

Usage config RIP distribution list.

Example config RIP distribution list.
 Switch(config)# rip
 Switch(config-rip)#distribute-list test in interface vlan 1

access-list

Syntax **access-list WORD<1-32> (deny|permit) A.B.C.D/M [exact-match]**
access-list WORD<1-32> (deny|permit) any
no access-list WORD<1-32> (deny|permit) A.B.C.D/M [exact-match]

Parameter WORD < 1-32 > 32 characters
 Deny | permit denied or allowed
 A.B.C.D/M Source and destination IPv4 addresses and masks of IPv4
 addresses

Default no

Mode rip configuration mode.

Usage Run the "access-list" command to RIP an access list

Example Specify a RIP access list
 Switch(config)# rip
 Switch(config-rip)#access-list test deny 192.168.2.20/24

show ip route rip

Syntax show ip route rip

Parameter No

Default no

Mode global configuration.

Usage Displaying RIP Information.

Example Displaying RIP Information
Switch(config)# show ip route rip

log

Syntax	log rip console no log rip console log rip file no log rip file
---------------	--

Parameter	No
------------------	----

Default no

Mode global configuration mode.

Usage Run the log rip file command to enable RIP log output to a file

Run the log rip console command to enable outputting logs to the serial port

Example RIP syslog log
Switch(config)# log rip file
Switch(config)# log rip console

43.VRRP

vrrp vrid

Syntax	vrrp vrid vrid virtual-ip A.B.C.D no vrrp vrid vrid virtual-ip A.B.C.D
---------------	---

Parameter	Vrid Backup group ID ranges from 1 to 5 A.B.C.D Indicates the virtual IP address
------------------	---

Default no

Mode VLAN interface configuration mode

Usage Using this command, you can assign an IP address on a local network segment to a virtual switch (also known as a backup group).

Example Configure a virtual group for VLAN interface 1 and set the virtual IP address to 192.168.1.1
 Switch(config-if-vlan1)# vrrp vrid 1 virtual-ip 192.168.1.1

vrrp priority

Syntax **vrrp vrid vrid priority <1-254>**
no vrrp vrid vrid priority

Parameter Vrid Backup group ID ranges from 1 to 5
 <1-254> Priority range

Default Priority 100

Mode VLAN interface configuration mode.

Usage The value of priority ranges from 0 to 255 (a higher value indicates a higher priority).

Example Set the priority of the switch in backup group 1 to 200
 Switch(config-if-vlan1)#**vrrp vrid 1 priority 200**

preempt-mode

Syntax **vrrp vrid <1-5> preempt-mode [timer delay <0-255>]**
no vrrp vrid <1-5> preempt-mode

Parameter Vrid Backup group ID ranges from 1 to 5
 Delay <0-255> Preemption mode and delay of the backup group

Default disable

Mode VLAN interface configuration mode

Usage Configure the preemption mode and delay of the backup group.

Example Configure the preemption mode and delay of the backup group
 Switch(config-if-vlan1)#**vrrp vrid 1 preempt-mode 1 timer delay 3**

advertise

Syntax **vrrp vrid <1-5> timer advertise <1-255>**
no vrrp vrid <1-5> timer advertise

Parameter Vrid Backup group ID ranges from 1 to 5
 Advertise <1-255> Configure the advertisement interval of the backup group

Default advertise default 1

Mode VLAN interface configuration mode.

Usage Set the notification interval for the backup group.

Example Set the notification interval of backup group 1 to 1 second
 Switch(config-if-vlan1)#vrrp vrid 1 timer advertise 1

track

Syntax vrrp vrid <1-5> track vlan-interface <1-4094> [reduced <1-254>]
 no vrrp vrid <1-5> track vlan-interface <1-4094>

Parameter Vrid Backup group ID ranges from 1 to 5
 <1-4094> Indicates the VLAN ID of the interface
 <1-254> Priority reduction value range

Default no

Mode VLAN interface configuration mode.

Usage Priority reduction value range

Example Set monitoring interface of backup group 1 to VLAN interface 2, and set its priority reduction value to 20
 Switch(config-if-vlan1)#vrrp vrid 1 vlan-interface 2 reduced 20

show

Syntax show vrrp [vlan-interface <1-4094>]
 show vrrp vlan-interface <1-4094> vrid <1-5>

Parameter Vrid Backup group ID ranges from 1 to 5
 <1-4094> Indicates the VLAN ID of the interface

Default no

Mode global configuration.

Usage Displaying VRRP Information.

Example Displaying VRRP Information.
 Switch(config)#show vrrp

44.DHCP SERVER

dhcp-server

Syntax	dhcp-server no dhcp-server
---------------	---

Parameter	no
------------------	----

Default disable

Mode global configuration.

Usage The DHCP server was enabled or disabled

Example Ebable DHCP server
Switch(config)# **dhcp-server**

dhcp-server group(global)

Syntax	dhcp-server group <1-256> ip A.B.C.D no dhcp-server group <1-256> ip
---------------	---

Parameter	<1-256 > ID of a Dhcp server group A.B.C.D Ipv4 address
------------------	--

Default no

Mode global configuration.

Usage Configure a DHCP server group.

Example Configure DHCP server group 1, IP address: 192.168.1.10
Switch(config)# **dhcp-server group 1 ip 192.168.1.10**

ip pool

Syntax	ip pool WORD<1-32> no ip pool WORD<1-32>
---------------	---

Parameter	WORD<1-32> Name of the Dhcp address pool. The value is a string of 1 to 32 characters
------------------	---

Default no

Mode global configuration.

Usage The DHCP address pool name is specified.

Example The DHCP address pool name is 'test' .
Switch(config)# **ip-pool test**

gateway

Syntax gateway A.B.C.D/M
no gateway

Parameter A.B.C.D/M Gateway ipv4 address

Default no

Mode Ip-pool Indicates the Ip address pool configuration mode.

Usage The gateway address of the address pool was set.

Example The gateway address of address pool 1 on the DHCP server is specified
Switch(config-ip-pool-1)# **gateway 192.168.2.1/24**

section

Syntax section <1-8> A.B.C.D A.B.C.D
no section <1-8>

Parameter <1-8> Session ids in the address pool range from 1 to 8
A.B.C.D A.B.C.D Address Pool Valid IP address range of the session

Default no

Mode Ip-pool Indicates the Ip address pool configuration mode.

Usage The valid IP address of the address pool is specified.

Example Configure IP addresses 192.168.2.2 to 192.168.2.10 in address pool 1 of the DHCP server.
Switch(config-ip-pool-1)#**section 0 192.168.2.2 192.168.2.10**

dhcp-server group(if-vlan)

Syntax dhcp-server group <1-256>
no dhcp-server group <1-256>

Parameter <1-256> Indicates the ID range of the interface configuration group

Default no

Mode VLAN interface configuration mode.

Usage The interface DHCP server group was configured.

Example The interface DHCP server group ID is set to 1.
Switch(config-if-vlan1)#dhcp-server group 1

show dhcp-server

Syntax show dhcp-server
show dhcp-client

Parameter no

Default no

Mode global configuration.

Usage The DHCP server information is displayed

The DHCP client information is displayed.

Example Displaying DHCP server Information.
Switch(config)# **show dhcp-server**

DHCP server : enabled

interface dhcp server group ip
Displaying DHCP client Information.
Switch(config)#**show dhcp-client**
dhcp-client bind table info:
MAC Address ipAddress VlanId UserName

Total 0 entry.

45.DNS

ip domain

Syntax ip domain lookup
no ip domain lookup

Parameter no

Default disable

Mode global configuration.

Usage The DNS server was enabled or disabled.

Example Enabling the DNS Server
Switch(config)# ip domain lookup

ip domain name

Syntax ip domain name HOSTNAME
no ip domain name

Parameter HOSTNAME Domain name character

Default no

Mode global configuration.

Usage Run the '**ip domain name**' command to The domain name .

Example Set The domain name is test
Switch(config)# ip domain name test

ip name-server

Syntax ip name-server (A.B.C.D|X:X::X:X) [(A.B.C.D|X:X::X:X)]
[(A.B.C.D|X:X::X:X)] [(A.B.C.D|X:X::X:X)]
no ip name-server (A.B.C.D|X:X::X:X) [(A.B.C.D|X:X::X:X)]
[(A.B.C.D|X:X::X:X)] [(A.B.C.D|X:X::X:X)]

Parameter A.B.C.D Ipv4 address
X:X::X:X Ipv6 address

Default no

Mode global configuration.

Usage Configure the available domain name servers.

Example Set the DNS server to 192.168.2.10.
Switch(config)# ip name-server 192.168.2.10

ip host

Syntax ip host HOSTNAME (A.B.C.D|X:X::X:X)
no ip host HOSTNAME

Parameter A.B.C.D Ipv4 address
X: X: X: X Ipv6 address
HOSTNAME Domain name String

Default no

Mode global configuration.

Usage Configure the mapping between static domain names and IP address.

Example Set the static mapping between domain name 'test' and IP address '192.168.2.10'.
Switch(config)# **ip host test 192.168.2.10**

show hosts

Syntax show hosts

Parameter no

Default no

Mode global configuration.

Usage The DNS configuration information is displayed.

Example The DNS configuration information is displayed.
Switch(config)# **show hosts**

Name/address lookup is enabled

Default Domain Table

Domain Source Preference

Name Server Table

IP Address Source Preference

192.168.2.10 Static 1

Cache Table

Flags: (STA, OK)

STA - Static

OK - Okay

Host IP Address Type State

test 192.168.2.10 IPv4 STA,OK
